

W-KING H10

W-KING H10 Portable Bluetooth Speaker User Manual

Model: H10 | Brand: W-KING

INTRODUCTION

Thank you for choosing the W-KING H10 Portable Bluetooth Speaker. This powerful 2.1 Stereo 3-Way speaker delivers 120W RMS (240W Peak) audio with deep bass and clear highs, perfect for parties, outdoor events, or home use. It features versatile connectivity, microphone and guitar inputs, and advanced sound customization options. This manual provides detailed instructions to help you set up, operate, and maintain your speaker for optimal performance.



The W-KING H10 Portable Bluetooth Speaker, shown with its accompanying wireless microphone and remote control, ready for use.

SAFETY INFORMATION

Please read all safety instructions carefully before using the product. Keep this manual for future reference.

- Do not expose the speaker to extreme temperatures, humidity, or direct sunlight.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble, repair, or modify the speaker yourself. Refer all servicing to qualified personnel.
- Keep the speaker away from water and liquids. This product is not waterproof.
- Use only the provided charging cable and accessories.
- Ensure proper ventilation when operating the speaker.

PACKAGE CONTENTS

Verify that all items are present in the package:

- W-KING H10 Portable Bluetooth Speaker
- Wireless Microphone
- Remote Control
- AUX Cable

- Charging Adapter
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the various components and controls of your W-KING H10 speaker.

Top Panel Controls



The top panel features illuminated control knobs for volume, treble, bass, and echo, along with a digital display and playback buttons.

- **Volume/Treble/Bass/Echo Knobs:** Adjust audio parameters.
- **Display Screen:** Shows current mode, battery level, and settings.
- **Playback Controls:** Play/Pause, Next/Previous Track.
- **Mode Button:** Switch between Bluetooth, AUX, USB, TF Card modes.
- **EQ Button:** Toggle between different equalizer presets.

START YOUR CONCERT



Musical
accompaniment



Mic Priority

The rear panel provides multiple connectivity options including microphone, guitar, USB, TF card, Live, AUX, and DC power input.

- **MIC Input:** For wired microphones.
- **GUITAR Input:** For connecting a guitar or other instrument.
- **USB Port:** For USB drive playback and recording.
- **TF Card Slot:** For TF card playback and recording.
- **LIVE Port:** For live streaming connection.
- **AUX Input:** For connecting external audio devices via 3.5mm cable.
- **DC 15V/1.6A Input:** For charging the speaker.

SETUP

Charging the Speaker

1. Connect the charging adapter to the DC 15V/1.6A input port on the rear of the speaker.
2. Plug the adapter into a power outlet.
3. The battery indicator on the display will show charging status. Charge fully before first use (approximately 3-4 hours).

Bluetooth Pairing

1. Power on the speaker by pressing and holding the power button.
2. The speaker will automatically enter Bluetooth pairing mode (indicated by a flashing Bluetooth icon on the display).
3. On your mobile device, enable Bluetooth and search for "W-KING H10".
4. Select "W-KING H10" to connect. A voice prompt will confirm successful pairing.

Connecting Microphone and Guitar



The W-KING H10 speaker supports both wired microphones and guitar connections for versatile audio input.

- **Wireless Microphone:** The included wireless microphone is pre-paired. Simply turn it on to use.

- **Wired Microphone:** Plug a wired microphone into the MIC input port.
- **Guitar:** Plug your guitar into the GUITAR input port.
- Adjust the volume for both microphone and guitar using the dedicated knobs on the top panel.

Dual Stereo Pairing (TWS Function)



Pair two W-KING H10 speakers together for a powerful 240W true wireless stereo experience.

1. Ensure both W-KING H10 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (usually indicated by two interlocking circles).
3. The speaker will search for another W-KING H10. Once found, they will automatically connect, and you will hear a confirmation sound.
4. Now, connect your mobile device to the primary speaker via Bluetooth. Audio will play through both speakers in stereo.

OPERATING INSTRUCTIONS

Audio Playback

- **Bluetooth Mode:** After pairing, play audio from your connected device. Use the speaker's playback controls or your device's controls.
- **AUX Mode:** Connect an external audio device using the 3.5mm AUX cable to the AUX input. The speaker will automatically switch to AUX mode.
- **USB/TF Card Mode:** Insert a USB drive or TF card into the respective port. The speaker will automatically detect and play audio files.

Sound Customization

- **Bass/Treble Adjustment:** Use the dedicated knobs on the top panel to adjust bass and treble levels (12 levels of adjustment).
- **Equalizer Modes:** Press the EQ button to cycle through different equalizer presets, optimizing sound for various music genres.

Microphone Features



The W-KING H10 enhances your singing experience with musical accompaniment and microphone priority functions.

- **Microphone Volume/Treble/Bass/Reverb (Echo):** Adjust these settings directly on the wireless microphone or via the speaker's controls.
- **MIC Circumstances:** Choose from Original, Professional, Pop, or Reverb modes for the microphone.
- **Microphone Priority:** Press the instrument button to reduce the vocal track in a song, allowing your voice to be more prominent for karaoke.
- **Musical Accompaniment:** Use this feature to sing along with instrumental versions of songs.

Recording & Headphone Monitoring

RECORDING HEADPHONE MONITORING



Connect headphones to the W-KING H10 for private monitoring or listening, while also supporting recording to USB or TF card.

- **Recording:** Insert a TF card or USB drive. Use the recording function to capture your voice or performances. Recorded files can be played back directly from the speaker.
- **Headphone Monitoring:** Plug your headphones into the dedicated headphone jack to monitor your audio privately.

Live Streaming & Sound Effects

SPREAD YOUR VOICE



The W-KING H10 supports live streaming by connecting to your phone, allowing background music and microphone output to be mixed into your broadcast.

- **Live Streaming:** Connect your phone to the LIVE port using a suitable cable. Audio from the speaker, including microphone input, will be sent to your live stream as background music (BGM).
- **Sound Effects:** Use the remote control to trigger seven built-in sound effects, adding fun and engagement to your live broadcasts or parties.

Remote Control

The included remote control allows convenient operation from a distance, including volume adjustment, track skipping, mode selection, and sound effect activation.

MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

- **Battery Care:** To prolong battery life, charge the speaker regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not pressed correctly.	Charge the speaker; Press and hold the power button for a few seconds.
No sound.	Volume too low; Incorrect mode selected; Device not connected.	Increase volume; Press Mode button to select correct input; Reconnect Bluetooth/AUX/USB/TF.
Bluetooth connection unstable.	Device too far; Obstructions; Interference.	Move device closer to speaker; Remove obstructions; Avoid other wireless devices.
Microphone not working.	Microphone off; Low microphone battery; Volume too low.	Ensure microphone is on; Charge/replace microphone batteries; Increase microphone volume.

SPECIFICATIONS

Feature	Detail
Brand	W-KING
Model Number	H10
Output Wattage	120 Watts RMS (240W Peak)
Number of Channels	2.1 Stereo (3-Way)
Audio Input	Bluetooth, Wireless Microphone, Wired Microphone, Guitar, AUX, USB, TF Card
Power Source	Battery Powered
Product Dimensions (L x W x H)	5.87 x 14.76 x 9.33 inches
Item Weight	15.34 pounds
Recommended Uses	Indoor/Outdoor

WARRANTY AND SUPPORT

W-KING products come with a standard manufacturer's warranty. For detailed warranty information, technical support, or service inquiries, please refer to the official W-KING website or contact their customer service.

- **Official User Manual (PDF):** [Download PDF](#)
- **W-KING Store on Amazon:** [Visit Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question