Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM FR837-299V00ND0531

HOMCOM Shoe Cabinet with 2 Tilt-Out Doors

Model: FR837-299V00ND0531

1. Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your HOMCOM Shoe Cabinet. Please read these instructions thoroughly before beginning assembly and retain them for future reference. Proper assembly and care will ensure the longevity and functionality of your product.



Image 1.1: The HOMCOM Shoe Cabinet, featuring a vintage design with chevron patterns, positioned in an entryway. It has two tilt-out doors and a small top shelf.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the cabinet. Refer to the 'Specifications' section for weight limits.
- **Anti-Tipping Device:** This shoe cabinet must be securely attached to a wall using the provided anti-tipping device to prevent serious injury from tipping. Never allow children to climb on or play with the cabinet.



Image 2.1: Illustration of the anti-tipping design, showing a diagram of a cabinet tipping over a child and a close-up of the wall-mounting hardware for the anti-tipping strap.

3. Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Cabinet panels (top, bottom, sides, back)
- Tilt-out door panels (x2)
- Adjustable shelves (for interior compartments)
- Rubberwood feet (x4)
- Aluminum handles (x2)
- Assembly hardware (screws, dowels, cam locks, tilt-out mechanisms)
- Anti-tipping hardware (strap, wall anchors, screws)

- Assembly instructions (this manual)

4. Assembly Instructions

Assembly is required for this product. It is recommended to have two people for assembly. A Phillips head screwdriver and a hammer (not included) may be required.

1. **Attach Feet:** Secure the four rubberwood feet to the bottom panel of the cabinet using the provided screws. Ensure they are firmly attached.
2. **Assemble Cabinet Frame:** Connect the side panels to the bottom panel, then attach the back panel. Use the appropriate hardware (dowels, cam locks, screws) as indicated in the detailed diagram (refer to the included paper manual for specific diagrams).
3. **Install Tilt-Out Mechanisms:** Attach the tilt-out mechanisms to the interior side panels of the cabinet. Ensure they are oriented correctly for smooth operation of the doors.
4. **Attach Doors:** Connect the two tilt-out door panels to the installed mechanisms. Ensure the chevron pattern aligns correctly if applicable. Install the aluminum handles onto the front of each door.
5. **Insert Adjustable Shelves:** Each tilt-out compartment includes an adjustable shelf. Insert these shelves into the desired height slots within each door. This allows for flexible storage of different shoe sizes.
6. **Attach Top Panel:** Secure the top panel to the assembled cabinet frame.
7. **Install Anti-Tipping Device:** Position the cabinet in its desired location. Securely attach the anti-tipping strap to the back of the cabinet and then to a wall stud or using appropriate wall anchors. This step is crucial for safety.



Image 4.1: Close-up details of the shoe cabinet, highlighting the aluminum handles, the chevron pattern on the panels, and the sturdy rubberwood feet.

5. Operating Instructions

The HOMCOM Shoe Cabinet is designed for convenient shoe storage with its tilt-out door mechanism.

- **Opening Doors:** Gently pull the aluminum handle on each door outwards and downwards. The door will tilt open, revealing two storage levels.
- **Placing Shoes:** Arrange shoes on the two internal shelves within each compartment. The adjustable shelf allows for different shoe heights. The cabinet can accommodate approximately 12 pairs of shoes, depending on size and style.
- **Closing Doors:** Push the door upwards and inwards until it clicks securely into the closed position. Ensure both doors are fully closed to maintain a tidy appearance and prevent dust accumulation.



Image 5.1: The shoe cabinet with both tilt-out doors open, showcasing the internal storage compartments filled with various pairs of shoes.



Image 5.2: A detailed view of the shoe cabinet's interior with one door open, illustrating the two storage levels and indicating a capacity of up to 12 pairs of shoes.

6. Maintenance and Care

To keep your HOMCOM Shoe Cabinet in optimal condition, follow these care guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. Dry immediately with a clean cloth.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.

7. Troubleshooting

If you encounter any issues with your shoe cabinet, refer to the following common solutions:

- **Doors not closing properly:** Check if any shoes are obstructing the closing mechanism. Ensure the internal shelves are correctly seated. Verify that the tilt-out mechanisms are properly installed and not damaged.
- **Cabinet feels unstable:** Ensure all assembly screws are tightened. Confirm that the anti-tipping device is securely attached to both the cabinet and the wall. If on an uneven floor, consider using furniture levelers (not included).
- **Squeaking or stiff doors:** Apply a small amount of silicone lubricant to the moving parts of the tilt-out mechanism.
- **Scratches on surface:** For minor scratches, a wood repair marker or furniture polish matching the finish may help.

8. Specifications

Feature	Detail
Brand	HOMCOM
Model Number	FR837-299V00ND0531
Overall Dimensions (L x W x H)	70 cm x 30 cm x 120 cm (27.6" x 11.8" x 47.2")
Material	Engineered Wood (Particle Board, MDF)
Color	Natural
Total Weight Capacity	22 kg (48.5 lbs)
Top Shelf Weight Capacity	10 kg (22 lbs)
Each Drawer Weight Capacity	6 kg (13.2 lbs)
Shoe Capacity	Approx. 12 pairs
Features	2 Tilt-Out Doors, Adjustable Shelves, Anti-Tipping Device, Vintage Style, Chevron Pattern, Aluminum Handles, Rubberwood Feet



Image 8.1: Detailed dimensions diagram of the shoe cabinet, showing overall height (120 cm), width (70 cm), depth (30 cm), and internal measurements for the tilt-out compartments.

9. Warranty and Support

For warranty information, please refer to the purchase agreement or contact the retailer where the product was purchased. Information regarding spare parts availability is not provided in this manual. For further assistance or inquiries, please contact HOMCOM customer support through their official website or the retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BNW53CRD

More documents and user manuals: **https://manuals.plus/**