

FLEXISPOT EN2

FLEXISPOT EN2 Whole-Piece Standing Desk

INSTRUCTION MANUAL

Model: EN2 | Brand: FLEXISPOT

Introduction and Overview

The FLEXISPOT EN2 Whole-Piece Standing Desk is designed to provide a versatile and ergonomic workspace, allowing seamless transitions between sitting and standing positions. This electric height-adjustable desk features a durable, single-piece desktop, integrated power outlets, and intuitive controls for enhanced productivity and comfort in any office or home environment.



Image: The FLEXISPOT EN2 Standing Desk, showcasing its spacious rustic brown desktop, black frame, and integrated power strip, set up with dual monitors and various office accessories.

Key Features

- **Removable Desktop Power Outlet:** Equipped with 3 AC power outlets and 2 USB charging ports for convenient device charging. Can be clipped to the back or side of the desk.
- **Ample Whole-Piece Desktop:** A 1" eco-friendly desktop (55" x 28") provides generous space for computer setups, documents, and accessories.
- **4 Memory Buttons:** A 6-button digital controller with 4 programmable memory presets allows easy switching between sitting and standing heights (28.1" to 45.7").
- **Durable Construction:** Industrial-grade steel frame and solid tabletop support up to 176 pounds, rigorously tested for performance and safety.
- **Quiet Operation:** The motorized height-adjustable system operates smoothly and quietly at less than 50 dB.
- **Cable Management:** Includes devices to help tidy up your workspace and manage cables effectively.

UP TO 30% STABLER

Durable, Spacious Single-Piece Desktop



Smooth, Single-Piece
Desktop



Uneven Two-Piece
Desktop

Image: Detail of the removable desktop power outlet, highlighting its 3 AC outlets and 2 USB charging ports for easy access.



Image: The 6-button digital controller with a clear display, showing the current height and four programmable memory presets for quick adjustments.

Package Contents

Your FLEXISPOT EN2 Standing Desk will arrive in two separate packages, which may be shipped independently. Please ensure you have received both packages before beginning assembly.

- Desktop (55" Rustic Brown)
- Desk Frame (Black)
- Digital Controller
- Removable Desktop Power Outlet (3 AC, 2 USB)
- Cable Management Devices
- Assembly Hardware and Tools (Note: Electric drill not included, but may be required for some steps.)



Image: Illustration showing the two separate packages for the FlexiSpot desk: one for the desktop and one for the desk frame.

Safety Information


Please read all instructions carefully before assembly and use. Keep children and pets away from the desk during operation. Ensure all cables are properly managed to prevent tripping hazards and interference with the desk's movement. Do not overload the desk beyond its maximum weight capacity of 176 pounds. Assembly may require an electric drill, which is not included. Always ensure the desk is level and stable before placing heavy items on it.

Setup and Assembly

Assembly is straightforward, but it is recommended to have two people for easier installation. An electric drill may be helpful for certain steps, particularly for securing the controller and horizontal support bar.

1. **Unpack Components:** Carefully remove all parts from both packages and lay them out on a clean, soft surface to prevent scratches. Verify all components are present against the packing list.
2. **Assemble Desk Frame:** Follow the detailed instructions provided in the included manual to assemble the desk frame. Pay close attention to the crossbar adjustment; ensure screws are loose enough to extend the crossbar to its full length before tightening in a later step.
3. **Attach Desktop:** Carefully place the desktop upside down on a soft surface. Align the assembled desk frame with the pre-drilled holes on the desktop. Secure the frame to the desktop using the provided screws.
4. **Install Controller:** The controller can be mounted on either the left or right side of the desk. While pre-drilled holes may exist, you might need to drill pilot holes for optimal security, especially for the controller and additional horizontal support bar areas.
5. **Install Power Outlet and Cable Management:** Attach the removable power outlet to your desired location (back or side of the desktop) using its clamp mechanism. Utilize the included cable management devices to route and secure all power and device cables, ensuring they do not interfere with the desk's movement.
6. **Flip and Level Desk:** With assistance, carefully flip the assembled desk upright. Adjust the leveling feet at the bottom of the desk legs to ensure the desk is stable and level on your floor.


DIMENSIONS



Table

Size: 55"-28"

Can Hold Two 27" Monitor And One Laptop And More




Leg

Adjustable Height
28.1"-45.7"

Can Support Your Daily Work

Power Strip

Up To 1.7" Desk Edge



Cable Manager

Size: 15.75"-7.09"-4.72"



Image: A visual comparison demonstrating effective cable management, transforming a cluttered setup into a neat and organized workspace.

The FLEXISPOT EN2 desk features an intuitive digital controller for easy height adjustments and memory presets.

- **Adjusting Height:** Use the ▲ (up) and ▼ (down) arrow buttons on the digital controller to manually adjust the desk height. The current height will be displayed on the LED screen.
- **Setting Memory Presets:** The controller has four programmable memory buttons (1, 2, 3, 4). To set a preset:
 - a. Adjust the desk to your desired height.
 - b. Press and hold one of the memory buttons (1-4) until the display flashes or beeps, indicating the height has been saved.
- **Using Memory Presets:** Simply press the corresponding memory button (1-4) to automatically move the desk to your saved sitting or standing position. The desk will move smoothly and quietly.
- **Using the Power Outlet:** Plug your electronic devices into the 3 AC outlets or use the 2 USB charging ports on the removable power strip for convenient charging directly from your desk.

Your browser does not support the video tag.

Video: An official FLEXISPOT video demonstrating the features and operation of the standing desk, including height adjustment and integrated power solutions.

Maintenance

To ensure the longevity and optimal performance of your FLEXISPOT EN2 Standing Desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desktop surface regularly with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. For stubborn marks, a mild soap solution can be used.
- **Check Connections:** Periodically inspect all electrical connections and cables to ensure they are secure and free from damage. Ensure cables are not pinched or tangled, especially during height adjustments.
- **Lubrication:** The motorized components are generally maintenance-free. Do not attempt to lubricate internal mechanisms unless specifically instructed by FLEXISPOT support.

Troubleshooting

If you encounter any issues with your FLEXISPOT EN2 Standing Desk, refer to the common troubleshooting tips below:

Problem	Possible Cause / Solution
Desk does not move / No power.	Check if the power cord is securely plugged into both the desk and a working wall outlet. Ensure the power outlet is switched on.

Problem	Possible Cause / Solution
Desk is wobbly or unstable.	Ensure all assembly screws are tightened. Adjust the leveling feet at the bottom of the desk legs to compensate for uneven flooring. Avoid placing excessive weight on one side of the desk.
Motor makes unusual noise.	A slight hum is normal. If the noise is loud or unusual, check for any obstructions under the desk or contact customer support.
Height adjustment is not smooth.	Ensure the desk is not overloaded. Check for any obstructions that might be hindering movement.

If the above steps do not resolve the problem, please contact FLEXISPOT customer support for further assistance.

Specifications

Attribute	Detail
Brand	FLEXISPOT
Model	EN2
Desktop Dimensions	55"W x 28"D x 1"H
Color	Black Frame + Rustic Brown Desktop
Height Adjustment Range	28.1" to 45.7"
Weight Capacity	Up to 176 lbs
Noise Level	Less than 50 dB
Power Outlet	3 AC Outlets (125V/12A), 2 USB Charging Ports (5V/2A)
Assembly Required	Yes (Recommended 2 people)
Material	Alloy Steel Frame, Wood Desktop







Warranty and Support

FLEXISPOT stands behind the quality of its products. Your EN2 Standing Desk comes with the following warranty coverage:

- **5-Year Warranty:** Applies to frames, motors, and other mechanical devices.
- **2-Year Warranty:** Applies to controllers, switches, and electronics.

For any questions, technical support, or warranty claims, please contact FLEXISPOT Customer Support. You can find contact information on the official FLEXISPOT website or through your purchase platform.

Related Documents - EN2

	<p>FlexiSpot E2Q Electric Standing Desk: Installation Guide and Specifications</p> <p>Comprehensive installation guide and specifications for the FlexiSpot E2Q electric standing desk. Learn how to assemble, operate, and troubleshoot your adjustable height desk.</p>
	<p>FlexiSpot EH1-EU Electric Standing Desk Frame User Manual</p> <p>Comprehensive user manual for the FlexiSpot EH1-EU electric standing desk frame, detailing specifications, assembly instructions, wiring, operation, and troubleshooting for optimal use.</p>
	<p>FlexiSpot E7QB 4-Leg Standing Desk Frame User Manual and Warranty</p> <p>Comprehensive user manual for the FlexiSpot E7QB 4-Leg Standing Desk Frame, covering installation, usage, troubleshooting, and warranty information. Learn how to assemble, operate, and maintain your adjustable desk.</p>
	<p>FlexiSpot EG8B/EG8W Installation Guide and Limited Warranty</p> <p>This document provides a comprehensive installation guide and limited warranty information for the FlexiSpot EG8B/EG8W adjustable standing desk. It details specifications, assembly steps, keypad operation, troubleshooting, safety precautions, and warranty terms.</p>
	<p>FlexiSpot EC1 Electric Height Adjustable Standing Desk Assembly Guide</p> <p>This assembly guide provides step-by-step instructions for setting up the FlexiSpot EC1 electric height-adjustable standing desk. It includes specifications, parts list, assembly procedures, keypad operation, troubleshooting tips, and warranty information.</p>
	<p>FlexiSpot E2LB-V2/E2LW-V2 Electric Height-Adjustable Desk User Manual</p> <p>User manual for the FlexiSpot E2LB-V2 and E2LW-V2 electric height-adjustable desks, covering assembly, operation, technical specifications, and troubleshooting.</p>