

Kichler 330243SBK

Kichler Lucian II 60-inch Ceiling Fan Instruction Manual

Model: 330243SBK

1. PRODUCT OVERVIEW

The Kichler Lucian II 60-inch Ceiling Fan is designed for indoor use, offering both functionality and a modern aesthetic. This fan features a satin black finish and reversible blades, providing versatile style options for various interior designs.



Figure 1: Kichler Lucian II 60-inch Ceiling Fan, showcasing its satin black finish and five blades.

Key features include an AC motor for easy installation and control compatibility, and a pull chain for adjusting airflow and speed settings. The fan is UL Listed, ensuring compliance with safety standards.

2. SAFETY INFORMATION

Before beginning installation or operation, please read and understand all safety instructions. Always ensure the power supply is disconnected at the circuit breaker before working on the fan. Consult local electrical codes and regulations. It is recommended to have a qualified electrician perform the installation if you are not experienced with electrical wiring.

Important: Please check your local laws before purchasing or installing this product.

3. SETUP AND INSTALLATION

The Kichler Lucian II ceiling fan is designed for ceiling mount installation and includes all necessary hardware. An included downrod facilitates proper mounting. Ensure the mounting location can support the fan's weight (approximately 27.2 pounds).

3.1 Unpacking

- Carefully remove all components from the packaging.
- Verify that all parts listed in the packing list are present and undamaged.
- Keep packaging materials until installation is complete to prevent loss of small parts.

3.2 Mounting the Fan

1. Turn off power at the circuit breaker.
2. Attach the mounting bracket to the ceiling junction box, ensuring it is securely fastened and capable of supporting the fan's weight.
3. Assemble the downrod and canopy according to the detailed instructions provided in the separate installation guide.
4. Carefully lift the fan motor assembly and hang it from the mounting bracket.

3.3 Wiring Connections

- Connect the fan's electrical wires to the household wiring as per the wiring diagram in the installation guide.
- Ensure all connections are secure and properly insulated.
- The AC motor fan is designed for straightforward electrical connection.

3.4 Attaching Blades

The fan includes five blades. These blades are reversible, offering a choice between a silver or black finish to match your decor. Attach the blades to the motor housing using the provided screws, ensuring they are firmly secured.



Figure 2: The Kichler Lucian II fan blades, illustrating the reversible design with different finishes.

4. OPERATING INSTRUCTIONS

Once installed, the Kichler Lucian II fan is operated using its integrated pull chain mechanism. This fan offers three distinct power levels for air circulation.

4.1 Fan Speed Control

- Pull the chain once to turn the fan on at the highest speed.

- Pull the chain a second time to switch to medium speed.
- Pull the chain a third time to switch to low speed.
- Pull the chain a fourth time to turn the fan off.

The AC motor fan is compatible with various optional accessories for control, such as wall switches or remote controls, which may be purchased separately. Refer to the accessory's specific instructions for pairing and operation.

5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your ceiling fan.

5.1 Cleaning

- **Always turn off the power supply at the circuit breaker before cleaning.**
- Use a soft, damp cloth to clean the fan blades and motor housing.
- Avoid using abrasive cleaners or solvents, as these can damage the finish.
- Periodically wipe down the pull chain and any accessible parts.

5.2 Annual Inspection

- Check all screws on the motor housing and blade attachments for tightness. Tighten any loose screws.
- Ensure the downrod and canopy are securely fastened.
- Inspect wiring connections for any signs of wear or damage.

6. TROUBLESHOOTING

If you experience issues with your Kichler Lucian II ceiling fan, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wiring connections; faulty pull chain.	Check circuit breaker and wall switch. Ensure all wiring connections are secure. Test the pull chain mechanism.
Fan makes noise	Loose screws on blades or motor housing; unbalanced blades; motor issues.	Tighten all screws. Ensure blades are balanced (a balancing kit may be required). If noise persists, contact customer support.
Excessive wobbling	Loose blade screws; unbalanced blades; improper mounting.	Verify all blade screws are tight. Use a balancing kit to correct unbalanced blades. Ensure the mounting bracket is securely installed.
Airflow is weak	Fan running on low speed; incorrect blade pitch; obstruction.	Adjust fan speed using the pull chain. Ensure blades are installed with the correct pitch. Check for any obstructions around the fan.

If the problem persists after attempting these solutions, please contact Kichler customer support.

7. SPECIFICATIONS

Brand	Kichler
Model Name	Lucian II Fan

Model Number	330243SBK
UPC	783927600859
Color	Satin Black
Product Dimensions	60"D x 60"W x 14.25"H
Item Weight	27.2 pounds
Power Source	AC
Wattage	84 watts
Voltage	120 Volts
Air Flow Capacity	5190 Cubic Feet Per Minute
Efficiency	61.79 CFM per watt
Number of Blades	5
Blade Length	25.48 Inches
Control Method	Pull Chain (Touch compatible with optional accessories)
Number of Power Levels	3
Indoor/Outdoor Usage	Indoor
Installation Type	Ceiling Mount
Specification Met	UL Listed

8. WARRANTY INFORMATION

This Kichler Lucian II 60-inch Ceiling Fan comes with a **1 Year Manufacturer Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty documentation included with your product or visit the official Kichler website.




9. CUSTOMER SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please contact Kichler customer service. You can find contact information on the official Kichler website or in the product packaging. Visit the [Kichler Store on Amazon](#) for more products and information.



Related Documents - 330243SBK

	<u>KICHLER 52"/60" LUCIAN™ LED Ceiling Fan Instruction Manual</u> Comprehensive instruction manual for KICHLER's 52-inch and 60-inch LUCIAN™ LED ceiling fans. Covers installation, safety guidelines, electrical connections, operation, and troubleshooting.
--	---

 <p>KICHLER 52" DAWN LED INSTRUCTION MANUAL MODEL# 300319</p>	<p>Kichler 52" Dawn LED Ceiling Fan Instruction Manual - Model 300319</p> <p>Comprehensive instruction manual for the Kichler 52" Dawn LED Ceiling Fan, Model#: 300319, covering safety, installation, operation, and troubleshooting.</p>
 <p>KICHLER 60" / 80" MYLO WEATHER+ INSTRUCTION MANUAL MODEL# 310660, 310680</p>	<p>Kichler 60" / 80" Mylo Weather+ Ceiling Fan Instruction Manual</p> <p>Detailed instruction manual for the Kichler 60" and 80" Mylo Weather+ ceiling fan, covering installation, safety guidelines, electrical connections, operation, and troubleshooting. Includes model numbers 310660 and 310680.</p>
 <p>KICHLER 60"/65"/85" GENTRY CEILING FAN INSTRUCTION MANUAL MODEL# 300260XXX, 300265XXX, 300285XXX</p>	<p>Kichler 60"/65"/85" Gentry Ceiling Fan Instruction Manual</p> <p>Comprehensive instruction manual for the Kichler Gentry ceiling fan series (60", 65", 85"), detailing installation, operation, and safety guidelines for models 300260XXX, 300265XXX, and 300285XXX.</p>
 <p>KICHLER 60" HUMBLE INSTRUCTION MANUAL MODEL# 300415</p>	<p>Kichler 60" Humble Ceiling Fan Model 300415 Installation Manual</p> <p>Comprehensive instruction manual for the Kichler 60" Humble ceiling fan (Model 300415), covering installation, operation, safety guidelines, and troubleshooting. Learn how to properly install and use your Kichler fan.</p>
 <p>KICHLER 38200 SEMI-FLUSHMOUNT CEILING FIXTURE INSTRUCTION MANUAL MODEL# 38200</p> <p>ATTACH YOUR RECEIPT HERE Save Receipt Purchase Date Purchase Store Order Number Comments, Questions, Returns, and Technical Support: 800-332-8338, Monday - Friday, 8:00 a.m. - 5:00 p.m. Eastern Time KICHLER</p>	<p>Kichler 38200 Semi-Flushmount Ceiling Fixture Installation Manual</p> <p>Installation instructions, safety information, parts list, and troubleshooting guide for the Kichler 38200 Semi-Flushmount Ceiling Fixture. Includes step-by-step assembly guidance.</p>