

[Manuals.plus](#) /

› [AEG](#) /

› AEG BPS335061M Built-in Oven User Manual

AEG BPS335061M

AEG BPS335061M Built-in Oven User Manual

Model: BPS335061M (949 498 251)

INTRODUCTION

Welcome to the user manual for your new AEG BPS335061M Built-in Oven. This appliance is designed to provide exceptional cooking results with advanced features for convenience and efficiency. Please read this manual thoroughly before using your oven to ensure safe and optimal operation.



Front view of the AEG BPS335061M Built-in Oven, showcasing its sleek stainless steel design and control panel.

Key Features

- **SurroundCook Hot Air System:** Ensures uniform cooking results on up to three levels simultaneously.
- **Pyrolytic Self-Cleaning:** Converts dirt, grease, and food remains into odorless ash for easy wipe-off.
- **LED Touch Control Display:** Intuitive interface with sensitive touch sensors for precise settings.
- **Safe Touch Outer Door:** Special door glazing keeps the front temperature low, preventing burns.
- **MaxiKlasse Large Cooking Space:** A generous 72-liter capacity for versatile cooking.
- **Rapid Heat-up:** Preheating is significantly faster than conventional models.
- **Anti-Fingerprint Coating:** Special stainless steel coating reduces visible fingerprints.

Detailed Features

LED Touch Control Display

The oven features an advanced LED Touch Control Display with five sensitive touch sensors. Dimmable LEDs highlight individual setting values such as temperature and time during selection. A two-color temperature control shows the progress of the desired heating temperature, providing clear and precise feedback.



The intuitive LED Touch Display for clear operation and precise settings.

SurroundCook Hot Air System

The SurroundCook multifunction oven utilizes an advanced hot air system with a ring radiator to distribute heat evenly and efficiently throughout the cooking area. This ensures uniform cooking results on up to three levels, eliminating the need to worry about food placement.



Demonstration of the Hot Air System providing even heat distribution for consistent cooking results, as shown with a lasagna dish.

Safe Touch Outer Door

The oven is equipped with a special door glazing that ensures a low front temperature, significantly reducing the risk of burns. This feature provides enhanced safety during operation, especially in households with children.



Einschubhilfe

Einhängegitter und Backbleche lassen sich einfach einsetzen. Schnell und sicher.

Diagram illustrating the low surface temperature of the Safe Touch Outer Door, highlighting its safety feature.

Rapid Heat-up

The Rapid Heat-up function significantly reduces preheating time, making your cooking process more efficient. Preheating is up to 40% faster compared to conventional oven models, saving you valuable time in the kitchen.



Visual representation of the Rapid Heat-up feature, indicating faster preheating times.

MaxiKlasse Large Cooking Space

With an extra-large cooking compartment of 72 liters, the MaxiKlasse oven provides more space for perfect cooking results. This generous capacity allows for cooking larger dishes or multiple items simultaneously.



Leichtreinigungstür

Besonders einfache Reinigung der herausnehmbaren Glasscheibe.


The MaxiKlasse oven interior, demonstrating its spacious 72-liter capacity with a large food tray.

SETUP AND INSTALLATION

The AEG BPS335061M is a built-in oven designed for seamless integration into your kitchen cabinetry. Proper installation is crucial for the oven's performance and safety. It is highly recommended that installation be performed by a qualified professional.

Installation Requirements

- Ensure adequate ventilation around the appliance.
- Verify electrical supply meets the oven's voltage and wattage requirements (220 Volts, 3490 Watts).
- Refer to the detailed installation diagrams for precise cabinet dimensions and clearances.



Detailed diagram showing the dimensions and requirements for installing the AEG built-in oven into kitchen cabinetry.


Included Components: The oven comes with 1 x Combination Grille and 1 x Enamel Tray. Ensure these are present before installation.

OPERATING INSTRUCTIONS

Familiarize yourself with the control panel and various cooking functions to get the most out of your AEG oven.

Control Panel Overview

The oven's control panel features two rotary knobs for function and temperature selection, along with the central LED Touch Control Display for precise adjustments and feedback.



The AEG built-in oven integrated into a modern kitchen, showing its operational display.

Basic Operation

1. **Switching On:** Turn the function knob to select a cooking mode.
2. **Setting Temperature:** Use the temperature knob or the touch display to set the desired temperature (range: 30°C - 300°C).
3. **Setting Time:** Use the touch display to set cooking duration or timer functions.
4. **Selecting Cooking Functions:** Choose from various functions like Hot Air, Conventional Heat, Grill, etc., using the function knob.

Using the Insertion Aid

The oven is designed with an insertion aid system, making it easy to slide in and remove the combination grille and baking trays. This ensures quick and secure handling of hot dishes.



Schnellaufheizung

Spart Zeit. Das Vorheizen ist 40 % schneller als bei herkömmlichen Modellen.


Close-up view of the oven's interior, highlighting the convenient insertion aid for racks and trays.

CARE AND MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your AEG oven.


Pyrolytic Self-Cleaning

The pyrolytic self-cleaning function simplifies oven maintenance. At high temperatures, dirt, grease, and food remains are converted into odorless ash. Once the cleaning cycle is complete and the oven has cooled, the residue can be easily wiped away with a damp cloth.



STANDARD
BACKOFEN

HEISSLUFT MIT
RINGHEIZKÖRPER



Heißluftsystem

Gleichmäßige Wärmeverteilung im gesamten Garraum. Für beste Brat- und Backergebnisse.

A hand wiping away the ash residue after a pyrolytic self-cleaning cycle, demonstrating the ease of cleanup.

Easy Clean Door

The oven door features removable glass panes, making cleaning particularly easy. This design allows for thorough cleaning of all glass surfaces, ensuring clear visibility into the oven cavity.



Anti-Fingerprint

Weniger putzen dank spezieller
Edelstahl-Beschichtung. Macht Finger-
abdrücke nahezu unsichtbar.

The removable glass panes of the oven door, designed for easy and thorough cleaning.

Anti-Fingerprint Surface

The stainless steel exterior of the oven is treated with a special anti-fingerprint coating. This coating significantly reduces the visibility of fingerprints and smudges, requiring less frequent cleaning to maintain its pristine appearance.



A hand demonstrating the anti-fingerprint coating on the stainless steel surface, which minimizes visible smudges.

TROUBLESHOOTING


This section provides solutions to common issues you might encounter with your oven. For problems not listed here,

please contact customer support.

Problem	Possible Cause	Solution
Oven does not heat up	No power supply; Incorrect settings	Check power connection and circuit breaker; Verify cooking mode and temperature settings.
Uneven cooking results	Incorrect rack position; Overloaded oven	Use recommended rack positions for selected function; Avoid overcrowding the oven.
Pyrolysis not starting	Oven door not fully closed; Temperature too high	Ensure door is securely latched; Allow oven to cool if necessary before starting cycle.
Display not working	Power interruption; Faulty connection	Reset power by turning off and on at the circuit breaker; Contact service if issue persists.

TECHNICAL SPECIFICATIONS

Specification	Value
Brand	AEG
Model Number	BPS335061M (949 498 251)
Installation Type	Built-In
Capacity	72 Liters
Dimensions (H x W x D)	23.39 x 23.39 x 22.36 inches
Item Weight	66 pounds
Voltage	220 Volts
Wattage	3490 watts
Energy Efficiency Class	A+ (A+++ to D scale)
Annual Energy Consumption	0.93 kWh/year
Temperature Range	30°C - 300°C
Noise Level	10 dB
Material Type	Stainless Steel
Color	Stainless Steel With Anti-fingerprint
Oven Cooking Mode	Convection
Included Components	1 x Combination Grille, 1 x Enamel Tray



The official EU Energy Label for the AEG BPS335061M oven, indicating its A+ energy efficiency class and consumption details.

Produktdatenblatt	
Marke	AEG
Modell	BPS335061M 949498251
Energieeffizienzindex EEI - Hauptbackofen	81.2
Energieeffizienzklasse - Hauptbackofen	A+ (Spektrum A+++ bis D)
Energieverbrauch bei Standardbeladung pro Zyklus im konventionellen Modus (kWh/Zyklus) - Hauptbackofen	0.93
Energieverbrauch bei Standardbeladung pro Zyklus im Umluftmodus (kWh/Zyklus) - Hauptbackofen	0.69
Anzahl der Garräume	1
Wärmequelle	Elektro
Volumen (l) - Hauptbackofen	72

Product data sheet providing detailed technical specifications and energy consumption figures for the AEG BPS335061M oven.

Your AEG BPS335061M Built-in Oven comes with a manufacturer's warranty. Please refer to the warranty card included with your appliance for specific terms and conditions. For technical assistance, spare parts, or service requests, please contact AEG customer support through their official website or the contact information provided in your product documentation.

Always use genuine AEG spare parts to ensure the safety and performance of your appliance.