



Manuals.plus /

- › Bissell /
- › BISSELL® CrossWave® HydroSteam™ Wet Dry Vac User Manual

Bissell 35151

BISSELL® CrossWave® HydroSteam™ Wet Dry Vac User Manual

Model: 35151

INTRODUCTION

The BISSELL® CrossWave® HydroSteam™ Wet Dry Vac is designed to provide a comprehensive cleaning solution for various floor types. This innovative machine combines vacuuming, washing, and steaming functionalities to effectively tackle tough, sticky messes. Its HydroSteam™ Technology enhances cleaning performance, while the Two-Tank Technology ensures you always clean with fresh water and formula. The integrated self-cleaning cycle simplifies post-cleaning maintenance.

WHAT'S IN THE BOX



Image: The BISSELL CrossWave HydroSteam Wet Dry Vac shown with its included accessories: cleaning formulas, filter, and auto clean out tray.

- BISSELL® CrossWave® HydroSteam™ Wet Dry Vac Unit
- PET Multi-Surface Formula (8oz trial size)
- Hard Floor Sanitize Formula (8 oz trial size)
- FreshStart™ Clean Out Cycle Formula (8 oz trial size)
- Filter
- Auto Clean Out Tray with Accessory Holder



PET Multi-Surface Formula



Hard Floor Sanitize Formula



FreshStart™ Clean Out
Cycle Formula



Filter



Auto Clean Out Tray

SETUP

Before first use, ensure all components are present and the unit is properly assembled. The CrossWave HydroSteam requires some assembly.

1. **Handle Assembly:** Insert the handle into the main body of the unit until it clicks securely into place.
2. **Clean Water Tank:** Remove the clean water tank from the back of the unit. Fill the tank with warm tap water up to the indicated fill line. Add the appropriate BISSELL cleaning formula (e.g., PET Multi-Surface or Hard Floor Sanitize) up to its designated fill line. Replace the tank securely on the unit.
3. **Dirty Water Tank:** Ensure the dirty water tank is empty and properly seated before use.
4. **Power Cord:** Unwind the power cord and plug the unit into a grounded electrical outlet.

OPERATING INSTRUCTIONS

The BISSELL CrossWave HydroSteam offers versatile cleaning modes for different needs.

3-in-1 HydroSteam Cleaning



Vacuum, wash, & steam

Vacuum, wash, and steam wet and dry debris simultaneously.

Image: The CrossWave HydroSteam in action, demonstrating its ability to vacuum, wash, and steam simultaneously.

This mode allows you to vacuum, wash, and steam your floors simultaneously. It is particularly effective for tough, sticky messes and pet spills.

- Press the power button to turn on the unit.
- Select the desired cleaning mode (e.g., Hard Floor or Area Rug) using the mode selection button.
- Engage the steam function by pressing the steam button. Allow a few moments for the steam to generate.
- Hold the solution spray trigger to dispense water and formula as you move the unit forward and backward over the cleaning area.
- For best results on tough messes, make slow passes to allow the HydroSteam™ Technology to work effectively.

Multi-Surface Versatility



Image: The CrossWave HydroSteam effectively cleaning various surfaces including tile, area rugs, and sealed wood floors.

The CrossWave HydroSteam is designed to clean wet and dry messes on multiple sealed hard floor surfaces, including tile, sealed wood, and laminate. It can also refresh area rugs.

- Ensure you select the correct mode for your floor type.
- For area rugs, use the "Area Rug" mode and make slow, even passes. Do not oversaturate rugs.

Tangle-Free Brushroll



Minimize Hair Wrap

With an innovative Tangle-Free Brush Roll, picking up hair on your floors becomes hassle-free by reducing pesky hair wrap and tangles around the brush roll for an uninterrupted clean.

Image: The Tangle-Free Brushroll effectively picking up pet hair without tangling, ensuring continuous cleaning performance.

The specialized brushroll design minimizes hair wrap and tangles, making it ideal for homes with pets.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your CrossWave HydroSteam.

One-Touch Self-Cleaning Cycle

After each use, perform the self-cleaning cycle to clean the brushroll and internal components.

1. Place the unit on the Auto Clean Out Tray.
2. Ensure the dirty water tank is empty.
3. Fill the clean water tank with FreshStart™ Clean Out Cycle Formula and water as instructed in the quick start guide.

- Press the self-clean button. The cycle will run automatically, cleaning the brushroll and flushing the system.
- Once the cycle is complete, empty the dirty water tank and rinse it thoroughly.

Tank Maintenance



Image: Illustration of the distinctive two-tank system, highlighting the separate clean water and dirty water tanks.

- **Clean Water Tank:** Empty any remaining solution after each use. Rinse the tank with warm water.
- **Dirty Water Tank:** Always empty and rinse the dirty water tank after each use. The mesh divider helps separate solids for easier disposal.

Filter Cleaning

- Remove the filter from the dirty water tank.
- Rinse the filter under warm running water until clean.
- Allow the filter to air dry completely before reinserting it into the unit. Do not operate the unit with a wet filter.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No Power	Unit not plugged in; circuit breaker tripped.	Ensure power cord is securely plugged into a working outlet. Check household circuit breaker.
No Steam	Steam function not activated; insufficient water in clean tank.	Press the steam button. Ensure clean water tank is filled to the appropriate line. Allow time for heating.
Poor Cleaning Performance	Dirty water tank full; clogged filter; brushroll tangled.	Empty and rinse dirty water tank. Clean or replace filter. Check brushroll for debris and clean if necessary.
Leaking Water	Tanks not properly seated; damaged seals.	Ensure both clean and dirty water tanks are securely in place. Contact customer support if seals appear damaged.

SPECIFICATIONS

Feature	Detail
Brand	Bissell
Model Number	35151
Dimensions (D x W x H)	11.61"D x 13.78"W x 26.14"H
Item Weight	12.5 Pounds
Clean Water Tank Capacity	28 Fluid Ounces
Power Source	Corded Electric
Form Factor	Upright
Assembly Required	Yes

WARRANTY & SUPPORT

For warranty information and customer support, please refer to the official BISSELL website or contact their customer service directly.

- **Online Support:** Visit www.bissell.com for FAQs, troubleshooting guides, and product registration.
- **Customer Service:** Contact BISSELL customer service for assistance with product issues, parts, or warranty claims. Refer to your product packaging or the BISSELL website for current contact details.
- **Protection Plans:** Extended protection plans may be available for purchase. Refer to your retailer for details.