

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Razer](#) /

› [Razer Wireless Controller and Quick Charging Stand Bundle for Xbox Series X|S and Xbox One - Instruction Manual](#)

Razer RZ87-04720400-B3U1

Razer Wireless Controller and Quick Charging Stand Bundle

For Xbox Series X|S and Xbox One

Model: RZ87-04720400-B3U1

INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your Razer Wireless Controller and Quick Charging Stand Bundle. This product is designed for use with Xbox Series X|S, Xbox One, and compatible PC/Mac systems (requires Xbox Wireless Adapter, sold separately).

Key Features:

- **Wireless and Universal:** Compatible with Xbox Series X|S and all Xbox One models. Quick and easy pairing.
- **Impulse Analog Triggers:** Provides haptic feedback and pressure sensitivity for enhanced gameplay immersion.
- **Textured Grips:** Enhanced grip on triggers, bumpers, and back-case for comfortable handling.
- **Quick Charge:** Fully charges controllers in under 3 hours with built-in overcharge protection.
- **Magnetic Contact System:** Securely docks the controller for reliable charging.

PACKAGE CONTENTS

- Razer Wireless Controller (Green Edition)
- Razer Quick Charging Stand (Green Edition)
- Rechargeable Battery Pack
- USB Charging Cable
- Instruction Manual

SETUP

1. Installing the Battery Pack

1. Locate the battery compartment on the back of the Razer Wireless Controller.
2. Open the battery compartment cover.

3. Insert the rechargeable battery pack, ensuring correct polarity.
4. Replace the battery compartment cover.

2. Setting Up the Charging Stand

1. Place the Razer Quick Charging Stand on a stable, flat surface.
2. Connect the USB charging cable to the port on the back of the charging stand.
3. Connect the other end of the USB cable to a powered USB port (e.g., Xbox console, PC, or USB wall adapter).
4. The LED indicator on the stand will illuminate to confirm power.



Image: Razer Wireless Controller securely docked on its Quick Charging Stand, ready for charging.

3. Initial Charging

1. Gently place the Razer Wireless Controller onto the charging stand. The magnetic contact system will secure it.
2. Ensure the charging contacts on the controller align with those on the stand.
3. The LED indicator on the charging stand will change color (e.g., orange for charging, green for fully charged) to indicate charging status.

4. Allow the controller to fully charge before first use (approximately 3 hours).



Image: Top view of the Razer Quick Charging Stand, showing the charging contacts and LED indicator.

OPERATING THE CONTROLLER

1. Pairing with Xbox Console

1. Turn on your Xbox console.
2. Press and hold the Xbox button on your Razer Wireless Controller to turn it on.
3. Press the Pair button on your Xbox console (usually located near the USB ports).
4. Press and hold the Pair button on the top edge of your Razer Wireless Controller until the Xbox button starts flashing rapidly.
5. Once the Xbox button on the controller becomes solid, it is successfully paired.



Image: Front view of the Razer Wireless Controller, highlighting the Xbox button and other controls.

2. Pairing with PC/Mac

For PC/Mac gaming, an Xbox Wireless Adapter (sold separately) is required for wireless connectivity. Follow the adapter's instructions for pairing. Alternatively, you can connect the controller directly via a USB-C cable (not included).

3. Controller Functions

- **Impulse Triggers:** Experience tactile feedback during gameplay, such as weapon firing or impact.
- **Textured Grips:** Designed for enhanced comfort and control during extended gaming sessions.
- **Battery Life:** The rechargeable battery provides extended gameplay. Monitor battery status via your Xbox console or PC settings.



Image: Back view of the Razer Wireless Controller, showing the battery compartment and charging contacts.

MAINTENANCE

Cleaning

- Use a soft, dry cloth to clean the controller and charging stand.
- Avoid using abrasive cleaners, solvents, or harsh chemicals.
- Do not immerse the controller or charging stand in water or any other liquid.

Battery Care

- The charging stand features overcharge protection to prevent battery damage.
- For optimal battery life, avoid storing the controller in extremely hot or cold environments.
- If the controller will not be used for an extended period, it is recommended to fully charge it before storage.

TROUBLESHOOTING

Controller Not Connecting

- Ensure the controller is charged.
- Verify that the console or PC is powered on.
- Repeat the pairing process as described in the 'Operating the Controller' section.
- If using with PC, ensure the Xbox Wireless Adapter is correctly installed and drivers are up to date.

Charging Issues

- Check that the USB cable is securely connected to both the charging stand and the power source.
- Ensure the controller is properly seated on the charging stand, with contacts aligned.
- Try a different USB port or power adapter.
- Clean the charging contacts on both the controller and the stand with a dry cloth to remove any debris.

Other Issues

If you encounter other issues not covered here, please visit the official Razer support website for further assistance.

SPECIFICATIONS

Feature	Detail
Model Number	RZ87-04720400-B3U1
Compatibility	Xbox Series X S, Xbox One, PC/Mac (with Xbox Wireless Adapter)
Connectivity	Wireless
Charging Time	Under 3 hours (full charge)
Product Dimensions	7.63 x 7.63 x 3.75 inches
Item Weight	2.34 pounds
Manufacturer	Razer

WARRANTY AND SUPPORT

Razer products are manufactured to high quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official Razer website. For technical support, driver downloads, and frequently asked questions, please visit the [Razer Support Page](#).

© 2025 Razer Inc. All rights reserved.

Razer is a registered trademark of Razer Inc. Xbox, Xbox Series X|S, and Xbox One are registered trademarks of Microsoft Corporation.

Related Documents - RZ87-04720400-B3U1

	<p><u>Razer BlackShark V3 for Xbox</u></p> <p>Razer BlackShark V3 for Xbox . , Xbox PC , 2.4GHz Bluetooth , Razer Synapse Razer Audio .</p>
	<p><u>Razer Quick Charging Stand for Xbox: User Manual</u></p> <p>Comprehensive user manual for the Razer Quick Charging Stand for Xbox, detailing setup, usage, and troubleshooting. Includes FCC statements and warranty information.</p>
	<p><u>Razer Universal Quick Charging Stand for Xbox: Master Guide</u></p> <p>Comprehensive master guide for the Razer Universal Quick Charging Stand for Xbox, covering setup, safety, maintenance, and warranty information for Xbox controllers.</p>
	<p><u>Razer Blackshark V3 for Xbox: Основное Руководство</u></p> <p>Полное руководство пользователя для гарнитуры Razer Blackshark V3 для Xbox, охватывающее настройку, использование, безопасность и юридическую информацию. Узнайте, как подключить и оптимизировать вашу игровую гарнитуру.</p>
	<p><u>Razer BlackShark V3 for Xbox User Manual</u></p> <p>Comprehensive user guide for the Razer BlackShark V3 for Xbox gaming headset, covering setup, features, software configuration with Razer Synapse, safety, and maintenance.</p>
<p>Date: 23 Oct 2020</p> <p>Product Manual for Gaming Headset Model: RZ04-0348</p>	<p><u>Razer RZ04-0348 Gaming Headset: Setup, Features, and Safety Guide</u></p> <p>Comprehensive user manual for the Razer RZ04-0348 Gaming Headset. Learn about setup, pairing with Xbox and PC, audio controls, microphone functions, safety guidelines, and warranty information.</p>