

Instiwitt K65

Instiwitt K65 Wireless Earbuds User Manual

Model: K65

1. INTRODUCTION

Welcome to the Instiwitt K65 Wireless Earbuds User Manual. This guide provides comprehensive instructions on how to set up, operate, maintain, and troubleshoot your new earbuds. Please read this manual carefully before using the product to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW

The Instiwitt K65 Wireless Earbuds are designed for comfortable and enjoyable audio experiences, especially for children, featuring a unique and playful charging case. They offer wireless connectivity and intuitive controls.

2.1 Components

- Instiwitt K65 Wireless Earbuds (Left and Right)
- Charging Case
- USB Charging Cable
- Multiple sizes of ear tips (S, M, L)



Figure 2.1: Instiwitt K65 Wireless Earbuds and Charging Case. The earbuds are white with light-up indicators, and the charging case is pink, shaped like a cartoon character's head.

Ergonomic Ear Gels



Three point fx to ensure earbuds do not fall out even when you are running, hiking or jogging.



Oval sound outlet is designed to same shape of ear canal to provide-comfortable wearing experience.

Figure 2.2: Ergonomic Ear Gels and Design. The earbuds feature a three-point fixation for secure fit during activity and an oval sound outlet for comfortable wear.



wireless function



Share function



Built-in microphone



Three size ear caps

Figure 2.3: Child wearing Instiwitt K65 Earbuds. The earbuds are designed to be comfortable and gentle for children's ears, offering noise reduction and adjustability.

Universal Compatibbility



Figure 2.4: Instiwitt K65 Earbuds in various scenarios. The earbuds are suitable for diverse activities such as travel, studying, and entertainment.





Figure 2.5: Fashionable Design and Comfort. The earbuds are lightweight (only 3.5g) and designed to fit children's ear canal size comfortably, providing deep bass audio.



The charging case of the mini cartoon is easyfits in pockets and small bags

Wide Compatible with Most Bluetooth Enhanced devices on iOS/Android/Windows System

Single & Dual Ear Switch Freely

Figure 2.6: Universal Compatibility. The InstiWitt K65 earbuds are compatible with various Bluetooth-enabled devices including iPhones, audio devices, iPads, laptops, and PCs.

Enjoy Your Sound Music Anytime,Anywhere



Figure 2.7: Hearing Protection Feature. The earbuds are designed with a volume limit to protect children's hearing, ensuring comfortable and safe listening levels.

3. SETUP

3.1 Initial Charging

Before first use, fully charge the earbuds and the charging case. Place both earbuds into the charging case. Connect the charging case to a USB power source using the provided charging cable. The indicator lights on the case will show charging status.

- A single charge provides approximately 4-5 hours of listening time.
- With the charging case, total listening time can exceed 32 hours.
- Approximately 2 hours of charging provides 36 hours of listening time.

Protect children's hearing



Comfortable to wear



volume limit



Figure 3.1: Instiwitt K65 Earbuds in Charging Case. The earbuds are placed inside the case for charging and storage. The case has indicator lights to show battery level.

**One charge.
Days of play.**

4-5 Hours **Over 32 Hours**

Single charge

With charging case

2 Hours

Charging=36 Hour Listening



You'll love what you hear

6mm Dynamic driver unit offers deep bass, firm midrange performance and crisp treble for any types of music.

Bluetooth 5.1



6mm Dynamic Driver Unit

built-in microphone.

Figure 3.2: Battery Life and Dynamic Driver Unit. Illustrates the extended battery life with the charging case and highlights the 6mm dynamic driver unit for deep bass and clear sound.

3.2 Pairing with a Device

1. Ensure the earbuds are fully charged.
2. Open the charging case. The earbuds will automatically enter pairing mode (indicator lights will flash).
3. On your device (smartphone, tablet, laptop), enable Bluetooth.
4. Search for "Instiwitt K65" or similar in the list of available Bluetooth devices.
5. Select "Instiwitt K65" to connect. Once connected, the earbud indicator lights will stop flashing.
6. If pairing fails, place the earbuds back into the case, close it, and repeat the steps.

4. OPERATING INSTRUCTIONS

The Instiwitt K65 earbuds feature smart touch controls for easy management of audio playback and calls.

Smart Touch Control



Figure 4.1: Smart Touch Control Guide. This image illustrates the touch gestures for various functions, though the earbuds shown are black, the controls apply to the K65 model.

4.1 Music Playback

- **Play/Pause:** Double-tap the touch area on either the Left (L) or Right (R) earbud.
- **Next Track:** Single-tap the touch area on the Right (R) earbud.
- **Previous Track:** Single-tap the touch area on the Left (L) earbud.
- **Volume Up:** Double-tap the touch area on the Right (R) earbud.
- **Volume Down:** Double-tap the touch area on the Left (L) earbud.

Note: The provided image indicates single tap for volume control. Please refer to the specific product behavior for accurate volume adjustment.

4.2 Call Management

- **Answer/Hang Up Call:** Double-tap the touch area on either the Left (L) or Right (R) earbud during an incoming call or to end an active call.
- **Reject Call:** Double-tap the touch area on either the Left (L) or Right (R) earbud during an incoming call.

4.3 Voice Assistant

- **Activate Voice Assistant (Siri, Google Assistant, etc.):** Triple-tap the touch area on the Left (L) earbud.

4.4 Single and Dual Earbud Use

The Instiwiit K65 earbuds support both single and dual earbud modes. You can use either the left or right earbud independently, or both together for a stereo experience.


CAN'T BE CHARGED

When the headset cannot be charged, please Clean the charging contacts with a lint-free cloth or toothpick



POOR SOUND QUALITY

①Choosing the right eartips, Can provide better bass and noise isolation.



②Clean eartips and mesh.



Figure 4.2: Single and Dual Earbud Use. This image illustrates the flexibility of using one or both earbuds, allowing for single or dual earbud operation.

5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Instiwitt K65 earbuds.

5.1 Cleaning

- Regularly clean the charging contacts on both the earbuds and inside the charging case using a dry, lint-free cloth or a toothpick. This prevents charging issues.
- Clean the ear tips and the mesh covers of the earbuds to prevent wax buildup, which can affect sound quality. Remove the ear tips and gently wipe them. Use a soft, dry brush or cotton swab for the mesh.


CAN'T BE CHARGED

When the headset cannot be charged, please Clean the charging contacts with a lint-free cloth or toothpick



POOR SOUND QUALITY

①Choosing the right eartips, Can provide better bass and noise isolation.



②Clean eartips and mesh.



Figure 5.1: Cleaning Charging Contacts and Ear Tips. Demonstrates how to clean the charging contacts to resolve charging issues and how to clean ear tips and mesh for optimal sound quality.

5.2 Storage

- Always store the earbuds in their charging case when not in use to protect them and keep them charged.
- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your Instiwitt K65 earbuds, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Earbuds not charging	Dirty charging contacts; improper placement in case; faulty cable/charger.	Clean charging contacts on earbuds and case. Ensure earbuds are correctly seated. Try a different USB cable and power adapter.
Cannot pair with device	Earbuds not in pairing mode; Bluetooth off on device; previously paired device interfering.	Ensure earbuds are in pairing mode (open case). Turn Bluetooth off/on on your device. Forget "Instiwitt K65" from your device's Bluetooth list and re-pair. Ensure earbuds are charged.
No sound or poor sound quality	Low battery; ear tips clogged; incorrect ear tip size; device volume too low.	Charge earbuds. Clean ear tips and mesh. Try different sized ear tips for a better seal. Increase device volume.

Problem	Possible Cause	Solution
Earbuds disconnect frequently	Out of Bluetooth range; interference; low battery.	Stay within 10 meters (33 feet) of your device. Avoid strong electromagnetic interference. Ensure earbuds are charged.

7. SPECIFICATIONS

Feature	Specification
Brand	Instiwitt
Model Name	K65
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.1
Form Factor	In-Ear
Item Weight	15 Grams
Battery Type	Lithium-polymer (3 batteries required)
Special Features	Fast charging, Volume limit for hearing protection, Built-in microphone
Recommended Uses	Calling, Running, Video Gaming, Cycling, Exercise, Motorcycling, DJ, Skateboarding, Snowboarding
Age Range (Description)	Child
Included Components	Wireless charging case

8. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Instiwitt customer service through the retailer where you purchased the product or visit the official Instiwitt website. Please retain your proof of purchase for warranty claims.