

GENGQIANSI A520221125B09

GENGQIANSI Replacement Remote Control for Altra Flame Electric Fireplace Heater (Models FA30V60L Series) User Manual

Model: A520221125B09

INTRODUCTION

This manual provides comprehensive instructions for the GENGQIANSI replacement remote control, designed for use with Altra Flame and AltraFlame electric fireplace heaters. Please read this manual thoroughly before operating the remote control to ensure proper function and safety. This remote is compatible with models including FA30V60L, FA30V60L-1, FA30V60L-2, FA30V60L-3, FA30V60L-4, FA30V60L-5, FA30V60L-6, FA30V60L-7, FA30V60L-8, and FA30V60L-9.

PRODUCT OVERVIEW

The GENGQIANSI replacement remote control offers a convenient way to operate your Altra Flame electric fireplace heater. It features essential functions for power, flame effects, heat settings, timer, and temperature/fan control. Before use, verify that your fireplace model is listed as compatible or that your original remote matches the appearance of this replacement.





Figure 1: Front view of the remote control with button layout.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) AAA 1.5V batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Battery type:

AAA 1.5V



Figure 2: Remote control with open battery compartment, showing AAA 1.5V battery requirement.







Figure 3: Remote control with closed battery compartment.

OPERATING INSTRUCTIONS

Point the remote control directly at the electric fireplace heater's receiver. Ensure there are no obstructions between the remote and the fireplace.

- **Power Button ():** Press to turn the fireplace ON or OFF.
- **Flame Button ():** Adjusts the flame brightness or effect settings. Multiple presses may cycle through different flame options.
- **Heat Button (🔥):** Activates or deactivates the heating function. May also cycle through heat levels (e.g., low, high).
- **Timer Button ():** Sets a timer for automatic shutdown of the fireplace. Press repeatedly to cycle through available timer durations.
- **Temperature/Fan Control Buttons (⬆️⬆️):** Adjusts the desired temperature setting or fan speed. Use the up and down arrows to increase or decrease the setting.

MAINTENANCE

Battery Replacement

Replace batteries when the remote control's range decreases or if it stops responding. Always replace both batteries simultaneously with new AAA 1.5V batteries. Do not mix old and new batteries or different battery types.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners, solvents, or wet cloths, as these can damage the remote's surface or internal components.

TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly and are not depleted. Replace if necessary.
 - Ensure there is a clear line of sight between the remote and the fireplace's receiver. Remove any obstructions.
 - Confirm that the remote is compatible with your specific Altra Flame fireplace model. Refer to the 'Product Overview' section.
- **Limited range:**
 - Replace the batteries.
 - Ensure no strong light sources (like direct sunlight) are interfering with the infrared signal.

SPECIFICATIONS

Brand	GENGQIANSI
-------	------------

Model Number	A520221125B09
Compatible Devices	Altra Flame Electric Fireplace Heater (FA30V60L series)
Connectivity Technology	Infrared
Controller Type	Button Control
Color	Black
Power Source	2 x AAA 1.5V Batteries (not included)

WARRANTY INFORMATION

This product comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accidents, unauthorized modifications, or improper battery installation. For warranty claims or service, please contact the seller directly with your purchase details.

SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please refer to your product's purchase platform for seller contact information. Provide your product model number (A520221125B09) and a detailed description of the issue for efficient support.

© 2023 GENGQIANZI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question