

Aspiron AS-CA019

Aspiron Steam Cleaner AS-CA019 User Manual

Model: AS-CA019 | Brand: Aspiron

1. INTRODUCTION

Thank you for choosing the Aspiron Steam Cleaner AS-CA019. This powerful and versatile steam cleaner is designed to provide effective, chemical-free cleaning for a wide range of surfaces in your home and vehicle. By utilizing high-temperature, pressurized steam, it effortlessly removes dirt, grease, and grime, ensuring a hygienic environment. Please read this manual thoroughly before operating the appliance to ensure safe and optimal performance.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury.

- Always ensure the appliance is unplugged from the power outlet before filling, emptying, or cleaning.
- Do not leave the steam cleaner unattended while it is operating.
- Keep children and pets away from the appliance during operation.
- The steam produced is very hot. Avoid direct contact with skin or eyes. Use caution when handling the steam nozzle and accessories.
- Do not open the water tank cap while the appliance is pressurized or hot. Allow it to cool down and release pressure before refilling.
- Use only distilled or demineralized water to prevent mineral buildup and extend the life of the appliance.
- Do not immerse the appliance in water or other liquids.
- Regularly check the power cord for damage. If damaged, it must be replaced by the manufacturer or a qualified service agent.
- The appliance features an **Advanced Safety System** with indicators for steam pressure and water shortage. Pay attention to these indicators during use.

Hochentwickelte Sicherheit



Image: Control panel showing indicators for 4 Bar steam pressure (green) and water shortage (red).

3. PACKAGE CONTENTS

Carefully unpack your Aspiron Steam Cleaner and ensure all items are present. The package typically includes:

- Aspiron Steam Cleaner Main Unit
- Flexible Steam Hose
- Extension Wands (2)
- Floor Brush

- Carpet Glider
- Window Squeegee
- Jet Nozzle
- Small Round Brushes (various sizes/materials)
- Measuring Cup
- Funnel
- Microfiber Cloths/Pads
- Storage Bag
- User Manual



Image: The Aspiron Steam Cleaner main unit with its comprehensive set of 21 accessories, including various nozzles, brushes, and cleaning tools.

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your Aspiron Steam Cleaner:

- **Main Unit:** Houses the water tank, heating element, and control panel.
- **Water Tank:** 1.5 Liter capacity for extended cleaning sessions.
- **Steam Hose & Nozzle:** Delivers high-temperature, pressurized steam.
- **Accessories:** A variety of brushes, nozzles, and tools for different cleaning tasks.

Große Wasserkapazität

Bietet bis zu 50 Minuten Dampfreinigung
mit einer vollständigen Befüllung




50,7 oz / 1,5 L Kessel



Image: Internal view of the Aspiron Steam Cleaner showing its large 1.5 Liter water tank, providing up to 50 minutes of continuous steam cleaning.

Hochtemperatur- und Druckdampf

Erreichen Sie sturmartige
Reinigungskraft



145°C
Dampftemperatur



4 Bar
Dampfdruck



3 Kg/h
Dampfleistung

Image: Close-up of the steam cleaner's nozzle emitting powerful, high-temperature steam at 145°C and 4 Bar pressure, with a steam output of 3 Kg/h.

5. SETUP

1. **Place the Unit:** Position the steam cleaner on a flat, stable surface.
2. **Fill the Water Tank:** Unscrew the safety cap. Using the provided measuring cup and funnel, fill the water tank with up to 1.5 liters of distilled or demineralized water. Do not overfill. Securely replace the safety cap.
3. **Attach Accessories:** Connect the flexible steam hose to the main unit. Select the appropriate cleaning attachment (e.g., floor brush, jet nozzle) and securely attach it to the steam hose or extension wands.

4. **Plug In:** Plug the power cord into a grounded electrical outlet.

6. OPERATING INSTRUCTIONS

1. **Power On & Heat Up:** Turn on the steam cleaner. The indicator light will illuminate, signaling that the unit is heating. The appliance typically heats up in approximately 5 minutes.
2. **Steam Ready:** Once the steam is ready, the indicator light will change (refer to your unit's specific indicator behavior, often a green light or light turning off).
3. **Begin Cleaning:** Press the steam trigger on the handle to release steam. Direct the steam towards the surface you wish to clean. For stubborn dirt, hold the nozzle closer to the surface for a few seconds.
4. **Surface-Specific Cleaning:**
 - **Floors & Carpets:** Use the floor brush with extension wands. Attach the carpet glider for carpets.
 - **Grease & Grime:** Use the jet nozzle or a small round brush for concentrated cleaning on kitchen surfaces, ovens, or grout.
 - **Mirrors & Glass:** Attach the window squeegee for streak-free cleaning.
 - **Tiles & Grout:** Use a small brush attachment to scrub away dirt and mildew.
 - **Curtains & Upholstery:** Use the fabric tool or a soft brush attachment, keeping a slight distance to avoid oversaturation.
5. **Refilling:** If the water shortage indicator illuminates or steam output decreases significantly, turn off and unplug the unit. Allow it to cool and depressurize before carefully refilling the water tank.
6. **Finish Cleaning:** When done, turn off the appliance and unplug it from the power outlet.

Effektive Reinigung mit hoher Effizienz

145°C heißer, unter Druck stehender Dampf entfernt effektiv Fett und Schmutz



5 Minuten schnelle Erwärmung



Image: The Aspiron Steam Cleaner demonstrating high-efficiency cleaning on a floor, highlighting its 5-minute quick heating capability.

Breite Anwendung



Boden



Teppich



Fett und Schmutz



Spiegel & Glas



Fliesen



Vorhang

Image: A visual guide to the wide applications of the Aspiron Steam Cleaner, including cleaning floors, carpets, grease and grime, mirrors and glass, tiles, and curtains.

7. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your steam cleaner.

- **Empty Water Tank:** After each use, ensure the unit is cool and depressurized, then carefully empty any remaining water from the tank.
- **Clean Accessories:** Wash removable accessories with mild soap and water. Allow them to dry completely before storing.
- **Descaling (Periodically):** If you notice reduced steam output or mineral buildup, descale the unit.

Consult the full manual for detailed descaling instructions, typically involving a vinegar solution.

- **Storage:** Store the steam cleaner and its accessories in a cool, dry place. The included storage bag helps keep accessories organized.



Bequeme Aufbewahrung

Zubehör kann ordentlich in der mitgelieferten Aufbewahrungstasche verstaut werden

Image: Demonstrates convenient storage of the Aspiron Steam Cleaner and its accessories, which can be neatly organized in the provided storage bag.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No steam or low steam output	Water tank empty; Unit not heated; Mineral buildup.	Refill water tank; Allow 5 minutes for heating; Descale the unit.
Water leaking from nozzle	Unit not fully heated; Condensation; Accessory not properly attached.	Wait for full heating; This is normal at start-up; Reattach accessory securely.
Power indicator not on	Not plugged in; Power outlet issue; Unit off.	Check power connection; Test outlet; Turn unit on.

9. SPECIFICATIONS

Feature	Specification
Brand	Aspiron
Model Number	AS-CA019
Product Dimensions (L x W x H)	52.5 x 30 x 31 cm
Item Weight	5.62 kg
Water Tank Capacity	1.5 Liters
Power	1500 Watts
Voltage	120 Volts
Steam Temperature	Up to 145°C (293°F)
Steam Pressure	4 Bar
Heating Time	Approx. 5 minutes
Continuous Steam Time	Up to 50 minutes (per full tank)
Cable Length	16 Feet (approx. 4.88 meters)
Material	Glass, Nylon, Stainless Steel

10. WARRANTY & SUPPORT

Aspiron is committed to providing high-quality products and excellent customer service.

- **Extended Warranty:** Your product comes with a standard warranty, which can be extended by an additional 18 months (total 12+18 months) by activating your privilege service.
- **Money Back Guarantee:** Enjoy a 30-day money-back guarantee.
- **Customer Support:** For any inquiries or assistance, our customer support team is available 24 hours.
- **VIP Service:** Benefit from free replacement services under our VIP program.

To activate your warranty and access privilege services, please visit: <https://aspiron.co/warranty>

For direct support, please contact us at: support@aspiron.co

