

[Manuals.plus](#) /

› [Aigostar](#) /

› Aigostar 3-in-1 Evaporative Air Cooler User Manual

Aigostar B0BPCNP4B8

Aigostar 3-in-1 Evaporative Air Cooler User Manual

Model: B0BPCNP4B8

INTRODUCTION

Thank you for purchasing the Aigostar 3-in-1 Evaporative Air Cooler. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your appliance. Please read this manual thoroughly before use and retain it for future reference.

This versatile unit combines the functions of an air cooler, fan, and humidifier, designed to provide comfortable cooling and improved air quality for your home or office.

SAFETY INSTRUCTIONS

- Always place the unit on a stable, level surface.
- Do not use the unit near water or in excessively humid environments.
- Ensure the power supply matches the voltage specified on the rating label.
- Unplug the unit from the power outlet before cleaning, filling, or performing any maintenance.
- Keep children and pets away from the unit during operation.
- Do not block the air inlets or outlets.
- Do not insert objects into the unit's openings.
- Use only clean water in the water tank.
- Do not use without water when in cooling or humidifying mode.

PRODUCT COMPONENTS



Figure 1: Main unit with ice packs and water level indicator.

This image shows the complete evaporative air cooler unit in white, with two blue ice packs positioned next to it. The lower section of the unit clearly displays a water tank with a visible water level, indicating its capacity and function.

3-IN-1 Multiple Portable Air Cooler

Say goodbye to the summer heat



Figure 2: Product dimensions and 3-in-1 functionality.

This image illustrates the dimensions of the air cooler, showing its height (23.6 inches) and width (9.4 inches), along with its three primary functions: fan (without water), humidifier (with water), and air cooler (with water & ice packs).

3 Adjustable Wind Speeds

Customize your exclusive wind



Low Speed

Wind speed is soft and comfortable



Medium Speed

Medium wind speed, cool down



High Speed

strong wind speed, rapid cooling



Figure 3: Control panel with fan speed settings.

A close-up of the control panel on top of the unit, highlighting the buttons for fan speeds (1, 2, 3) and the OFF button, indicating adjustable airflow settings.



Figure 4: 360° Swivel Casters for easy mobility.

This image focuses on the base of the air cooler, showing the four 360-degree swivel casters, which enable easy movement of the unit across different surfaces.

SETUP

1. Unpacking and Placement

- Carefully remove the air cooler from its packaging.
- Ensure all packing materials are removed.
- Place the unit on a firm, level surface. The unit is pre-assembled with 360-degree castor wheels for easy movement.

2. Filling the Water Tank

- The unit features an upper and large visualized dual water tank (1.85 gallons capacity).
- Open the top lid of the unit.
- Pour clean water into the tank, ensuring the water level is between the "MIN" and "MAX" indicators on the side of

the unit. Do not overfill.

- For enhanced cooling, place the two included ice packs into the water tank. These ice packs help expel ice-cold air.
- Close the top lid securely.



Figure 5: Visualized 1.85 Gallon (7L) Water Tank.

This image highlights the large 7-liter (1.85 gallons) water tank capacity, emphasizing its ability to hold a significant amount of water for extended cooling and humidification.

OPERATING INSTRUCTIONS

1. Power On/Off

- Plug the power cord into a suitable electrical outlet.
- Press the **ON/OFF** button on the control panel to turn the unit on or off.

2. Adjusting Fan Speed

- The unit offers 3 fan speeds: Low, Medium, and High.
- Press the **1** button for Low speed.
- Press the **2** button for Medium speed.
- Press the **3** button for High speed.



3. Cooling and Humidifying Function

- To activate the cooling and humidifying function, ensure the water tank is filled.
- Press the **COLD** button. The unit will begin to circulate water and provide cooler, humidified air.
- The unit will automatically power off if the water tank runs out of water.

4. Oscillation Function

- Press the **OSC** button to activate the 70° wide oscillation feature, distributing cool air across a wider area.

- Press the **OSC** button again to stop oscillation.



Figure 7: 70° Widespread Cooling.

This image demonstrates the unit's 70-degree oscillation capability, showing how it distributes cool air across a wider area in a room, enhancing comfort.

5. Official Product Video

Your browser does not support the video tag.

Video 1: Aigostar 3-in-1 Evaporative Air Cooler - Smart.

This official product video from Aigostar US demonstrates the features and operation of the 3-in-1 evaporative air cooler, including its water tank, ice pack usage, fan speeds, and oscillation function.

MAINTENANCE

1. Cleaning the Water Tank

- Before cleaning, ensure the unit is unplugged from the power outlet.

- Drain any remaining water from the tank.
- Clean the water tank regularly with a soft cloth and mild detergent. Rinse thoroughly with clean water.
- Allow the tank to air dry completely before refilling or storing the unit.

2. Cleaning the Air Filter/Cooling Pad

- The air filter and cooling pad should be cleaned periodically to maintain optimal performance.
- Refer to the specific instructions in the full user manual (PDF link provided in the "Warranty and Support" section) for detailed steps on how to remove and clean these components.

3. Cleaning the Exterior

- Wipe the exterior of the unit with a soft, damp cloth.
- Do not use abrasive cleaners or solvents, as these may damage the surface.
- The manual fan blades can be adjusted to keep them clean easily.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply; Power button not pressed.	Check if the power cord is securely plugged in; Press the ON/OFF button.
No cool air/humidification.	Water tank empty; Cooling function not activated.	Fill the water tank; Press the COLD button.
Water leakage.	Water tank overfilled; Unit not on a level surface.	Do not overfill the tank; Ensure the unit is on a stable, level surface.
Weak airflow.	Air filter/cooling pad clogged; Fan speed too low.	Clean the air filter/cooling pad; Increase the fan speed.

If the problem persists after attempting the above solutions, please contact Aigostar customer support.

SPECIFICATIONS

Feature	Detail
Brand	Aigostar
Model	B0BPCNP4B8
Type	3-in-1 Evaporative Air Cooler (Cooling, Fan, Humidifier)
Power Consumption	80 watts
Water Tank Capacity	1.85 Gallons (approx. 7 Liters)
Fan Speeds	3 (Low, Medium, High)

Feature	Detail
Oscillation	70° Wide Oscillation
Coverage Area	Cools up to 370 Square Feet
Noise Level	Low sound operation (less than 60dB)
Included Accessories	2 Ice Boxes
Dimensions (approx.)	23"D x 23"W x 23"H
Item Weight	7.78 pounds

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Aigostar website or the full user manual provided with your product.

- **Official User Manual (PDF):** [Download PDF](#)
- **Aigostar Official Store:** [Visit Aigostar Store on Amazon](#)

If you encounter any issues not covered in this manual, please contact Aigostar customer service for assistance.

