

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [MoKo](#) /

> [MoKo Keyboard Case User Manual for iPad \(A16\) 11th Generation 2025 & iPad 10th Generation 10.9 inch 2022](#)

MoKo A2696/A2757/A2777

MoKo Keyboard Case User Manual

For iPad (A16) 11th Generation 2025 & iPad 10th Generation 10.9 inch 2022

1. INTRODUCTION

Thank you for choosing the MoKo Keyboard Case. This product is designed to enhance your iPad experience by providing a protective cover, a detachable Bluetooth keyboard, and multiple viewing angles. This manual will guide you through the setup, operation, and maintenance of your new keyboard case.



Image: The MoKo Keyboard Case in pink, featuring the detachable keyboard and the iPad securely placed in the case, set up for typing.

2. COMPATIBILITY

This MoKo Keyboard Case is specifically designed for the following iPad models:

- iPad 10th Generation 10.9-inch 2022 release (Models: A2696, A2757, A2777)
- New iPad (A16) 11-inch 2025 (Models: A3354, A3355, A3356)

It is **NOT** compatible with any other iPad models. Please verify your iPad model number before use.

ONLY COMPATIBLE WITH



New iPad (A16) 11 Inch 2025

(Model: A3354, A3355, A3356)

iPad 10 Generation 10.9 Inch 2022

(Model: A2696, A2757, A2777)

Image: A visual guide indicating the specific iPad models compatible with this keyboard case, including the 10th Generation 10.9-inch and the new 11-inch (A16) 2025 models.

3. FEATURES

- **Detachable Wireless Keyboard:** The keyboard attaches magnetically to the case, allowing for easy repositioning or removal. It features a QWERTY layout with practical shortcuts and is compatible with iOS, Windows, and Android systems.

STRONG

Magnetic Connection



Bluetooth Connection

10m/33ft effective distance



QWERTY English Keyboard

Image: An illustration demonstrating the strong magnetic connection between the iPad case and the detachable Bluetooth keyboard, highlighting the effective Bluetooth range of 10m/33ft.

- **Long Life Battery:** Equipped with a built-in rechargeable Li-polymer battery, the keyboard offers extended use. It features a hibernation mode for energy saving and can be fully charged in approximately 2 hours, providing over 100 hours of working time.

COMFORTABLE VIEWING ANGLES

Meet the needs of different perspectives,
ideal for working or watching videos




Image: A graphic illustrating the keyboard's Type-C fast charging, highlighting its 150mAh battery, 2-hour charging time, and over 100 hours of working time.

- **Pencil Holder & Multiple Angles:** The case includes a convenient built-in pencil slot for easy storage and retrieval of your stylus (pencil not included). Multiple horizontal slots allow you to adjust the iPad to various comfortable viewing angles for typing, watching, or drawing.

MOKO 👍

More Convenient
Pen Slot

Easy to remove with one hand



OTHERS 👎

Hard-to-Operate
Pen Slot

Need two hands for each
removing



Image: A comparison highlighting the MoKo case's convenient pen slot, designed for easy one-hand removal of the stylus, contrasted with other designs that require two hands.

TYPE-C

Fast Charging



150mAh Battery



2h Charging Time



100h+ Working Time



Image: The iPad case demonstrating two comfortable viewing angles (120° and 126°), ideal for various activities like working or watching videos.

- **Quality Materials & Precise Cutouts:** The case is made from PU leather, offering scratch-proof and fingerprint-proof protection. Precise cutouts ensure full access to all ports, support auto wake/sleep functionality, and Touch ID.



Image: Visuals demonstrating the case's splash-proof quality and its ease of cleaning, showing water droplets on the surface and a spill being wiped away.

4. SETUP

4.1 Charging the Keyboard

1. Locate the USB-C charging port on the keyboard.
2. Connect the provided USB charging cord to the keyboard and a suitable USB power adapter (not included).
3. The charging indicator light will illuminate. Once fully charged, the light will change or turn off.

4.2 Pairing the Keyboard with Your iPad

1. Ensure the keyboard is charged.
2. Turn on the keyboard by sliding the power switch to the 'ON' position.
3. Press the 'Connect' button on the keyboard (usually a small button near the power switch or a function key combination like Fn+C). The Bluetooth indicator light will start blinking.
4. On your iPad, go to **Settings > Bluetooth**.
5. Turn on Bluetooth. Your iPad will search for nearby devices.
6. Select 'MoKo Keyboard' or a similar name from the list of available devices.
7. If prompted, enter the pairing code displayed on your iPad using the keyboard and press Enter.
8. Once paired, the Bluetooth indicator light on the keyboard will stop blinking and remain solid or turn off, and your iPad will show the keyboard as 'Connected'.

5. OPERATING

5.1 Inserting Your iPad into the Case

1. Align your iPad with the protective shell of the case.
2. Gently press the iPad into the case, ensuring all corners are securely fitted.
3. The precise cutouts will allow access to all ports, buttons, and the camera.

5.2 Using the Stand Function

The case features multiple grooves or folds that allow you to prop up your iPad at various angles. Simply fold the cover to create a triangular stand and place the edge of your iPad into one of the grooves for your desired viewing or typing angle.

5.3 Keyboard Usage

Once paired, the keyboard functions like a standard external keyboard. You can use it for typing, navigating, and utilizing various shortcut keys. Refer to your iPad's operating system documentation for specific keyboard shortcuts.



Image: A user comfortably interacting with the MoKo keyboard case and iPad, illustrating the product's ergonomic design for daily use.

6. MAINTENANCE

- **Cleaning the Case:** Wipe the PU leather exterior with a soft, damp cloth. For spills, use a mild soap solution if necessary, then wipe dry. Avoid harsh chemicals or abrasive cleaners.
- **Cleaning the Keyboard:** Use a soft, dry cloth to clean the keyboard keys. For dust or debris between keys, use compressed air. Do not immerse the keyboard in water or any liquid.

- **Storage:** When not in use for extended periods, store the keyboard case in a cool, dry place. Ensure the keyboard is turned off to conserve battery life.

7. TROUBLESHOOTING

- **Keyboard not connecting via Bluetooth:**
 - Ensure the keyboard is charged and turned on.
 - Make sure Bluetooth is enabled on your iPad.
 - Press the 'Connect' button on the keyboard to enter pairing mode.
 - Forget the device on your iPad's Bluetooth settings and try pairing again.
 - Restart both your iPad and the keyboard.
- **Keys not responding:**
 - Check if the keyboard is properly connected to your iPad.
 - Ensure the keyboard battery is not low.
 - Try restarting the keyboard and iPad.
- **Auto wake/sleep function not working:**
 - Ensure your iPad is correctly seated in the case.
 - Check your iPad's settings for 'Lock/Unlock' or 'Cover Lock/Unlock' and ensure it is enabled.

8. SPECIFICATIONS

Feature	Detail
Brand	MoKo
Model Number	A2696/A2757/A2777 (for iPad 10th Gen)
Color	Watermelon Red (rouge pastèque)
Connectivity Technology	Bluetooth, USB (for charging)
Keyboard Description	Flexible, Detachable Bluetooth Keyboard
Number of Keys	78
Special Features	Detachable Bluetooth keyboard, Built-in pencil holder, Adjustable viewing angles
Battery Composition	Lithium-polymer
Product Dimensions	27.8L x 19.3W x 2H centimeters

9. WARRANTY AND SUPPORT

This product is covered by the standard return policy of the retailer, typically 30 days for refund/replacement. For specific warranty details and technical support, please refer to the manufacturer's official website or contact MoKo customer service directly. Information regarding software updates and spare parts availability is not provided at this time.

For further assistance, please visit the [seller's page](#) on Amazon or contact MoKo support.

