

Logitech MK670

Logitech MK670 Comfort Wave Wireless Keyboard & Mouse Combo and Mini Bluetooth Speaker User Manual

Model: MK670

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Logitech MK670 Comfort Wave Wireless Keyboard and Mouse Combo, along with the included Mini Bluetooth Speaker, Gel Wrist Pad, and Gel Mouse Pad. Please read this manual thoroughly before using the products to ensure optimal performance and longevity.



Image 1.1: Complete bundle including the Logitech MK670 keyboard, mouse, mini Bluetooth speaker, and gel pads.

2. PRODUCT COMPONENTS

Your package should contain the following items:

- Logitech MK670 Comfort Wave Wireless Keyboard
- Logitech Wireless Mouse
- Logitech Unifying USB Receiver
- Mini Portable Wireless Bluetooth Speaker
- Gel Wrist Pad
- Gel Mouse Pad
- Micro USB Charging Cable (for speaker)

- User Documentation (this manual)

3. SETUP INSTRUCTIONS

3.1. Logitech Keyboard and Mouse Setup

1. **Unpack:** Carefully remove the keyboard and mouse from their packaging.
2. **Insert Batteries:** The keyboard and mouse typically come with pre-installed batteries or require standard AA/AAA batteries. Open the battery compartments (usually on the underside of each device) and ensure batteries are correctly inserted.
3. **Locate Unifying Receiver:** The small USB Unifying receiver is often stored inside the mouse's battery compartment for safekeeping. Remove it.
4. **Connect Receiver:** Plug the Logitech Unifying USB receiver into an available USB port on your computer.
5. **Power On:** Turn on the keyboard and mouse using their respective power switches (usually located on the underside or side). The devices should automatically connect to your computer.



Image 3.1: The Logitech MK670 wireless keyboard and mouse, ready for connection via the Unifying receiver.

3.2. Mini Bluetooth Speaker Setup

1. **Charge Speaker:** Before first use, fully charge the mini Bluetooth speaker using the provided Micro USB charging cable. Connect the Micro USB end to the speaker and the USB-A end to a power source (e.g., computer USB port, USB wall adapter). The charging indicator light will typically turn off or change color when fully charged.

2. **Power On:** Press and hold the power button on the speaker until you hear an audible prompt or see an indicator light flash, indicating it is in pairing mode.
3. **Pair via Bluetooth:**
 - On your device (smartphone, tablet, laptop), go to Bluetooth settings.
 - Ensure Bluetooth is enabled.
 - Search for available devices. The speaker will typically appear as a name like "Mini Speaker" or similar.
 - Select the speaker to pair. Once paired, you will hear a confirmation sound.



Image 3.2: A close-up view of the compact mini Bluetooth speaker, highlighting its design.

3.3. Gel Pads Placement

1. **Keyboard Wrist Rest:** Place the longer gel wrist pad directly in front of your Logitech MK670 keyboard, aligning it to support your wrists while typing.
2. **Mouse Pad with Wrist Rest:** Position the gel mouse pad on your desk where you typically use your mouse. Ensure the integrated wrist rest provides comfortable support for your mousing hand.



Image 3.3: The ergonomic gel wrist pad and gel mouse pad, designed for comfort and support.

4. OPERATING INSTRUCTIONS

4.1. Keyboard Usage

- **Typing:** The Comfort Wave design provides an ergonomic layout for natural hand and wrist positioning.
- **Numeric Keypad:** Utilize the full-size numeric keypad for efficient data entry.
- **Shortcut Keys:** Access common functions quickly using the dedicated shortcut keys (e.g., media controls, volume, application launch). Refer to the key legends for specific functions.
- **Adjustable Tilt Legs:** Flip out the tilt legs on the underside of the keyboard to adjust the typing angle for personalized comfort.



Image 4.1: Side view of the Logitech MK670 keyboard, illustrating the adjustable tilt legs for ergonomic customization.

4.2. Mouse Usage

- **Pointing and Clicking:** Use the mouse for precise cursor control, left-clicks, and right-clicks.
- **Scrolling:** The scroll wheel allows for smooth navigation through documents and web pages.
- **Ambidextrous Design:** The mouse is designed for comfortable use by both left and right-handed users.



Image 4.2: A detailed view of the Logitech wireless mouse, showcasing its ergonomic shape.

4.3. Mini Bluetooth Speaker Usage

- **Power On/Off:** Press and hold the power button to turn the speaker on or off.
- **Bluetooth Pairing:** Once powered on, the speaker will automatically attempt to connect to the last paired device. If not, it will enter pairing mode for new connections (refer to Section 3.2).
- **Volume Control:** Volume is typically controlled via the connected device. Some speakers may have integrated volume buttons.
- **Selfie Remote:** The speaker may feature a remote selfie button. Consult the speaker's specific instructions for activation and use with your device's camera.
- **Hands-Free Calling:** With its built-in microphone, the speaker can be used for hands-free calls when connected to a smartphone.

5. MAINTENANCE

5.1. Cleaning

- **Keyboard and Mouse:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution. Avoid harsh chemicals or abrasive materials. For dust between keys, use compressed air.
- **Mini Bluetooth Speaker:** Wipe the exterior with a soft, dry cloth. Do not immerse in water.
- **Gel Pads:** Wipe with a damp cloth and mild soap if necessary. Allow to air dry completely before reuse.

5.2. Battery Replacement (Keyboard and Mouse)

When the battery indicator light on your keyboard or mouse signals low power, replace the batteries with new ones of the same type (e.g., AA or AAA). Ensure correct polarity when inserting new batteries.

6. TROUBLESHOOTING

6.1. Keyboard/Mouse Not Responding

- **Check Batteries:** Ensure batteries are correctly inserted and have sufficient charge. Replace if necessary.
- **Power Switches:** Verify that both the keyboard and mouse power switches are in the 'ON' position.
- **USB Receiver:** Ensure the Logitech Unifying USB receiver is securely plugged into a working USB port on your computer. Try a different USB port.
- **Proximity:** Ensure the keyboard and mouse are within the operational range (up to 33 feet) of the USB receiver.
- **Re-pair:** If issues persist, you may need to re-pair the devices using Logitech's Unifying software (downloadable from the Logitech support website).

6.2. Mini Bluetooth Speaker Connection Issues

- **Speaker Power:** Ensure the speaker is charged and powered on.
- **Bluetooth On:** Verify Bluetooth is enabled on your source device.
- **Forget Device:** On your source device, 'forget' or 'unpair' the speaker from your Bluetooth device list, then attempt to pair again.
- **Proximity:** Keep the speaker and source device within close range (typically 10 meters or 33 feet) for stable connection.
- **Interference:** Move away from other wireless devices that might cause interference.

6.3. No Sound from Speaker

- **Volume Levels:** Check the volume on both the speaker and the connected device.
- **Source Device Output:** Ensure your device's audio output is set to the Bluetooth speaker.
- **Media Playback:** Verify that media is playing on your source device.

7. SPECIFICATIONS

Feature	Detail
Brand	Logitech
Model	MK670 (Keyboard & Mouse Combo)
Connectivity Technology	2.4GHz Wireless (Keyboard & Mouse), Bluetooth 5.0 (Speaker)
Wireless Range	Up to 33 feet (10 meters)
Keyboard Features	Ergonomic Comfort Wave design, Full-size with numeric keypad, Shortcut keys, Cushioned palm rest, Adjustable tilt legs
Mouse Features	Ambidextrous design, Precise tracking

Feature	Detail
Speaker Dimensions	45.45 mm x 33 mm (1.75" x 1.3")
Speaker Weight	2.46 oz
Speaker Battery Capacity	400mAh
Speaker Playback Time	Up to 4 hours
Speaker Special Features	Magnetic base, Built-in mic, Remote selfie button, Glow in the Dark (Yellow variant)
Compatible Devices	Laptops, Gaming Consoles (for keyboard/mouse functionality), Bluetooth-enabled devices (for speaker)
Item Weight (Bundle)	4 pounds
Package Dimensions	23 x 10 x 10 inches

8. WARRANTY INFORMATION


Logitech products are typically covered by a limited hardware warranty. For specific warranty terms and conditions, including duration and coverage details, please refer to the warranty card included with your product or visit the official Logitech website. Keep your proof of purchase for warranty claims.






9. SUPPORT

For further assistance, technical support, or to download the latest drivers and software for your Logitech products, please visit the official Logitech support website. You can also find FAQs and community forums there.

Logitech Support Website: <https://support.logi.com/>

Related Documents - MK670

	<p>Logitech M535 Bluetooth Mouse: Features, Setup, and Compatibility Guide</p> <p>Discover the Logitech M535 Bluetooth Mouse. This guide covers its features, Bluetooth connection steps, customization with Logitech Options software, and compatibility with Windows, Mac OS, Chrome OS, and Android devices.</p>
---	---

 <p>Getting started with Premiere Edition Logitech® Wireless Wave Combo MK550</p> <p>unifying</p>	<p>Logitech Wireless Wave Combo MK550: Getting Started Guide</p> <p>Comprehensive guide to setting up and using the Logitech Wireless Wave Combo MK550. Learn about keyboard and mouse features, battery management, and troubleshooting for this ergonomic wireless set.</p>
	<p>Logitech Marathon Mouse M705: Getting Started Guide & Features</p> <p>Comprehensive guide to setting up and using the Logitech Marathon Mouse M705, including features, troubleshooting, and Unifying receiver setup.</p>
	<p>Logitech LIFT Vertical Ergonomic Mouse User Guide and Setup</p> <p>Comprehensive guide to setting up, connecting, and using the Logitech LIFT Vertical Ergonomic Mouse. Learn about its features like SmartWheel, Easy-Switch, and Logitech Flow.</p>
	<p>Logitech M337 Bluetooth Mouse: Features, Setup, and Compatibility Guide</p> <p>A comprehensive guide to the Logitech M337 Bluetooth Mouse, detailing its features, setup process, gesture controls, power management, and system compatibility for Windows, macOS, Chrome OS, and Android devices.</p>
	<p>Logitech MX Ergo S Setup Guide Ergonomic Trackball Mouse</p> <p>Set up and connect your Logitech MX Ergo S ergonomic trackball mouse. Discover features like adjustable angle, precision scroll wheel, easy-switch, and Logitech Flow technology for seamless multi-device productivity. Includes Bluetooth and Logi Bolt setup instructions.</p>