**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**TMEOSK WF294AAF**

# TMEOSK Full Modern Upholstered Platform Bed WF294AAF Instruction Manual

Model: WF294AAF

## Important Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference. Failure to follow these instructions may result in injury or damage to the product.

- Ensure all parts are present and undamaged before beginning assembly.
- Assemble the bed on a soft, clean surface (e.g., carpet) to prevent scratching.
- Do not use power tools for assembly as overtightening may damage fasteners or components.
- Periodically check all connections and fasteners to ensure they remain tight.
- This bed is designed for use with a mattress only; a box spring is not required.
- Do not exceed the recommended weight capacity of 500 lbs (Full size).
- Keep small parts away from children during assembly.

## Package Contents

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- Headboard (1)
- Side Rails (2)
- Footboard (1)
- Center Support Beam (1)
- Wooden Slats (Quantity varies, typically 10-14)
- Support Legs (4-6, including center legs)
- Hardware Pack (Bolts, washers, nuts, Allen wrench)





Figure 1: Exploded view of bed components with dimensions. This image illustrates the headboard, footboard, side rails, and slat system, along with overall measurements.

## Setup: Assembly Instructions

Follow these steps carefully to assemble your TMEOSK Platform Bed. It is recommended to have two people for assembly.

1. **Step 1: Attach Side Rails to Headboard.**

   Align the side rails (A) with the pre-drilled holes on the headboard (B). Secure them using the provided bolts and washers. Do not fully tighten yet.



Figure 2: Front view of the bed frame, illustrating the connection points for the headboard and side rails.

2. **Step 2: Attach Side Rails to Footboard.**

   Connect the other end of the side rails (A) to the footboard (C) using the remaining bolts and washers. Ensure all connections are snug, then fully tighten all bolts from Step 1 and Step 2.

3. **Step 3: Install Center Support Beam and Legs.**

   Attach the center support beam (D) to the designated brackets on the headboard and footboard. Screw in the adjustable support legs (E) to the center beam and any additional support points on the side rails.

4. **Step 4: Place Wooden Slats.**

   Lay the wooden slats (F) across the side rails, ensuring they are evenly spaced and secured to the frame if attachment points are present. Some slats may have Velcro or plastic caps for stability.



Figure 3: Angled view of the bed frame with wooden slats in place, demonstrating the slat support system.



Figure 4: Detailed view of the wooden slats and the central support structure, highlighting the robust design.

5. **Step 5: Final Check.**
   Confirm all bolts are securely tightened and the bed frame is stable before placing your mattress on it.

## Operating Instructions

Your TMEOSK Platform Bed is designed for straightforward use.

- **Mattress Placement:** Place your full-size mattress directly onto the wooden slats. A box spring is not required.
- **Weight Capacity:** The bed frame is designed to support a maximum weight of 500 lbs (including mattress and occupants). Do not exceed this limit.
- **Movement:** When moving the bed, lift it rather than dragging it to prevent damage to the frame or floor.

## Maintenance

Proper care will extend the life and appearance of your bed frame.

- **Cleaning Upholstery:** For general cleaning, gently vacuum the velvet headboard and frame with a soft brush attachment. For spills, blot immediately with a clean, dry cloth. For stubborn stains, a mild fabric cleaner designed for velvet can be used, testing on an inconspicuous area first.
- **Frame Cleaning:** Wipe wooden or metal parts with a damp cloth and mild soap if necessary. Dry immediately.
- **Fastener Check:** Periodically (every 3-6 months) check all bolts and screws to ensure they are tight. Retighten as needed to maintain stability and prevent squeaking.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight may cause the fabric color to fade.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Bed squeaks or wobbles. | Loose fasteners; uneven floor; damaged slat. | Tighten all bolts and screws. Ensure the bed is on a level surface. Inspect slats for damage and replace if necessary. |
| Parts do not align during assembly. | Incorrect orientation of parts; overtightened bolts. | Review the assembly steps and diagrams. Loosen previously tightened bolts to allow for adjustment, then retighten. |
| Missing hardware or components. | Packaging error. | Carefully check all packaging materials. Contact customer support with the specific part number or description. |

## Specifications

| Feature | Detail |
|---|---|
| **Brand** | TMEOSK |
| **Model Number** | WF294AAF |
| **Size** | Full |
| **Product Dimensions** | 79"L x 59"W x 43"H |
| **Color** | Gray |
| **Material** | Velvet Upholstery, Solid MDF, Particle Board, Wood Slats |
| **Weight Capacity** | 500 lbs |
| **Assembly Required** | Yes |
| **Item Weight** | 55 pounds |
| **UPC** | 768611060683 |

## Warranty and Support

For warranty information or assistance with your TMEOSK product, please refer to the warranty card included in your package or contact TMEOSK customer service directly. Please have your model number (WF294AAF) and purchase date available when contacting support.
Contact information for TMEOSK customer service can typically be found on the product packaging or the official TMEOSK website.

© 2023 TMEOSK. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0BPGRZ7LK**

More documents and user manuals: **https://manuals.plus/**