

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Mont Alpi](#) /

› [Mont Alpi MAi400-DBEV 4-Burner Deluxe Outdoor Kitchen Island Instruction Manual](#)

Mont Alpi MAi400-DBEV

Mont Alpi MAi400-DBEV 4-Burner Deluxe Outdoor Kitchen Island Instruction Manual

INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Mont Alpi MAi400-DBEV 4-Burner Deluxe Outdoor Kitchen Island. Please read this manual thoroughly before assembly and use, and retain it for future reference.



The complete Mont Alpi MAi400-DBEV 4-Burner Deluxe Outdoor Kitchen Island, featuring a grill, refrigerator, sink, and ample counter space.

Your browser does not support the video tag.

An overview video showcasing the features and design of the Mont Alpi 4-Burner 400 Deluxe Series Outdoor Kitchen Island.

SAFETY INFORMATION

General Safety Precautions

- Always operate the outdoor kitchen in a well-ventilated area.
- Keep children and pets away from the unit during operation.
- Ensure all gas connections are secure and leak-free before use.
- Do not store flammable materials near the grill.
- Use heat-resistant gloves when handling hot surfaces.

- Never leave the grill unattended while in operation.
- Ensure proper clearance from combustible materials as specified in local codes.

Electrical Safety

- Connect the refrigerator and grill electrical components to a properly grounded outlet.
- Do not use extension cords unless absolutely necessary and ensure they are rated for outdoor use and the appliance's power requirements.
- Keep electrical cords away from hot surfaces and water.

PRODUCT FEATURES

The Mont Alpi MAi400-DBEV Deluxe Series Outdoor Kitchen Island is designed for comprehensive outdoor cooking and entertainment. Key features include:

- **Construction:** Heavy-duty 304 stainless steel and white granite countertops.
- **Grill:** 32-inch 4-burner gas grill with 78,000 BTU output.
- **Burners:** 4 tubular stainless steel main burners, 1 ceramic infrared side burner (16" x 14"), and 1 rear height-adjustable ceramic infrared rotisserie burner.
- **Cooking Area:** 28" x 18" (792 square inches total including side burner).
- **Ignition:** Electronic ignition.
- **Lighting:** LED knob lights (blue when off, red when on) and internal cooking lights.
- **Refrigerator:** Outdoor-rated MAF refrigerator with 110-can capacity, glass door, interior blue LED lighting, temperature control, adjustable shelves, and lockable door.
- **Sink & Faucet:** Integrated stainless steel faucet and 12.25"D x 14.5"W x 8.5"D sink with hole cap and strainer.
- **Storage:** Soft-closing drawers and storage cabinets.
- **Mobility:** Gliding castor wheels for movement and stability.
- **Accessories:** Heavy-duty rotisserie kit (110V, 4-watt motor, holds up to 25 lbs), propane hose and regulator, white granite chopping board, and water-resistant full weather cover.
- **Fuel Type:** Propane ready, convertible to natural gas (conversion kit sold separately).

KEY FEATURES



INFRA-RED REAR BURNER

Perfect for rotisserie cooking and pizzas. **PLUS** - Extra large stainless-steel warming rack, internal oven lights.



ACCU-TEMP

Oversize Temperature Gauge



SEAR PLATES


Heavy duty stainless steel infra-red system sear plates, provide even distribution of heat and easy to control heat.



LED ILLUMINATED KNOBS

Blue when off, red when on.

PLUS - A bottle opener (the most important tool for any outdoor cooking)



HEAVY DUTY BURNERS

304 Stainless steel heavy duty burners

Visual representation of the grill's key features: the infrared rear burner for rotisserie, Accu-Temp gauge, sear plates, LED illuminated control knobs, and heavy-duty burners.

INFRA-RED SIDE BURNER



POWERFUL, CONTROLLABLE HEAT

Cooking with Infra-red heat creates flavor, maintain juiciness, and saves you time



RESTAURANT QUALITY SEARING

Cooks steaks at 1800°F for restaurant quality sear marks.



VERSATILITY - Great for heating pots and pans (sauces and boiling water).



TWO GRATE SETTINGS - allow for any pot size and precise searing.



WHEN NOT IN USE - the cover sits flush with the side shelf, creating a fully usable flat surface.

The powerful infrared side burner, demonstrating its heat output, restaurant-quality searing capability, and two grate settings for various cooking needs.



Large capacity outdoor fridge (110 cans of beer), or a variation of wine, beer and soft drinks. Plenty of space.



Lockable door



6 coolness setting 35F to 67F



Easy clip shelves allow for seamless configuration



3 Shelves+ floor, variation of surfaces for drink storage of all shapes and sizes

The integrated outdoor-rated refrigerator, highlighting its large capacity, lockable door, adjustable shelves, and interior blue LED lighting.

SETUP AND INSTALLATION

Unpacking and Placement

The Mont Alpi MAi400-DBEV outdoor kitchen island arrives almost fully assembled. Modular attachments may require minor assembly. Ensure the unit is placed on a level, stable surface with adequate clearance from combustible materials.

Gas Connection

The grill is configured for propane use and includes a propane hose and regulator. For natural gas conversion, a Mont Alpi Natural Gas Conversion Kit (sold separately) is required. Follow the instructions provided with the conversion kit for safe installation. Always check for gas leaks after connecting the gas supply.

Electrical Connection

Connect the grill and refrigerator to a grounded 110V electrical outlet. Ensure the power cords are routed safely and are not exposed to heat or water.

Water Connection (for Sink)

Connect the integrated faucet to a suitable outdoor water supply. Ensure all connections are watertight to prevent leaks.

OPERATING INSTRUCTIONS

Grill Operation

Igniting the Main Burners

1. Ensure the grill lid is open.
2. Turn all main burner control knobs to the "OFF" position.
3. Open the gas supply valve on your propane tank or natural gas line.
4. Push and turn one main burner control knob to the "HIGH" position.
5. Press and hold the electronic ignition button until the burner ignites.
6. Once ignited, release the ignition button and adjust the flame to your desired cooking temperature.
7. Repeat for other main burners as needed.

Using the Infrared Side Burner

1. Lift the side burner cover.
2. Ensure the side burner control knob is in the "OFF" position.
3. Push and turn the side burner control knob to the "HIGH" position.
4. Press and hold the electronic ignition button until the burner ignites.
5. Adjust the flame as required for searing, pan frying, or boiling.

Using the Rotisserie Burner

1. Ensure the rotisserie burner control knob is in the "OFF" position.
2. Mount the rotisserie rod with food securely onto the rotisserie motor.
3. Plug in the 110V rotisserie motor.
4. Push and turn the rotisserie burner control knob to the "HIGH" position.
5. Press and hold the electronic ignition button until the burner ignites.
6. Monitor cooking and adjust heat as necessary.



A detailed view of the heavy-duty rotisserie kit, showing its setup within the grill for even cooking.



The precision control knobs with LED backlighting (blue when off, red when on) and the convenient built-in bottle opener.

Refrigerator Operation

Plug the refrigerator into a grounded 110V outlet. Use the internal temperature control to set your desired cooling level. The blue LED interior lighting can be controlled via a switch inside the unit.

Sink and Faucet Use

Turn on the water supply to the faucet as needed for washing and cleaning. Ensure the drain is clear.

MAINTENANCE AND CARE

Cleaning the Grill

- **Cooking Grids:** Clean after each use with a grill brush while warm. For stubborn residue, soak in warm, soapy water and scrub.
- **Flame Tamers/Heat Plates:** Periodically remove and clean any accumulated grease or food debris.
- **Grease Tray:** The full front pull-out grease tray should be emptied and cleaned regularly to prevent grease fires.
- **Exterior:** Wipe stainless steel surfaces with a soft cloth and a stainless steel cleaner. Clean granite countertops with a mild, non-abrasive cleaner.



The spacious, soft-closing storage drawers providing convenient access for grilling tools and accessories.

Refrigerator Maintenance

Regularly wipe down the interior and exterior of the refrigerator with a mild detergent and soft cloth. Ensure the door seal is clean and intact for efficient operation.

Sink Maintenance

Clean the sink and faucet with a mild cleaner. Ensure the drain is free of blockages.

Weather Protection

Use the provided water-resistant full weather cover to protect your outdoor kitchen from the elements when not in use.

TROUBLESHOOTING

Grill Not Igniting

- Check if the gas supply valve is fully open.
- Ensure the propane tank is not empty or the natural gas line is active.
- Verify that the burner control knob is pushed in and turned to "HIGH" before pressing the ignition button.
- Check if the igniter is sparking. If not, the battery may need replacement or the igniter electrode may be dirty/misaligned.

Uneven Heating

- Clean cooking grids and flame tamers to remove blockages.
- Ensure burners are free from debris.

Refrigerator Not Cooling

- Check if the refrigerator is plugged in and receiving power.
- Ensure the temperature control is set correctly.
- Verify that the door is sealing properly.

Water Leaks from Sink/Faucet


- Check all water connections for tightness.
- Inspect hoses and fittings for damage.

For issues not resolved by these steps, please contact Mont Alpi customer support.

SPECIFICATIONS

Feature	Detail
Brand	Mont Alpi
Model Number	MAi400-DBEV
Product Dimensions (D x W x H)	23"D x 120"W x 46"H
Item Weight	925 Pounds
Material	304 Stainless Steel, Granite
Color	White / Stainless Steel
Fuel Type	Propane (convertible to Natural Gas)
Main Burner Count	4
Side Burner Count	1 (Infrared)
Rear Burner	1 (Infrared Rotisserie)
Total BTU Output	78,000 BTU (Grill)
Cooking Surface Area	792 Square Inches

Refrigerator Capacity	110 Cans
Voltage	110V
Assembly Required	Yes (Modular attachment)



Detailed dimensions of the Mont Alpi MAi400-DBEV outdoor kitchen island, showing width, depth, and height.

WARRANTY AND SUPPORT

Limited Lifetime Warranty

Mont Alpi offers a limited lifetime warranty on its products, demonstrating commitment to quality and customer satisfaction. Specific limitations apply; please refer to the warranty documentation included with your product or contact customer support for full details. The product also includes a 15-Year Limited Warranty as per specifications.

Customer Support

For any questions, concerns, or assistance with your Mont Alpi outdoor kitchen island, please contact Mont Alpi customer support. Contact information can typically be found on the manufacturer's website or in your product packaging.