



Manuals.plus /

› Child Craft /

› Child Craft SOHO 2-Piece Nursery Set Instruction Manual (Model F34001.43-2PC)

## Child Craft F34001.43-2PC

# Child Craft SOHO 2-Piece Nursery Set

## INSTRUCTION MANUAL - MODEL F34001.43-2PC

Brand: Child Craft

### INTRODUCTION

Thank you for choosing the Child Craft SOHO 2-Piece Nursery Set. This manual provides essential information for the safe assembly, operation, and maintenance of your 4-in-1 convertible crib and 3-drawer dresser. Please read all instructions carefully before assembly and retain this manual for future reference.

### IMPORTANT SAFETY INFORMATION

**WARNING: Failure to follow these warnings and the assembly instructions could result in serious injury or death.**

- Always secure furniture to the wall using the provided anti-tip kit to prevent tip-over injuries.
- Never leave children unattended in the crib or bed.
- Always use the appropriate guard rail when converting the crib to a toddler bed or day bed (sold separately).
- Always follow the assembly instructions carefully to ensure the product is assembled correctly and safely.
- Ensure all hardware is tightened securely before use and periodically check for loose hardware.
- Do not use this crib if any parts are missing, damaged, or broken. Contact Child Craft for replacement parts.
- The mattress support adjusts to 3 positions. Always use the lowest position for infants who can pull themselves to a standing position.

### PARTS LIST

Before beginning assembly, ensure all parts listed below are present. If any parts are missing or damaged, do not proceed with assembly. Contact Child Craft customer service for assistance.

#### Crib Components:

- Crib End Panels (2)
- Crib Side Rails (2)

- Mattress Support Frame
- Hardware Pack (bolts, barrel nuts, washers, Allen wrench)

### **Dresser Components:**

- Dresser Top Panel
- Dresser Side Panels (2)
- Dresser Back Panel
- Dresser Base/Legs
- Drawer Fronts (3)
- Drawer Sides (6)
- Drawer Backs (3)
- Drawer Bottoms (3)
- Drawer Glides (6 pairs)
- Drawer Knobs/Pulls (6)
- Hardware Pack (screws, dowels, cam locks, anti-tip kit)

## **ASSEMBLY INSTRUCTIONS**

---

Assembly requires two adults. Use a soft surface during assembly to prevent scratching. Do not use power tools for assembly as overtightening may damage the furniture.

### **Crib Assembly**

1. Attach the crib end panels to the side rails using the provided bolts and barrel nuts. Ensure all connections are secure.
2. Insert the mattress support frame into the desired height position. The mattress support has three adjustable positions. For infants, use the lowest position.
3. Secure the mattress support to the end panels using the designated hardware.
4. Double-check all bolts and connections to ensure they are tight and secure.



Image: The assembled Child Craft SOHO 4-in-1 Convertible Crib, showcasing its modern design and white finish with natural wood legs.



Image: Diagram highlighting key features of the Child Craft SOHO crib, including three mattress height positions, durable pine wood construction, and stylish canted legs.

### Dresser Assembly

1. Assemble the dresser frame by attaching the side panels to the top and base panels using the provided hardware (dowels, screws, cam locks).
2. Install the drawer glides onto the dresser side panels, ensuring they are level and properly aligned.
3. Assemble each drawer: attach drawer sides, back, and front to the drawer bottom. Secure with screws.
4. Attach the drawer knobs/pulls to the drawer fronts.
5. Insert the assembled drawers into the dresser, aligning them with the glides.
6. Attach the anti-tip kit to the back of the dresser and to a wall stud, following the specific instructions included with the kit. This is crucial for safety.



Image: The assembled Child Craft SOHO 3-Drawer Dresser, featuring a white finish, silver handles, and natural wood base.



Image: A close-up of the Child Craft SOHO 3-Drawer Dresser with one drawer partially open, illustrating the smooth ball-bearing metal glides.

## OPERATING INSTRUCTIONS

---

### Crib Mattress Height Adjustment

The crib mattress support can be adjusted to three different heights to accommodate your child's growth. Always use the lowest position once your child can sit up unassisted or pull themselves to a standing position.

1. Remove the mattress and bedding from the crib.
2. Carefully loosen the bolts securing the mattress support frame to the end panels.
3. Adjust the mattress support to the desired height. Ensure all four corners are at the same level.
4. Retighten all bolts securely. Do not overtighten.

### Crib Conversion (4-in-1)

The SOHO crib converts into a toddler bed, day bed, and full-size bed. Conversion kits are sold separately.

## 4-IN-1 CRIBS

---

1

**Crib**



2

**Toddler Bed**



Guard Rail (F09544)  
sold separately

3

**Day Bed**



4

**Full Bed**



Bed Frame (F06402)  
sold separately

Image: A visual guide illustrating the four stages of the Child Craft SOHO crib: Crib, Toddler Bed (requires guard rail F09544, sold separately), Day Bed, and Full Bed (requires bed frame F06402, sold separately).

- **Toddler Bed Conversion:** Remove one of the crib side rails and replace it with the Child Craft Toddler Guard Rail (Model F09544.46, sold separately). Follow the instructions provided with the guard rail.
- **Day Bed Conversion:** Remove one of the crib side rails. No additional parts are typically required for day bed conversion, but ensure the mattress support is at the lowest position.
- **Full-Size Bed Conversion:** This conversion requires the Child Craft Hollywood Bed Frame (Model F06402.44, sold separately). Follow the instructions provided with the bed frame to attach the crib end panels as a headboard and footboard.

### Dresser Drawer Usage

The dresser features three spacious drawers with ball-bearing metal glides for smooth operation. To open, gently pull the knob/pull. To close, push firmly until the drawer is fully seated. Avoid forcing drawers open or closed.

### MAINTENANCE AND CARE

- **Cleaning:** Wipe the furniture surfaces with a dry cloth. For stubborn marks, a slightly damp cloth followed by a dry cloth can be used. Avoid abrasive cleaners, harsh chemicals, or polishes that may damage the finish.
- **Hardware Check:** Periodically check all bolts, screws, and connections on both the crib and dresser to

ensure they remain tight. Loose hardware can compromise safety.

- **Storage:** If storing the furniture, disassemble it carefully and store all parts and hardware in a dry, temperature-controlled environment.

## TROUBLESHOOTING

- **Wobbly Crib/Dresser:** Ensure all bolts and screws are tightened securely. If the issue persists, disassemble and reassemble, paying close attention to alignment.
- **Drawers Not Closing Smoothly or Falling Off Glides:**
  - Check that the drawer glides are properly aligned and securely attached to both the dresser frame and the drawer box.
  - Ensure no objects are obstructing the glides or preventing the drawer from closing fully.
  - Verify that the drawer is not overloaded, which can cause misalignment.
  - If the glides appear damaged, contact Child Craft for replacement parts.
- **Missing Parts:** If any parts are missing upon unboxing, do not proceed with assembly. Contact Child Craft customer service immediately.

## SPECIFICATIONS

| Feature                        | Detail   |
|--------------------------------|--|
| Product Name                   | Child Craft SOHO 2-Piece Nursery Set                       |
| Model Number                   | F34001.43-2PC  |
| Crib Dimensions (L x W x H)    | 54.5" x 29.5" x 36"  |
| Dresser Dimensions (L x W x H) | 42" x 19" x 36.5"  |
| Crib Material                  | Pine wood, MDF, LVL slats                                  |
| Dresser Material               | Rubberwood, MDF, Plywood drawer construction               |
| Finish                         | Baby-safe non-toxic finish                                 |
| Mattress Support               | Adjustable to 3 positions                                  |
| Special Features               | 4-in-1 Convertible Crib, Anti-tip kit included for dresser |

## WARRANTY AND SUPPORT

For warranty information, replacement parts, or customer support, please refer to the warranty card included with your product or visit the official Child Craft website. Keep your proof of purchase for warranty claims.

**Contact Information:** Please refer to the contact details provided on the Child Craft packaging or website for the most up-to-date support information.