

[Manuals.plus](#) /

› [Miele](#) /

› Miele PowerDisk All-in-1 Dishwasher Detergent with AutoDos (6-Pack) Instruction Manual

Miele 11841390

Miele PowerDisk All-in-1 Dishwasher Detergent with AutoDos

Model: 11841390

INTRODUCTION

The Miele PowerDisk All-in-1 Dishwasher Detergent is specifically designed for Miele dishwashers featuring the innovative AutoDos system. This product offers a convenient and effective solution for achieving superior cleaning results with every wash cycle. Each PowerDisk provides detergent for approximately 20 wash cycles, ensuring consistent performance and ease of use.



This image shows a pack of six Miele PowerDisk All-in-1 dishwasher detergent disks, highlighting the product packaging.

SETUP AND INSTALLATION

To begin using your Miele PowerDisk, follow these simple steps:

1. **Locate the AutoDos Compartment:** Open your Miele dishwasher door. The AutoDos compartment is typically located on the inner side of the door or within the appliance interior, specifically designed to house the PowerDisk.
2. **Insert the PowerDisk:** Carefully place the Miele PowerDisk into the designated AutoDos compartment. Ensure it is seated correctly and securely. The PowerDisk is designed for a precise fit.
3. **Close the Compartment:** Close the AutoDos compartment lid firmly until it clicks into place. This ensures proper sealing and detergent dispensing during the wash cycle.
4. **Check Other Consumables:** For optimal cleaning and care, ensure that rinse aid and dishwasher salt reservoirs in your Miele dishwasher are filled as needed, according to your dishwasher's instruction manual.



PowerDisk

Optimum cleaning results

Simply perfect dishwashing. Miele PowerDisks let you take full advantage of your dishwasher's performance. The PowerDisk is designed for Miele dishwashers with AutoDos, allowing for approximately 1 month of squeaky-clean dishwashing (20 cycles per disk).

The PowerDisk is designed to fit perfectly into the AutoDos dispenser of compatible Miele dishwashers, ensuring precise detergent release.



QuickIntenseWash

An unbeatable combination

The QuickIntenseWash program and the perfectly tailored PowerDisk achieve the best possible cleaning and drying results in less than one hour.

This image illustrates a Miele dishwasher featuring the AutoDos system, which automatically dispenses the PowerDisk detergent for optimal cleaning.

OPERATING INSTRUCTIONS

Once the PowerDisk is correctly installed in your Miele dishwasher with AutoDos, the system will automatically dispense the optimal amount of detergent for each wash cycle. No manual dosing is required.

- **Automatic Dosing:** The AutoDos system precisely dispenses the powder-granulate detergent from the PowerDisk at the appropriate time during the selected wash program.
- **Superior Cleaning:** The PowerDisk All-in-1 detergent contains active oxygen, formulated to provide thorough cleanliness and shining results, even with stubborn soiling.
- **Optimized Programs:** For enhanced performance, consider using wash programs like QuickIntenseWash, which, when combined with the PowerDisk, can achieve excellent cleaning and drying results in under an hour.



A detailed view of the Miele PowerDisk, revealing the powder-granulate detergent formulation designed for effective cleaning.

MAINTENANCE

The Miele PowerDisk is designed for convenience and requires minimal maintenance. Each disk is formulated to last for approximately 20 wash cycles, which typically equates to about one month of use, depending on your dishwashing frequency.

- **Replacement:** When the PowerDisk is empty, your dishwasher's display will indicate that a replacement is needed. Simply remove the used disk and insert a new one as described in the Setup section.
- **Storage:** Store unused PowerDisks in a cool, dry place, away from direct sunlight and moisture, to maintain their effectiveness.
- **Environmental Responsibility:** The PowerDisk packaging is made from 100% recycled plastic and is recyclable. Please dispose of empty disks responsibly according to local recycling guidelines.



The packaging for Miele PowerDisk is made from 100% recycled plastic and is certified recyclable, reflecting Miele's commitment to environmental responsibility.

TROUBLESHOOTING

If you experience issues with cleaning performance while using the Miele PowerDisk, consider the following:

- **PowerDisk Installation:** Ensure the PowerDisk is correctly and securely seated in the AutoDos compartment. An improperly installed disk may not dispense detergent effectively.

- **PowerDisk Level:** Check if the PowerDisk is empty and requires replacement. Your dishwasher's display should indicate this.
- **Rinse Aid and Salt:** Verify that your dishwasher's rinse aid and salt reservoirs are adequately filled. These are crucial for optimal drying and preventing water spots, especially in hard water areas.
- **Dishwasher Loading:** Ensure dishes are loaded correctly, allowing water and detergent to reach all surfaces. Avoid overcrowding the dishwasher.
- **Dishwasher Manual:** Refer to your Miele dishwasher's comprehensive instruction manual for specific troubleshooting steps related to the appliance itself and its AutoDos system.

SPECIFICATIONS

Brand	Miele
Model Name	PowerDisk Detergent, 6-pack
Item Model Number	11841390
Product Dimensions	6.06 x 6.06 x 1.5 inches
Item Weight	49.4 Ounces (for 6-pack)
Number of Items	6
Item Form	Powder-granulate
Scent	Fresh
Material Features	100% Recycled, Recyclable Packaging
Material Type Free	Paraben Free, Phosphate Free
Recommended Uses	Dishwashing in Miele dishwashers with AutoDos

Superior Cleaning



PowerDisk
Dishwasher detergent with active oxygen for shining results even with stubborn soiling



PowerDisk Eco
Environmentally friendly dishwasher detergent without fragrances and dyes

Miele offers both the PowerDisk Original with active oxygen for stubborn soiling and the PowerDisk Eco, an environmentally friendly option without fragrances and dyes.

WARRANTY AND SUPPORT

For product support, warranty information, or any inquiries regarding your Miele PowerDisk or Miele dishwasher, please contact Miele Customer Service directly. Detailed contact information can typically be found on the official Miele website or in your

dishwasher's instruction manual.

Miele is committed to providing high-quality products and support to ensure customer satisfaction.

- **Miele Official Website:** www.miele.com
- **Customer Service:** Refer to the contact section on the Miele website for regional support numbers and email.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question