Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Vorago /
- Vorago SC-302-V2 Electric Scooter User Manual

Vorago SC-302-V2

Vorago SC-302-V2 Electric Scooter User Manual

Model: SC-302-V2 | Brand: Vorago

INTRODUCTION

This manual provides essential instructions for the safe operation, maintenance, and troubleshooting of your Vorago SC-302-V2 Electric Scooter. Please read this manual thoroughly before using the scooter to ensure proper function and safety.

SAFETY INFORMATION

Always wear a helmet and appropriate safety gear when operating the scooter. Observe local traffic laws and regulations. Do not ride in adverse weather conditions or on slippery surfaces. Ensure the scooter is in good working order before each use.

- Maximum weight capacity: 120 kg.
- · Recommended age: 12 years and older.
- · Avoid riding on steep inclines exceeding 15%.
- · Do not operate under the influence of alcohol or drugs.

PACKAGE CONTENTS

Upon unpacking, verify that all components are present:

- Vorago SC-302-V2 Electric Scooter
- · Power Charger
- User Manual (this document)
- · Warranty Information

SETUP

Unfolding the Scooter

Carefully remove the scooter from its packaging. Locate the folding mechanism near the base of the handlebar stem. Release the latch and lift the handlebar stem until it locks securely into place. Ensure all locking mechanisms are engaged before use.



Image: The Vorago SC-302-V2 Electric Scooter in its fully unfolded position, ready for use. This image shows the scooter from a side profile.

Charging the Battery

Before first use, fully charge the scooter's battery. Connect the charger to the charging port, typically located on the side of the deck, and then plug the charger into a standard electrical outlet. The charging indicator light on the charger will change color (e.g., red to green) when charging is complete. A full charge takes approximately 5 hours.



Image: A close-up view of the scooter's deck, highlighting the charging port and indicating the electric brake feature. The image also shows an icon for "CARGA COMPLETA EN 4 HRS" (Full charge in 4 hours) and "FRENO ELÉCTRICO" (Electric Brake).

Handlebar Adjustment (if applicable)

Ensure the handlebars are at a comfortable height and securely fastened. Check all screws and quick-release levers for tightness.

OPERATING INSTRUCTIONS

Power On/Off

Press and hold the power button on the digital display panel to turn the scooter on or off. The digital panel will display speed, battery level, and speed mode.



Image: A view of the scooter's handlebar area, showing the digital display panel and LED lights. The display shows speed and battery information, and the LED lights are indicated for visibility.

Riding the Scooter

- 1. Place one foot on the deck and push off with the other foot to gain initial momentum.
- 2. Once moving, gently press the accelerator lever to engage the motor.
- 3. Adjust speed using the accelerator. The scooter features multiple speed modes, allowing a maximum speed of 25 km/h.
- 4. To change speed modes, refer to the digital display and control buttons.



Image: An illustration of the scooter highlighting its maximum speed of 25 km/h and its protected battery system, indicating performance and safety features.

Braking

The SC-302-V2 is equipped with both an electric brake and a disc brake for reliable stopping power. To brake, gently squeeze the brake lever on the handlebar. Apply both brakes simultaneously for optimal stopping performance, especially at higher speeds.

Folding for Storage/Transport

To fold the scooter, ensure it is powered off. Locate the folding mechanism and release the latch. Carefully fold the handlebar stem down until it clicks into its folded position. This compact design allows for easy storage and transport.



Image: A woman demonstrating the portability of the scooter by placing it, in its folded state, into the trunk of a car. This illustrates the scooter's convenient folding design for transport.

MAINTENANCE

Battery Care

- Charge the battery regularly, even if the scooter is not in use, to prolong its lifespan.
- · Avoid completely draining the battery before recharging.
- Store the scooter in a cool, dry place when not in use.

Cleaning

Wipe the scooter with a damp cloth. Do not use high-pressure water jets or immerse the scooter in water, as this can damage electronic components.

Tire Pressure

Regularly check tire pressure and inflate to the recommended PSI (pounds per square inch) as indicated on the tire sidewall or in the specifications section. Proper tire pressure ensures optimal performance and safety.

Brake Inspection

Periodically inspect the brake system for wear and proper function. Ensure brake levers are responsive and brake pads are not excessively worn.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Scooter does not power on	Low battery; loose connections	Charge the battery; check all cable connections.
Reduced range or speed	Under-inflated tires; low battery; heavy load	Inflate tires to correct pressure; fully charge battery; reduce load.
Brakes feel weak	Worn brake pads; loose brake cable	Inspect and replace brake pads if necessary; adjust brake cable tension.
Unusual noises during operation	Loose components; foreign object	Inspect scooter for loose parts; remove any foreign objects. If noise persists, contact support.

SPECIFICATIONS

Feature	Detail
Model Name	SC-302-V2
Motor Power	250W
Maximum Speed	25 km/h
Range (Autonomy)	Up to 25 km
Battery Type	6000mAh Lithium-Ion
Charging Time	Approximately 5 hours
Brake System	Electric brake, Disc brake
Frame Material	Aluminum
Maximum Load Capacity	120 kg
Dimensions (unfolded)	106 x 44 x 115 cm
Weight	14.4 kg
Special Features	Foldable design, Anti-slip deck, LED lights, Digital display panel

WARRANTY INFORMATION

The Vorago SC-302-V2 Electric Scooter comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and material faults under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

For warranty service, please contact Vorago customer support with your product details and proof of purchase.

CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report an issue with your Vorago SC-302-V2 Electric Scooter, please contact our customer support team.

- **Website:** www.voragolive.com (Please check the official Vorago website for the most current contact information.)
- Email: Refer to the official Vorago website for support email.
- **Phone:** Refer to the official Vorago website for support phone numbers.

When contacting support, please have your model number (SC-302-V2) and purchase date available.

© 2024 Vorago. All rights reserved.

Related Documents - SC-302-V2




Vorago Kick Scooter 202V2 Quick Guide

Official quick guide for the Vorago Kick Scooter 202V2, covering assembly, safety precautions, operation, battery information, and warranty details.



Vorago Kick Scooter 500 User Manual & Quick Guide

Comprehensive guide for the Vorago Kick Scooter 500, covering setup, safety, operation, maintenance, and technical specifications. Learn how to assemble, charge, ride, and care for your electric scooter.



EMOVE Cruiser V2 AWD: History and User Manual for Electric Scooter Performance

Explore the history, features, and comprehensive user guide for the EMOVE Cruiser V2 AWD electric scooter. Learn about its evolution, testing, specifications, setup, and maintenance from Voro Motors.



Hiboy Max V2 Electric Scooter User Manual and Guide

Comprehensive user manual for the Hiboy Max V2 electric scooter, covering assembly, charging, riding instructions, safety guidelines, maintenance, specifications, warranty, and troubleshooting.



Nissan/Infiniti Starting and Charging System Service Manual (VK45DE, VQ35DE)

Comprehensive service manual detailing the starting and charging systems for Nissan/Infiniti vehicles with VK45DE and VQ35DE engines. Includes diagnostics, troubleshooting, removal, installation, and specifications for battery, starter, and alternator.



Vorago HPB-505 Hybrid ANC Headphones - User Guide and Specifications

Comprehensive guide for Vorago HPB-505 Hybrid ANC Headphones, covering setup, app usage, charging, controls, ANC features, low latency mode, technical specifications, and warranty information.

Documents - Vorago - SC-302-V2



Vorago Kick Scooter 302V2 - User Manual and Safety Guide

Official user manual and safety guide for the Vorago Kick Scooter 302V2. Learn about assembly, operation, safety precautions, battery care, technical specifications, and warranty information.

lang:es score:39 filesize: 1.34 M page_count: 24 document date: 2023-01-09



[pdf] User Manual

SC 302 V2 Manual Ficha técnica Drivers Fichas y Manuales voragolive media vorago descargables ||| SC-302_V2_Manual.pdf 1 04/12/2024 11:28:02 a. m. C M Y CM MY CY CMY K SC-302_V2_Manual.pdf 2 04/12/2024 11:28:02 a. m. C M Y CM MY CY CMY K SC-302_V2_Manual.pdf 3 04/12/2024 11:28:03 a. m. C M Y CM MY CY CMY K SC-302_V2_Manual.pdf 4 04/12/2024 11:28:03 a. m. C M Y CM MY CY CMY K SC-302_V2_Manual.pdf 4 04/12/2024 11:28:03 a. m. C M Y CM MY CY CMY K SC-302_V2_Ma...

lang:tl score:29 filesize: 17.49 M page_count: 26 document date: 2024-12-04



[pdf]

KICK SCOOTER 302 GR SC Ficha voragolive media vorago descargables |||

SC-302-GR KICK SCOOTER 302-GR SCOOTER ELCTRICO El camino jams ser aburrido si lo recorres en un scooter **SC-302-V2**, que es tan veloz y resistente, que querrs hacer todos tus trayectos en I. Sintete seguro con su innovador sistema de frenado y cuando no lo utilices, gurdalo fcilmente en cualquier espa...

lang:es score:16 filesize: 2.61 M page_count: 4 document date: 2024-12-05



[pdf]

Ficha técnicaDrivers Fichas y ManualesSC 302 BK Fichavoragolive media vorago descargables SC ||| SC-302 KICK SCOOTER 302 SCOOTER ELCTRICO El camino jams ser aburrido si lo recorres en un scooter **SC-302-V2**, que es tan veloz y resistente, que querrs hacer todos tus trayectos en I. Sintete seguro con su innovador sistema de frenado y cuando no lo utilices, gurdalo fcilmente en cualquier espacio gr... lang:es score:16 filesize: 1.87 M page_count: 3 document date: 2025-07-09