

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Midea](#) /

› [Midea WHS-65LB1 Refrigerator & Farberware 0.7 Cu. Ft. Microwave Oven Instruction Manual](#)

## Midea WHS-65LB1

# Instruction Manual

## MIDEA WHS-65LB1 COMPACT REFRIGERATOR & FARBERWARE 0.7 CU. FT. MICROWAVE OVEN

**Models: WHS-65LB1 (Refrigerator), FMO07ABTWHA (Microwave)**

### Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Midea WHS-65LB1 Compact Refrigerator and Farberware 0.7 Cu. Ft. Countertop Microwave Oven. Please read these instructions thoroughly before use and retain them for future reference.

### Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons. This includes:

- Read all instructions before using the appliance.
- Ensure the appliance is properly grounded.
- Do not operate any appliance with a damaged cord or plug.
- Keep ventilation openings clear of obstructions.
- Unplug the appliance before cleaning or maintenance.

### Product Overview



**Figure 1:** Front view of the Midea WHS-65LB1 Compact Refrigerator.



**Figure 2:** Front view of the Farberware 0.7 Cu. Ft. Countertop Microwave Oven.

**Midea WHS-65LB1 Compact Refrigerator Features:**

- Mechanical Temperature Adjustment: Ranges from -2°C to 2°C (32°F to 35.6°F).
- Large Storage Areas: Ideal for chilling beverages and healthy snacks/produce. Not suitable for storing frozen foods or making ice cubes.
- Adjustable Legs: For stable placement.
- Reversible Door: Can be opened from the left or right.
- Net Capacity: 1.6 cu.ft.
- Environment-friendly technology.
- Separate chiller compartment.
- High-Quality HIPS Interior.



**Figure 3:** Key features of the Midea Compact Refrigerator.



**Figure 4:** Interior view of the Midea Compact Refrigerator showing storage capacity.

#### **Farberware 0.7 Cu. Ft. Countertop Microwave Oven Features:**

- Output Power: 700 Watts.
- 10 Power Levels: For versatile cooking.
- Multi-Stage Cooking: Allows for customized cooking sequences.
- 6 One-Touch Cooking Programs: Including popcorn, potato, pizza, beverage, frozen dinner, and reheat.
- Defrost Settings: Defrost by weight or by time.
- Express Cooking: 1-6 minute options and a +30 second button.
- Memory Function: To save favorite cook settings.
- LED Display: With clock and countdown timer.
- Interior LED Lighting: For easy viewing of food.
- Child Safety Lock Function.
- Easy-to-clean interior.

## **Setup**

#### **Midea WHS-65LB1 Compact Refrigerator:**

1. **Unpacking:** Carefully remove all packaging materials.
2. **Placement:** Place the refrigerator on a flat, stable surface. Ensure adequate ventilation around the unit.
3. **Adjustable Legs:** Use the adjustable legs to level the refrigerator.
4. **Reversible Door:** The door can be reversed to open from either the left or right side to suit your space. Refer to the detailed diagram below for instructions.



Figure 5: Refrigerator dimensions for proper placement.



Figure 6: Illustration of the reversible door hinge feature.

**Farberware 0.7 Cu. Ft. Countertop Microwave Oven:**

- 1. Unpacking:** Remove all packing materials and accessories. Check the microwave for any damage.
- 2. Placement:** Place the microwave on a flat, stable countertop. Ensure at least 3 inches of clearance on the top, sides, and rear for proper ventilation.
- 3. Power Connection:** Plug the microwave into a standard 120V, 60Hz grounded electrical outlet.

# WORKS WITH ANY DECOR



Figure 7: Microwave oven placed on a countertop.

# GET THE PERFECT FIT



Figure 8: Microwave oven dimensions for space planning.

## Operating Instructions

### Midea WHS-65LB1 Compact Refrigerator:

- Temperature Control:** Locate the mechanical temperature adjustment dial inside the refrigerator.
- Setting Temperature:** Turn the dial to your desired setting. A lower number typically indicates a warmer temperature, while a higher number indicates a colder temperature. The recommended range is between -2°C and 2°C (32°F to 35.6°F).
- Initial Cooling:** Allow the refrigerator to cool for several hours before placing food inside.



Figure 9: Removable shelf for flexible storage.



Figure 10: High-quality HIPS interior for direct food placement.

#### Farberware 0.7 Cu. Ft. Countertop Microwave Oven:

- Basic Cooking:** Place food in the microwave. Select desired power level and cooking time using the keypad. Press 'Start'.
- One-Touch Programs:** For common items like popcorn or pizza, press the corresponding one-touch button. The microwave will automatically set the optimal cooking time and power.
- Defrosting:** Use the 'Defrost by Weight' or 'Defrost by Time' functions. Enter the weight or time as prompted.
- Express Cooking:** Press any number from 1 to 6 for instant cooking for that many minutes at 100% power. Use the '+30 Sec' button to add 30 seconds to cooking time during operation.
- Setting the Clock:** Refer to the detailed instructions in the full manual for setting the clock and timer functions.

Your browser does not support the video tag.

Video 1: Overview of the 0.7 cu.ft Microwave Oven features and basic operation.

Your browser does not support the video tag.

Video 2: Demonstration of the Compact Microwave Oven's cooking capabilities.

#### Child Safety Lock:

The child safety door lock mode activates when the microwave is powered on. When cooking starts, the door automatically locks immediately.

- To open microwave during cooking:** Press the 0/UNLOCK or STOP/CANCEL pad once, then pull the door handle.
- To open microwave after cooking:** Press the 0/UNLOCK or STOP/CANCEL pad once, then pull the door handle.
- To deactivate the child safety lock:** Press the 0/UNLOCK pad for 2 seconds until the display indicates "ULoc". Then, press the 7 pad and 9 pad; the display will show "ULoc". The door can be opened at any time when child lock mode is deactivated and will remain deactivated even with a loss of power.
- To re-activate the child safety lock:** Press the 0/UNLOCK pad for 2 seconds until the display indicates "ULoc". Then, press the 7 pad and 9 pad; the display will show "Loc".

Your browser does not support the video tag.

Video 3: Instructions for activating and deactivating the Child Lock feature.

## Maintenance

#### Midea WHS-65LB1 Compact Refrigerator:

- Cleaning:** Regularly clean the interior and exterior surfaces with a mild detergent and soft cloth. Ensure the

refrigerator is unplugged before cleaning.

- **Defrosting:** This unit features a separate chiller compartment. Manual defrosting may be required for this section if ice buildup occurs.

#### Farberware 0.7 Cu. Ft. Countertop Microwave Oven:

- **Cleaning:** The microwave features an easy-to-clean interior. Wipe spills immediately with a damp cloth. For stubborn stains, use a mild, non-abrasive cleaner. The glass turntable can be removed for cleaning.
- **Exterior:** Clean the exterior with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.

## Troubleshooting

If you experience issues with your appliance, consult the following common troubleshooting tips. For more complex problems, contact customer support.

- **Appliance not turning on:** Check if the power cord is securely plugged into a working outlet. Verify the circuit breaker has not tripped.
- **Refrigerator not cooling:** Ensure the temperature control is set correctly. Check for obstructions around the vents. Avoid overloading the refrigerator.
- **Microwave not heating:** Ensure the door is closed securely. Check if the cooking time and power level are set correctly.
- **Unusual noises:** For refrigerators, slight humming or gurgling sounds are normal. For microwaves, ensure the turntable is properly seated.

## Specifications

### Midea WHS-65LB1 Compact Refrigerator

Feature	Specification
Brand	Midea
Model Info	WHS 65LB1
Capacity	1.6 Cubic Feet
Product Dimensions (W*D*H)	17.72"D x 18.58"W x 19.37"H
Color	Black
Door Hinges	Reversible (Left or Right)
Number of Doors	1
Shelves	2

### Farberware 0.7 Cu. Ft. Countertop Microwave Oven

Feature	Specification
Brand	Farberware (part of Midea product bundle)
Model Info	FMO07ABTWHA (from product description)
Capacity	0.7 Cubic Feet

Feature	Specification
Energy Use	700 Watts
Installation Type	Countertop
Special Features	Timer, Turntable, LED Lighting, Child Lock
Color	Black
Defrost System	Defrost

## **Warranty and Support**

The Midea WHS-65LB1 Compact Refrigerator comes with a full 1-year warranty. For warranty claims, technical support, or service inquiries for either appliance, please refer to the contact information provided with your purchase documentation or visit the respective brand's official website.