Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TMEOSK WF194AK

TMEOSK Twin Size Wood Platform Bed with Trundle and Headboard Instruction Manual

Model: WF194AK

1. Introduction and Safety Information

This manual provides detailed instructions for the assembly, operation, and maintenance of your TMEOSK Twin Size Wood Platform Bed with Trundle and Headboard. Please read all instructions carefully before assembly and use to ensure safe and proper operation.

Important Safety Warnings:

- Keep all assembly hardware out of reach of children.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not use power tools for assembly as this may overtighten screws and damage the wood.
- Place the bed on a flat, level surface during assembly and use.
- Do not stand or jump on the bed.
- Maximum weight capacity for the main bed: 250 lbs.
- Maximum weight capacity for the trundle bed: 250 lbs.

2. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Headboard (1)
- Footboard (1)
- Side Rails for Main Bed (2)
- Trundle Bed Frame Components (Front, Back, Sides)
- Main Bed Slats (10)
- Trundle Bed Slats (10)
- Trundle Casters (4)
- Hardware Pack (Screws, Bolts, Allen Wrench)

3. Setup and Assembly Instructions

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

Step 1: Assemble the Main Bed Frame

Attach the side rails to the headboard and footboard using the provided bolts and Allen wrench. Ensure all connections are secure but do not fully tighten until all major components are in place.



Image: Main bed frame with trundle partially extended, illustrating the structure and slat supports.



Image: Detail of a corner joint, showing how the side rail connects to the headboard/footboard using bolts.

Step 2: Install Main Bed Slats

Place the main bed slats across the side rails. Secure them using the provided screws. Ensure even spacing for optimal mattress support.



Image: Front view of the main bed frame with all wooden slats properly installed, ready for a mattress.

Step 3: Assemble the Trundle Bed Frame

Connect the trundle bed frame components (front, back, and sides) using the appropriate hardware. Attach the casters to the bottom of the trundle frame.



Image: Side profile showing the main bed frame and the separate trundle bed frame, highlighting their relative positions.

Step 4: Install Trundle Bed Slats

Place the trundle bed slats across the trundle frame and secure them with screws. Ensure the casters are functioning smoothly.



Image: The trundle bed fully assembled with slats and casters, neatly stored underneath the main bed frame.

Step 5: Final Tightening

Once all components are assembled, go back and fully tighten all bolts and screws. Do not overtighten.

4. Operating Instructions

Using the Trundle Bed:

1. To extend the trundle bed, gently pull the trundle frame from underneath the main bed. The casters will allow it to roll out smoothly.
2. To retract the trundle bed, push the trundle frame back underneath the main bed until it is fully stored.

Ensure the area around the bed is clear before extending or retracting the trundle to prevent obstruction.



Image: The TMEOSK Twin Platform Bed with its trundle extended, shown in a furnished room, demonstrating its functionality.

5. Maintenance

- **Cleaning:** Wipe the wood surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Hardware Check:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten as needed to maintain stability.
- **Avoid Moisture:** Protect the bed from excessive moisture and direct sunlight to prevent warping or fading of the wood.
- **Caster Care:** Keep trundle casters free of debris to ensure smooth operation.

6. Troubleshooting

- **Issue: Bed feels wobbly or unstable.**
  Solution: Check all bolts and screws. Ensure they are fully tightened. Make sure the bed is placed on a level surface.
- **Issue: Trundle bed does not slide smoothly.**
  Solution: Inspect the casters for any obstructions (e.g., carpet fibers, dust). Clean the casters if necessary. Ensure the floor surface is clear.
- **Issue: Squeaking noises.**
  Solution: Re-tighten all hardware. If squeaking persists, apply a small amount of lubricant (e.g., silicone spray) to the joints where wood meets wood or wood meets metal, being careful not to stain the wood finish.

7. Specifications

Feature	Detail
Model Number	WF194AK
Brand	TMEOSK
Size	Twin
Product Dimensions (L x W x H)	80"L x 42"W x 38"H
Main Bed Weight Capacity	250 lbs
Trundle Bed Weight Capacity	250 lbs
Material	Pine Wood
Color	Espresso
Assembly Required	Yes
Item Weight	76 pounds



Image: Diagram illustrating the precise dimensions of the main bed and the trundle bed components.

8. Warranty and Customer Support

TMEOSK products are manufactured with quality and care. For any questions regarding assembly, missing parts, or product issues, please contact TMEOSK customer support. Please have your model number (WF194AK) and purchase information ready when contacting support.

Specific warranty details may vary. Please refer to your purchase documentation or contact customer service for warranty information.

© 2023 TMEOSK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BPLSD71G

More documents and user manuals: **https://manuals.plus/**