

Laresar L6 NEX

Laresar L6 NEX Original Vacuum Cleaner Bags User Manual

Model: L6 NEX | Part Number: YA-CPA888-L6NEX-FR

1. INTRODUCTION

This manual provides essential information for the correct installation, usage, and maintenance of your Laresar L6 NEX original vacuum cleaner bags. Using genuine replacement parts ensures the optimal performance and longevity of your Laresar L6 NEX robotic vacuum cleaner. Please read these instructions carefully before use.

2. PACKAGE CONTENTS

Your package should contain the following items:

- 4 x Laresar L6 NEX Original Vacuum Cleaner Bags



This image displays a pack of four Laresar L6 NEX original vacuum cleaner bags. Each bag features a white filter material with a brown cardboard collar and a black rubber seal around the central opening, designed for secure fitting and efficient dust collection.

3. INSTALLATION INSTRUCTIONS

Follow these steps to correctly install a new vacuum cleaner bag into your Laresar L6 NEX robotic vacuum's auto-empty station:

1. **Power Off:** Ensure the auto-empty station is unplugged from the power outlet before beginning

installation.

2. **Open Compartment:** Locate and open the dust bag compartment on your Laresar L6 NEX auto-empty station. Refer to your vacuum's main user manual for the exact location if unsure.
3. **Remove Old Bag (if applicable):** If an old bag is present, carefully pull it upwards and out of the compartment. Most bags have a self-sealing mechanism to prevent dust leakage upon removal. Dispose of the used bag responsibly.
4. **Insert New Bag:** Take a new Laresar L6 NEX original vacuum cleaner bag. Align the cardboard collar of the new bag with the slot in the auto-empty station's compartment. Gently push the bag down until it is securely seated. Ensure the opening of the bag is properly aligned with the suction inlet.
5. **Close Compartment:** Close the dust bag compartment cover firmly until it clicks into place.
6. **Power On:** Plug the auto-empty station back into the power outlet. The vacuum cleaner is now ready for operation with the new bag.

Important: Only use original Laresar L6 NEX vacuum cleaner bags to ensure proper fit, filtration efficiency, and to prevent damage to your auto-empty station.

4. OPERATING CONSIDERATIONS

Once installed, the vacuum cleaner bag operates automatically as part of the auto-empty station's function. The station will transfer collected dust and debris from the robotic vacuum into the bag.

- **Automatic Emptying:** The L6 NEX robotic vacuum will automatically return to the auto-empty station to deposit its dustbin contents into the bag.
- **Bag Full Indicator:** Your auto-empty station or the accompanying mobile application may provide an indicator when the dust bag is full and requires replacement.

5. MAINTENANCE AND REPLACEMENT

Regular replacement of the vacuum cleaner bag is crucial for maintaining optimal suction power and air filtration performance of your Laresar L6 NEX system.

- **Replacement Frequency:** The frequency of bag replacement depends on usage habits, pet presence, and the amount of debris collected. Generally, it is recommended to replace the bag every 4-8 weeks, or when the "bag full" indicator is activated.
- **Checking Bag Status:** Periodically check the dust bag compartment to assess the fill level, especially if you notice a decrease in emptying efficiency or an unusual odor.
- **Disposal:** When replacing, carefully remove the full bag and dispose of it in household waste. The self-sealing design helps contain dust and allergens.

6. TROUBLESHOOTING

If you encounter issues related to the vacuum cleaner bags, consider the following:

- **Reduced Suction/Ineffective Emptying:**
 - Check if the dust bag is full and needs replacement.
 - Ensure the dust bag is correctly installed and fully seated in the compartment.
 - Verify that the compartment cover is securely closed.
- **Dust Leakage:**
 - Confirm the bag is an original Laresar L6 NEX bag. Non-original bags may not fit properly.

- Ensure the bag's cardboard collar and rubber seal are not damaged and are correctly aligned.
- Check for any tears or damage to the bag material itself.

- **"Bag Full" Indicator Remains On After Replacement:**

- Ensure the new bag is properly installed and the compartment door is fully closed.
- Restart the auto-empty station by unplugging and replugging it after a few seconds.

If problems persist, consult the main user manual for your Laresar L6 NEX robotic vacuum and auto-empty station, or contact Laresar customer support.

7. SPECIFICATIONS

| | |
|----------------------|--|
| Brand | Laresar |
| Model Compatibility | Laresar L6 NEX Robotic Vacuum Cleaner Auto-Empty Station |
| Part Number | YA-CPA888-L6NEX-FR |
| Quantity | 4 bags per pack |
| Material | Non-woven fabric, cardboard, rubber seal |
| Color | White (bag), Brown (collar) |
| Dimensions (Package) | 20.4 x 19.2 x 5.3 cm |
| Weight (Package) | 130 grams |



8. WARRANTY AND SUPPORT





Specific warranty information for replacement parts like vacuum cleaner bags is typically provided with the main product (the Laresar L6 NEX robotic vacuum cleaner and auto-empty station). Please refer to the warranty documentation included with your original vacuum cleaner purchase.

For further assistance or inquiries, please contact Laresar customer support through their official website or the contact information provided in your main product manual.

© 2024 Laresar. All rights reserved.

Related Documents - L6 NEX

| | |
|---|---|
|  | Laresar L6 Nex Robot Vacuum Cleaner App Quick Start Guide Get started quickly with the Laresar L6 Nex Robot Vacuum Cleaner. This guide covers app download, connection, and key cleaning features for efficient home cleaning. |
|  | Laresar L6 Nex Robot Vacuum Cleaner User Manual Comprehensive user manual for the Laresar L6 Nex Robot Vacuum Cleaner, covering setup, operation, maintenance, troubleshooting, specifications, and warranty information. |

| | |
|---|---|
|  | <p>Laresar L6 Pro Robot Vacuum Cleaner User Manual and Maintenance Guide</p> <p>Comprehensive user manual for the Laresar L6 Pro Robot Vacuum Cleaner, covering setup, maintenance, troubleshooting, and warranty information. Includes detailed instructions for optimal performance.</p> |
|  | <p>Laresar L6 Nex Robot Vacuum Cleaner Quick Start Guide</p> <p>This guide provides essential information for setting up and using the Laresar L6 Nex Robot Vacuum Cleaner, including app connection, cleaning modes, and important usage notes.</p> |
|  | <p>Laresar L6 Nex Robot Vacuum Cleaner User Manual</p> <p>Comprehensive user manual for the Laresar L6 Nex Robot Vacuum Cleaner, covering setup, operation, maintenance, troubleshooting, and specifications. Learn how to use the app, clean your floors, and keep your device in optimal condition.</p> |
|  | <p>Laresar L6 Nex Robot Aspirapolvere: Guida Utente e Manutenzione</p> <p>Manuale completo per il robot aspirapolvere Laresar L6 Nex, con istruzioni dettagliate su installazione, uso, manutenzione, risoluzione dei problemi e garanzia.</p> |