

[Manuals.plus](#) /

› [Sekey](#) /

› Sekey Collapsible Foldable Wagon Instruction Manual

Sekey FW35

Sekey Collapsible Foldable Wagon Instruction Manual

Model: FW35

Brand: Sekey

INTRODUCTION

This manual provides detailed instructions for the proper assembly, operation, maintenance, and care of your Sekey Collapsible Foldable Wagon. Please read this manual thoroughly before using the product to ensure safe and efficient operation. This wagon is designed for transporting goods and is not intended for transporting children.



Image: The Sekey Collapsible Foldable Wagon, showcasing its compact design and sturdy wheels.

SAFETY INFORMATION

- Do not exceed the maximum weight capacity of 330 pounds (150 kg).
- This product is not designed for transporting children or pets.
- Ensure the wagon is fully unfolded and locked into place before loading.
- Always engage the wheel brakes when the wagon is stationary, especially on inclines.
- Distribute weight evenly within the wagon to maintain stability.
- Avoid sharp turns at high speeds, especially when fully loaded.
- Keep hands and fingers clear of folding mechanisms during setup and folding.
- Inspect the wagon for any damage or loose parts before each use. Do not use if damaged.

COMPONENTS AND FEATURES

- **Heavy-Duty Frame:** Constructed from super strong anti-rust iron pipes for durability and stability.
- **600D Oxford Fabric:** Double-layered, thickened, waterproof, and tear-resistant material for the main compartment.
- **All-Terrain Wheels:** Large 10-inch diameter wheels designed for various surfaces including road, beach, grass, and rough terrain. Features anti-vibration and noise reduction.
- **Adjustable Handle:** Multi-angle and anti-drop handle for comfortable pulling and secure storage.
- **Extra Storage:** Includes two mesh cup holders and an additional storage mesh pocket for smaller items.
- **Sand-Leaking Net:** Located at the bottom four corners to prevent sand accumulation.
- **Secure Lock Buckle:** For quick-detach design and secure folding.

2 Drink Holders



Convenient zipper



2 Bold Wagon Straps

Storage mesh



Image: Detail view of the wagon's convenient features, including drink holders and storage mesh.

SETUP AND UNFOLDING

1. Remove the wagon from its packaging. It comes pre-assembled in a folded state.
2. Place the folded wagon on a flat, stable surface.
3. Grasp the center handle located inside the wagon's fabric and pull upwards firmly. The frame will begin to expand.
4. Continue pulling until the wagon is fully extended and the frame locks into place. Ensure all crossbars are fully straightened.
5. Press down on the bottom panel to flatten it and secure the wagon's base.
6. Adjust the pulling handle to your desired height by pressing the release button and extending or retracting the handle.



Image: Visual guide demonstrating the simple one-handed unfolding process of the wagon.

OPERATING INSTRUCTIONS

Loading the Wagon

- Place items evenly inside the wagon to prevent tipping.
- Utilize the extended and heightened cloth pocket for larger items.
- Use the mesh cup holders for beverages and the side storage mesh for smaller accessories.

Pulling and Steering

- Hold the adjustable handle firmly.
- The coaxial steering system allows for easier control and prevents tire collision, making it simpler to maneuver than traditional 360° universal wheels.
- Navigate over various terrains with ease due to the large, durable wheels.

Coaxial Steering



Easier To Control
Than 360° Universal Wheels



Avoid Tires
Collision



Image: Explanation of the coaxial steering system, highlighting its ease of control.

Engaging Brakes

- To stop the wagon from rolling, push down on the red brake levers located on the front wheels.
- Ensure both brakes are engaged for maximum stability when parked.
- To release, lift the red brake levers upwards.



Image: Detail of the wheel and brake mechanism for secure parking.

Folding for Storage

- Empty the wagon completely.
- Pull the center handle upwards, similar to unfolding, but continue pulling until the wagon collapses inward.
- Secure the folded wagon with the integrated lock buckle to keep it compact.
- The anti-drop handle design ensures the handle stays in place when folded.

MAINTENANCE AND CARE

- **Cleaning:** The 600D Oxford fabric is waterproof and tear-resistant. It can be easily disassembled for cleaning. Wipe down the fabric with a damp cloth and mild soap. For the frame, wipe with a damp cloth and dry thoroughly.
- **Storage:** Store the folded wagon in a dry place away from direct sunlight and extreme temperatures to prolong its lifespan.
- **Inspection:** Regularly check all bolts, screws, and moving parts to ensure they are secure. Tighten any loose fasteners.
- **Wheel Care:** Keep the wheels free of debris. The wheels are designed to be easily removable for maintenance if needed.



Image: The wagon's fabric is removable for convenient cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Wagon does not unfold completely.	Frame not fully extended or locked.	Ensure the center handle is pulled firmly upwards until the frame clicks into place. Press down on the bottom panel.
Wagon is difficult to pull or steer.	Overloaded or uneven weight distribution; debris in wheels.	Reduce load and redistribute weight. Check wheels for obstructions and clean if necessary.
Brakes are not holding.	Brake levers not fully engaged or worn.	Ensure brake levers are pushed down completely. If issue persists, contact customer support.

SPECIFICATIONS

- **Product Dimensions:** 35.43"D x 20.08"W x 37.6"H
- **Material:** Iron frame, 600D Oxford Fabric
- **Color:** Black&grey
- **Weight Limit:** 330 Pounds (150 kg)
- **Item Weight:** 20 pounds (9.07 kg)

- **Number of Wheels:** 4
- **Tire Type:** Tubeless, All-Terrain
- **Assembly Required:** No (comes pre-assembled)
- **Special Features:** Adjustable Handle, Built-In Cup Holder, Extra Storage, Foldable, Sand-leaking net



Image: Detailed dimensions of the Sekey Collapsible Foldable Wagon.

WARRANTY AND SUPPORT

Sekey wagons come with a **3-year warranty**. If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact Sekey customer support. Please refer to your purchase documentation for specific contact details or visit the official Sekey website.

Note: This product is not designed to transport children.

