

ODK 110*80*74cm White

ODK L-Shaped Gaming/Computer Desk Instruction Manual

Model: 110*80*74cm White

Brand: ODK

1. INTRODUCTION

Thank you for purchasing the ODK L-Shaped Gaming/Computer Desk. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.

This versatile L-shaped desk is designed to optimize your workspace, whether for gaming, remote work, or study. It features an integrated shelf for storage, a monitor stand, a headphone hook, and adjustable feet for stability on uneven surfaces.

2. SAFETY INFORMATION

- Always follow the assembly instructions precisely to ensure structural integrity.
- Do not exceed the maximum load capacities: Tabletop 60kg, Shelf 25kg.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Place the desk on a level surface. Use the adjustable feet to compensate for minor unevenness.
- Avoid placing hot items directly on the desk surface without protection.
- The desk's filleted design is for safety; however, exercise caution to prevent impacts.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop sections (L-shaped)

- Leg frames (metal)
- Shelf panels
- Monitor stand
- Headphone hook
- Adjustable feet
- Assembly hardware (screws, bolts, Allen wrench)
- Instruction manual

4. SETUP AND ASSEMBLY

Assembly is designed to be straightforward. It is recommended to have a second person assist with certain steps for easier handling. Please refer to the detailed diagrams in the included instruction manual for specific part identification and orientation.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Identify each part using the provided parts list and diagrams.
2. **Assemble Leg Frames:** Attach the horizontal support bars to the vertical leg frames using the provided screws. Ensure all connections are finger-tight at this stage.
3. **Attach Tabletop Sections:** Secure the L-shaped tabletop sections to the assembled leg frames. Align the pre-drilled holes and insert the screws.
4. **Install Shelves:** Insert the shelf panels into the designated slots on the leg frames. The shelf height can be adjusted to accommodate different items. Secure them with the appropriate fasteners.
5. **Attach Monitor Stand and Headphone Hook:** Place the monitor stand on the designated area of the tabletop. Attach the headphone hook to the side of the desk frame as desired.
6. **Tighten All Fasteners:** Once all components are in place, systematically tighten all screws and bolts using the provided Allen wrench. Do not overtighten.
7. **Adjust Feet:** Turn the adjustable feet at the bottom of the desk legs to level the desk and prevent wobbling.

組立簡単&耐久性高い

※「右棚仕様」左側には棚板をつけることができませんので
ご注意ください




Figure 4.1: Desk dimensions and load capacities. The tabletop supports up to 60kg, and each shelf supports up to 25kg.




Figure 4.2: The integrated shelves can be adjusted in height to suit your storage needs, allowing for flexible organization of books and documents.



Figure 4.3: Adjustable feet ensure the desk remains stable and level, even on slightly uneven floors, preventing wobbling.

5. OPERATING INSTRUCTIONS

The ODK L-Shaped Desk is designed for versatile use in various environments.

- **Workspace Utilization:** The L-shaped design maximizes corner space, providing ample room for multiple monitors, a keyboard, mouse, and other peripherals.
- **Integrated Storage:** Use the built-in shelves to store books, documents, computer towers, or other office supplies, keeping your main desktop clear and organized.
- **Monitor Stand:** The elevated monitor stand helps raise your screen to an ergonomic eye level, improving posture and reducing neck strain during long work or gaming sessions.
- **Headphone Hook:** Utilize the convenient headphone hook to keep your headphones easily accessible and off the desk surface.



Figure 5.1: The ODK L-shaped desk provides a spacious and organized setup for both work and gaming, accommodating multiple devices and accessories.



Figure 5.2: This image shows the desk integrated into a gaming room, highlighting its suitability for immersive gaming setups with ample space for equipment.

OK 頑丈な構造&安定性抜群

クロス補強金具でグラつきを防止し、脚にはアジャスター付きで、多少凹凸がある場所でも水平に設置できます



Figure 5.3: The desk is shown in an office environment, demonstrating its functionality as a professional workstation with space for a printer and other office essentials.



Figure 5.4: The ODK L-shaped desk is highly adaptable and can be effectively used in various settings, including living rooms, bedrooms, dedicated gaming rooms, and professional offices.

6. MAINTENANCE

Proper care will extend the life and appearance of your ODK desk.

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. For stubborn marks, use a mild soap solution and then wipe dry immediately. Avoid abrasive cleaners or harsh chemicals, as they can damage the melamine finish.
- **Spills:** Immediately wipe up any liquid spills to prevent water damage or staining.
- **Heat Protection:** Use coasters or heat-resistant pads under hot beverages or dishes to protect the surface from heat marks.
- **Scratch Prevention:** While the surface is scratch-resistant, avoid dragging sharp or heavy objects across it. Use desk mats for keyboards and mice if desired.
- **Fastener Check:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability.



Figure 6.1: The high-strength melamine laminated board surface is resistant to scratches, heat, and moisture, making it easy to clean and maintain.

7. TROUBLESHOOTING

If you encounter any issues with your ODK desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk wobbles or is unstable.	Uneven floor; loose fasteners.	Adjust the leveling feet at the bottom of the legs. Ensure all assembly screws are securely tightened.
Parts do not align during assembly.	Incorrect orientation of parts; screws not fully loosened.	Review the assembly diagrams carefully. Loosen all screws slightly, adjust alignment, then re-tighten.

Problem	Possible Cause	Solution
Missing or damaged parts.	Packaging error; shipping damage.	Do not proceed with assembly. Contact ODK customer support immediately for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Model	ODK L-Shaped Gaming/Computer Desk
Dimensions (L x W x H)	Approx. 110 cm x 80 cm x 74 cm (43.3 x 31.5 x 29.1 inches)
Weight	Approx. 14.5 kg (32 lbs)
Material	High-strength Melamine Laminated Board, Steel Frame
Color	White
Tabletop Load Capacity	60 kg (132 lbs)
Shelf Load Capacity	25 kg (55 lbs) per shelf
Features	L-shaped design, Integrated storage rack, Monitor stand, Headphone hook, Adjustable leveling feet, Filleted tabletop edges
Assembly Required	Yes (Customer Assembly)

9. WARRANTY AND SUPPORT

ODK is committed to providing high-quality products and services. In the unlikely event of an initial defect with your purchased product, please feel free to contact us at any time. Our dedicated team is ready to assist you.

For support inquiries, please refer to the contact information provided with your purchase or visit the official ODK store on Amazon.



Figure 9.1: ODK Brand Logo.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question