Azwok AU-6711A90032L-LG005

User Manual for Azwok Replacement Remote Control

Model: AU-6711A90032L-LG005

Introduction

This manual provides comprehensive instructions for the use and maintenance of your Azwok Replacement Remote Control, model AU-6711A90032L-LG005. This remote is designed as a direct replacement for various LG Air Conditioner remote models, including 6711A90032L, 6711A20091H, 6711A90031Y, 6711A20073V, 6711A20096C, 6711A90032N, 6711A20128B, 6711A20091G, 6711A90032Y, 6711A90031E, and many others. It replicates the primary functions of the original remote without requiring any programming.

Product Overview



Figure 1: Front view of the Azwok replacement remote control, showing the display screen and primary function buttons.



Figure 2: Angled view of the remote control, highlighting its ergonomic design.



Figure 3: Front view of the remote control with the extended function panel open, revealing additional control buttons.

Setup

1. Battery Installation

The remote control requires two (2) AAA batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.

3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 4: Illustration of correct battery insertion into the remote control's battery compartment.

2. Initial Use

No programming is required for this replacement remote control. Once batteries are installed, it is ready for immediate use with compatible LG Air Conditioner models.

Operating Instructions

This remote control functions identically to the original LG Air Conditioner remote. Point the remote control directly at the air conditioner's receiver when operating.

Common Functions:

- **Power Button:** Turns the air conditioner ON or OFF.
- **Mode Button:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **Temperature Adjustment Buttons (Up/Down Arrows):** Increases or decreases the desired temperature setting.
- **Fan Speed Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Swing Button:** Controls the louver swing function.
- **Timer Button:** Sets the ON/OFF timer for the air conditioner.
- **Sleep Mode Button:** Activates or deactivates sleep mode for quiet operation and energy saving.
- **Plasma/Air Purify Button:** Activates the air purification function (if available on your AC model).

Refer to your LG Air Conditioner's original user manual for detailed explanations of specific functions and advanced

settings.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote.
- **Battery Replacement:** Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage. Store in a cool, dry place away from direct sunlight.
- **Avoid Drops:** Protect the remote control from physical impact. Dropping it can damage internal components.

Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA batteries, ensuring correct polarity (+/-).
Remote control works intermittently.	Weak batteries or obstruction between remote and AC unit.	Replace batteries. Ensure a clear line of sight to the air conditioner's receiver.
Specific buttons not responding.	Button malfunction or AC unit does not support the function.	Check if your specific LG AC model supports the function. If not, the button may be inactive. If the function is supported, the remote may be faulty.
Air conditioner does not respond to remote.	AC unit is off, power issue, or remote is incompatible.	Ensure the AC unit is powered on. Verify the remote's compatibility with your specific LG AC model (refer to the list of compatible models in the introduction).

If troubleshooting steps do not resolve the issue, please contact customer support.

Specifications

- **Model:** AU-6711A90032L-LG005
- **Compatible with:** LG Air Conditioners (models including 6711A90032L, 6711A20091H, 6711A90031Y, 6711A20073V, 6711A20096C, 6711A20091G, 6711A20048G, and many others)
- **Power Source:** 2 x AAA Batteries (not included)
- **Connectivity Technology:** Infrared (IR)
- **Dimensions:** 5.31 x 1.85 x 0.79 inches (13.5 x 4.7 x 2.0 cm)
- **Weight:** 2.11 ounces (60 grams)
- **Special Feature:** No Programming Required

Warranty and Support

Warranty Information

This Azwok replacement remote control comes with a**12-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as described. If the product fails due to a manufacturing defect within this period, it will be replaced or refunded.
The warranty does not cover damage caused by misuse, accidental damage, unauthorized repairs, or normal wear and tear, including battery leakage.

Customer Support

For any questions, concerns, or technical assistance regarding your Azwok replacement remote control, please contact our customer support team. If your specific LG Air Conditioner model is not listed as compatible or if you are unsure about compatibility, please reach out to us for verification before purchase.
Contact information is typically available through your point of purchase or on the manufacturer's official website. Please have your product model number (AU-6711A90032L-LG005) and purchase details ready when contacting support.

© 2025 Azwok. All rights reserved.
LG is a registered trademark of LG Corp. This product is a compatible replacement and not manufactured by LG.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question