

SOOPYK WB001

SOOPYK Water Cooler Dispenser Bottle Base (Model WB001) Instruction Manual

Model: WB001

INTRODUCTION

This manual provides instructions for the proper installation, operation, and maintenance of your SOOPYK Water Cooler Dispenser Bottle Base, Model WB001. This replacement part is designed to provide a spill-proof connection for 5-gallon water bottles on compatible water dispensers. Please read this manual thoroughly before use to ensure safe and efficient operation.

SAFETY INFORMATION

- Ensure the water dispenser is unplugged from the power outlet before installing or removing the bottle base.
- Handle the bottle base carefully to avoid damage.
- Keep out of reach of children.
- This product is intended for use with standard 5-gallon water bottles and compatible water dispensers. Do not attempt to use with other bottle sizes or incompatible dispensers.
- Regularly inspect the bottle base for any signs of wear or damage. Replace if necessary.

PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x SOOPYK Water Cooler Dispenser Bottle Base (Model WB001)



Image: The SOOPYK Water Cooler Dispenser Bottle Base, Model WB001, shown inside its cardboard packaging.



Image: The retail cardboard box for the SOOPYK Water Cooler Dispenser Bottle Base, indicating "Anti-leakage bottle collar" and "Color: White".

SETUP AND INSTALLATION

Follow these steps to install the SOOPYK Water Cooler Dispenser Bottle Base:

1. **Unplug the Dispenser:** Before beginning, ensure your water cooler dispenser is unplugged from the electrical outlet to prevent any accidental operation.
2. **Remove Old Base (if applicable):** If replacing an existing bottle base, carefully lift and remove the old base from the top of the water dispenser.
3. **Position the New Base:** Place the SOOPYK Water Cooler Dispenser Bottle Base onto the top opening of your water dispenser. Ensure it sits securely and is properly aligned. The base is designed to fit many standard water dispenser models.
4. **Verify Fit:** Gently press down on the base to confirm it is seated firmly. The design includes pins that help secure the bottle and prevent spills.



Image: Top-down view of the SOOPYK Water Cooler Dispenser Bottle Base, showing the four metal pins and central water inlet.



Image: Side profile of the SOOPYK Water Cooler Dispenser Bottle Base, illustrating its funnel-like shape.



Image: The SOOPYK Water Cooler Dispenser Bottle Base correctly installed on the top of a water cooler dispenser.

OPERATION

Once the bottle base is installed, you can place a 5-gallon water bottle onto the dispenser:

1. **Prepare Bottle:** Ensure the 5-gallon water bottle is clean and free of debris. Remove any protective seals or caps from the bottle's opening.
2. **Place Bottle:** Carefully lift the 5-gallon water bottle and invert it, placing its neck into the opening of the installed SOOPYK bottle base. The pins in the base will engage with the bottle's opening, creating a spill-proof seal.
3. **Secure Bottle:** Gently push the bottle down until it is firmly seated in the base. You should hear or feel the water beginning to fill the dispenser's reservoir.
4. **Plug In Dispenser:** Once the bottle is securely in place and water is flowing into the reservoir, you may plug the water cooler dispenser back into the electrical outlet.

Your browser does not support the video tag.

Video: A brief demonstration of the SOOPYK Water Cooler Dispenser Bottle Base, showcasing its design and components from various angles. This video helps visualize the product's structure.

MAINTENANCE AND CLEANING

Regular cleaning of the bottle base is recommended to maintain hygiene and ensure optimal performance.

1. **Remove Bottle and Unplug:** First, remove the water bottle and unplug the water cooler dispenser from the power outlet.
2. **Remove Base:** Carefully lift the SOOPYK bottle base from the dispenser.
3. **Wash:** Wash the bottle base with warm, soapy water. Use a soft brush or sponge to clean all surfaces, especially around the pins and water inlet.
4. **Rinse:** Rinse thoroughly with clean water to remove all soap residue.
5. **Dry:** Allow the bottle base to air dry completely before re-installing it on the dispenser.
6. **Frequency:** Clean the bottle base every time you replace a water bottle, or at least once a month, to prevent mineral buildup and bacterial growth.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Water leaks when bottle is placed.	Bottle not seated correctly; damaged bottle cap; damaged bottle base.	Remove bottle and re-seat firmly. Check bottle cap for damage. Inspect bottle base for cracks or deformities; replace if damaged.
Water not flowing into dispenser.	Bottle not fully pierced by pins; airlock in bottle; dispenser reservoir full.	Ensure bottle is pushed down completely onto the pins. Lift and re-seat the bottle to break any airlock. Check if the dispenser's reservoir is already full.
Base does not fit dispenser.	Incompatible dispenser model.	Verify your water dispenser model is compatible with a standard 5-gallon bottle base.

SPECIFICATIONS

- **Model:** WB001
- **Brand:** SOOPYK
- **Material:** Acrylonitrile Butadiene Styrene (ABS)

- **Color:** White (Note: Product title and images indicate white, despite a specification listing black.)
- **Capacity:** Designed for 5-Gallon water bottles
- **Installation Type:** Freestanding (on top of dispenser)
- **Included:** 1x Water Bottle Base




Image: Top-down view of the SOOPYK Water Cooler Dispenser Bottle Base with key dimensions indicated: 7.7 inches outer diameter and 6.1 inches inner diameter.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact SOOPYK customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

Manufacturer: SOOPYK

ASIN: B0BPPQSHTB