

Robo Alive Robo Turtle ZUR07191

Robo Alive Robo Turtle Series 1 Instruction Manual

Model: Robo Turtle ZUR07191

1. INTRODUCTION

The Robo Alive Robo Turtle Series 1 brings a realistic robotic pet experience to life. Designed to move both on land and in water, these tropical turtles feature advanced robotic technology. They are water-activated, meaning they come to life when placed in water, and can also crawl on land. There are four vibrant colors to collect, allowing for a complete Robo Aquarium experience.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

- Recommended for ages 3 years and above.
- Adult supervision is recommended during play, especially when used in water.
- Do not attempt to open the battery compartment or replace batteries. Batteries are pre-installed and sealed.
- Ensure the toy is dry before storing to prevent damage.

3. WHAT'S IN THE BOX

- 1 x Robo Turtle
- 1 x Instruction Manual



Image: A blue Robo Alive Robo Turtle in its clear plastic packaging, indicating "I Swim & Walk Like a Real Turtle!" and "Ages 3+".

4. SETUP

Your Robo Turtle comes with pre-installed batteries and is ready for immediate play. No assembly or battery installation is required by the user.

1. Carefully remove the Robo Turtle from its packaging.
2. Ensure the turtle is dry before its first use in water.

5. OPERATING INSTRUCTIONS

Water Activation:

The Robo Turtle is equipped with advanced water-activated technology. To activate its swimming motion:

- Gently place the Robo Turtle into water.

- The turtle will automatically begin to swim in various directions (up to 5 different directions).
- To stop the swimming action, simply remove the turtle from the water. It will automatically power off when dry.

Land Movement:

The Robo Turtle can also crawl on land. Place it on a flat, dry surface to observe its land-based movements.



Image: A green Robo Alive Robo Turtle with a yellow and brown shell pattern, shown crawling on a white surface, demonstrating its land movement capability.



Image: Four Robo Alive Robo Turtles (pink, red, blue, green) swimming in a clear glass bowl, showcasing their water-activated movement and variety of colors.

6. MAINTENANCE

- After each use in water, gently shake off excess water and wipe the Robo Turtle dry with a soft cloth.
- Store the toy in a dry place away from direct sunlight and extreme temperatures.
- Do not use harsh chemicals or abrasive cleaners on the toy.

7. TROUBLESHOOTING

Problem	Solution
Robo Turtle does not move in water.	Ensure the water level is sufficient to fully immerse the turtle and activate its sensors. Check for any debris obstructing the movement of its fins.

Problem	Solution
Movement is sluggish or inconsistent.	This may indicate low battery power. While batteries are sealed, prolonged use will eventually deplete them. Consider replacing the unit if performance significantly degrades.
Robo Turtle does not stop moving when removed from water.	Ensure the turtle is completely dry. Water remaining on the sensors can keep it active. Wipe thoroughly.

8. SPECIFICATIONS

- **Brand:** Robo Alive (Zuru)
- **Model Name:** Robo Turtle
- **Model Number:** ZUR07191
- **Material:** Plastic
- **Operation Mode:** Automatic, Water-activated
- **Movement:** Swims in 5 directions, Walks on land
- **Power Source:** Batteries (pre-installed, non-replaceable)
- **Age Range:** 3 years and above
- **Item Weight:** 2.4 ounces
- **Item Dimensions:** 11.81 x 11.81 x 11.81 inches (packaging dimensions, actual product size is smaller)

9. WARRANTY AND SUPPORT

For any questions regarding your Robo Alive Robo Turtle, please refer to the contact information provided on the product packaging or visit the official Zuru website for customer support details. Specific warranty information may vary by region and retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question