azwok AU-ATV55UHD-BA003

azwok Replacement Remote Control for ATV55UHD Series Smart TVs - User Manual

Brand: azwok | **Model:** AU-ATV55UHD-BA003

Introduction

This manual provides instructions for the azwok replacement remote control, designed for various Smart TV models including Bauhn, Kogan, JVC, Linsar, CHIQ, Saba, and Changhong. It is specifically compatible with ATV55UHD series and models such as RM-C3348, RM-C3227, GCBLTV9MU, RCKGNTVT001, and ATV55UHDS-0519. This remote control is ready to use without any programming required; simply insert batteries, and it will function immediately.

Setup

1. Battery Installation

To begin using your remote control, you must install two AAA batteries (not included). Follow these steps:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover off.
3. Insert two new AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Figure 1: Rear view of the remote control with the battery compartment open, illustrating the correct placement for two AAA batteries.

Once batteries are installed, the remote is ready for use with compatible televisions.

Operation

This remote control provides full functionality for your compatible Smart TV. Point the remote directly at your television's infrared receiver for optimal performance.





Figure 2: Front view of the azwok replacement remote control, showing the layout of all buttons.

Button Functions

Button	Function
Power (Red)	Turns the TV on or off.
Mute	Mutes or unmutes the TV audio.
0-9 (Number Pad)	Direct channel selection and input.
INFO	Displays program information.
AUDIO (I/II)	Selects audio language or mode.
Colored Buttons (Red, Green, Yellow, Blue)	Context-sensitive functions, often used for teletext or smart TV features.
Q.MENU	Accesses quick menu options.
Navigation Arrows (Up, Down, Left, Right)	Navigates through menus and options.
OK	Confirms selections.
Back / **Exit**	Returns to the previous screen or exits a menu.
Settings (Gear icon)	Opens the TV settings menu.
EPG	Accesses the Electronic Program Guide.
LIST	Displays channel list or other lists.
SOURCE	Selects input source (HDMI, AV, etc.).
Home (House icon)	Returns to the Smart TV home screen.
Volume Up (+) / **Down (-)**	Adjusts the TV volume.
Channel Up (P^) / **Down (Pˇ)**	Changes TV channels.
Netflix	Direct access to the Netflix application.
YouTube	Direct access to the YouTube application.

Button	Function
Media Playback Controls	Play, Pause, Stop, Fast Forward, Rewind, Skip.

Maintenance

Cleaning

To maintain the remote control's functionality and appearance:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Do not use harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's finish or internal components.

Storage

When not in use for extended periods, remove the batteries to prevent leakage, which can damage the remote. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

If you experience issues with your remote control, please refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Remote is not responding.	• Check if the batteries are inserted correctly with the correct polarity. • Replace old or depleted batteries with new AAA batteries. • Ensure there is a clear line of sight between the remote and the TV's infrared sensor. Remove any obstructions. • Confirm the remote is pointed directly at the TV.
Some buttons are not working.	• This remote is a replacement and may not support all advanced functions of your original TV remote if they are unique to the original. • Ensure the TV is in the correct mode (e.g., Smart TV mode for Netflix/YouTube buttons). • Clean the remote's surface and buttons to ensure no debris is interfering with button presses.
Remote does not work with my TV model.	• Verify your TV model number against the compatibility list in this manual. • If your model is not listed or you are unsure, please contact customer support for assistance.

Specifications

Feature	Detail

Feature	Detail
Brand	azwok
Model Number	AU-ATV55UHD-BA003
Connectivity Technology	Infrared
Special Feature	No programming required
Compatible Devices	Television
Maximum Number of Supported Devices	1
Number of Buttons	45
Controller Type	Button Control
Maximum Range	10 Meters
Batteries Required	2 x AAA (Alkaline recommended)
Rechargeable Battery	No

Compatible TV Models

This azwok replacement remote control is compatible with a wide range of Smart TV models from various brands. Below is a list of known compatible models:

- **Brands:** Bauhn, Kogan, JVC, Linsar, CHIQ, Saba, Changhong
- **Series:** ATV55UHD, ATV65UHD
- **Specific Models:**
  - ATV55UHDS-0519, ATV40FHDS-0320, ATV32HDS-0420, ATV65UHDS-0319, ATV50UHDS-1019, ATV40FHDS-0720, ATV40FHDS-0819
  - LT-40N5105A, LT-32N3105A, LT-32N3105AC, LT40N5105A, LT32N3105A, LT32N3105AC
  - KALED40AF7000STA, AF7000
  - LS58UHDSM20, LED32HS71N1, U58G7N, L32H7L/N, U43H7L/N, U50H7L/N, U55H7L/N, L32G7N, L40G7N
  - SA32S48N1, S49N1, SB32HDS193LCES, B32G7 N-ESiT, SA24S45N1, SA32S49N1
  - GCBL-TV9MU, GCBLTV9MU
  - RM-C3348, RM-C3354, RM-C3349, RM-C3227B
  - LT-58KB585, LT-50KB585

If your specific TV model is not listed, or if your original remote control differs significantly in appearance, please contact customer support to confirm compatibility before purchase.

Warranty and Returns

This product comes with a**12-month replacement guarantee** from the date of purchase. If the remote control fails to function with your compatible device within this period, you are eligible for a replacement or refund. Additionally, returns are accepted for refund or exchange within**31 days** of receipt if the product does not meet your expectations or is found to be defective. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions regarding product compatibility, troubleshooting, or warranty claims, please contact our customer support team. We are committed to assisting you in finding the correct remote control and resolving any issues you may encounter.

Seller: HeeTech-EU

Please refer to your purchase platform for direct contact methods with the seller.

© 2023 azwok. All rights reserved.