Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok AU-RAR-3U4-HT001

Azwok Replacement RAR-3U4 Remote Control User Manual

For Hitachi Air Conditioners

Introduction

This manual provides instructions for the Azwok Replacement RAR-3U4 Remote Control, designed for use with various Hitachi Air Conditioner models. This remote control offers the primary functions of the original unit without requiring any programming.

Setup: Battery Installation

To begin using your remote control, you must install two AAA batteries (not included). Follow these steps:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: The back of the Azwok Replacement RAR-3U4 Remote Control with the battery compartment open, illustrating where to insert two AAA batteries.

The remote control is ready for use immediately after battery installation; no programming is required.

Operating Instructions

This remote control provides essential functions for your Hitachi Air Conditioner. Point the remote control directly at the air conditioner unit when operating.





Image: Front view of the Azwok Replacement RAR-3U4 Remote Control, displaying the LCD screen, power button, fan speed, mode, and temperature adjustment buttons.

Main Buttons and Functions:

- **Power Button (⏻)**: Press to turn the air conditioner ON or OFF.
- **Fan Speed Button (☻)**: Adjusts the fan speed. Multiple presses cycle through available fan speed settings.
- **Mode Button (➡)**: Changes the operating mode of the air conditioner (e.g., Cool, Dry, Fan, Heat, Auto).
- **Temperature Adjustment Buttons (°C)**: Use these buttons to increase or decrease the desired temperature setting.
- **Favorite/Star Button (★)**: This button may activate a pre-set favorite mode or function, depending on your air conditioner model.

Hidden Functions (Under Cover):

Some advanced functions are located under a sliding cover on the remote control. Slide the cover down to reveal these buttons.



Image: The Azwok Replacement RAR-3U4 Remote Control with its lower sliding cover open, showing additional buttons for functions like timer, swing, and a reset button.

- Specific functions under the cover may include Timer settings, Swing control, Sleep mode, and other advanced options. Refer to your air conditioner's original manual for detailed explanations of these functions.
- **Reset Button**: A small recessed button labeled "RESET" is available. If the remote control experiences abnormal operation, press this button using a pointed object (like a pen tip) to reset it.

Compatibility

This Azwok Replacement RAR-3U4 Remote Control is compatible with a range of Hitachi Air Conditioner models, including but not limited to:

- RAR-3U1
- RAR-3U3
- RAR-2A1
- RAR-52P1
- RAR-2SP1
- RAR-2P2
- RAR-52P2
- RAR-2P1
- RAS-80YHA
- RAR-3V2
- RAS-25YHA3
- RAS-35YHA3
- RAS-50YHA3

If your specific air conditioner model is not listed, or if your original remote control differs significantly in appearance, please contact customer support to confirm compatibility.

Maintenance

- **Battery Replacement**: Replace batteries when the remote's display becomes dim or the remote becomes unresponsive. Always replace both batteries simultaneously with new ones. Do not mix old and new batteries, or different types of batteries.
- **Cleaning**: Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the unit.

Troubleshooting

- **Remote Not Responding**:
  - Ensure batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Point the remote directly at the air conditioner's receiver.
  - Ensure there are no obstructions between the remote and the air conditioner.
- **Display Issues**: If the remote's display is dim or shows incorrect information, replace the batteries. If the issue persists or if the remote operates abnormally, press the recessed "RESET" button using a pointed object.
- **Air Conditioner Not Responding**: If the air conditioner unit does not respond to the remote, and the remote itself appears to be functioning (e.g., display is active), verify that the air conditioner unit is powered on and functioning correctly.

Specifications

Model Number	AU-RAR-3U4-HT001
Product Dimensions	5.71 x 2.17 x 0.59 inches
Item Weight	2.82 ounces
Batteries Required	2 x AAA (not included)
Connectivity Technology	Infrared
Compatible Devices	Air Conditioner

Warranty and Support

This Azwok replacement remote control comes with a 12-month replacement warranty from the date of purchase. If you encounter any issues or have questions regarding compatibility or functionality, please contact Azwok customer support for assistance.

For support, please refer to the contact information provided with your purchase or visit the Azwok official website.

© 2023 Azwok. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BPR4TJSP

More documents and user manuals: **https://manuals.plus/**