

[Manuals.plus](#) /

> [GGM Gastro](#) /

> GGM Gastro EHK500-R Oven Rack Instruction Manual

## GGM Gastro EHK500-R

# GGM Gastro EHK500-R Oven Rack Instruction Manual

Model: EHK500-R

## 1. INTRODUCTION

---

This manual provides essential information for the safe and effective use of your GGM Gastro EHK500-R Oven Rack. Please read these instructions carefully before installation and use, and retain them for future reference. This oven rack is designed for use with the GGM Gastro EHK500 oven model.

The GGM Gastro EHK500-R oven rack is a durable, chrome-plated support grid, resistant to wear and heat. It is designed for optimal baking results and easy removal. The material complies with European food standards and bears the CE mark, ensuring adherence to hygiene and safety directives.

## 2. SAFETY INSTRUCTIONS

---

- Always handle the oven rack with oven mitts or heat-resistant gloves, especially when the oven is hot.
- Ensure the oven rack is correctly positioned within the oven before heating.
- Do not overload the oven rack; refer to your oven's manual for maximum weight capacity.
- Avoid sudden temperature changes, which can cause warping or damage.
- Keep out of reach of children when not in use or when hot.
- Inspect the rack for any damage before each use. Do not use if bent or broken.

## 3. SETUP AND INSTALLATION

---

The GGM Gastro EHK500-R oven rack is designed for simple installation into compatible GGM Gastro EHK500 ovens.

1. Ensure the oven is turned off and completely cool before installing or removing the rack.
2. Open the oven door fully.
3. Carefully slide the oven rack into the desired rack guides within the oven cavity. Ensure it is fully seated and stable.
4. Close the oven door.




Image 1: GGM Gastro EHK500-R Oven Rack with indicated dimensions (352mm width, 322mm depth). This image shows the overall shape and size of the rack, highlighting its compatibility with the EHK500 oven.

## 4. OPERATING INSTRUCTIONS

---

Using the GGM Gastro EHK500-R oven rack is straightforward. Always refer to your oven's specific operating manual for detailed instructions on oven usage.

1. Place your bakeware or food directly onto the oven rack.
2. Ensure proper air circulation around the food for even cooking.
3. When removing items from the oven, always use appropriate heat protection.
4. The rack's chrome-plated surface is designed for optimal heat distribution and easy food release.

## 5. CLEANING AND MAINTENANCE

---

Regular cleaning and proper maintenance will extend the lifespan of your GGM Gastro EHK500-R oven rack.

- **Cleaning:**

- Allow the oven rack to cool completely before cleaning.
- Wash the rack with warm, soapy water and a non-abrasive sponge or cloth.
- For stubborn food residues, soak the rack in warm, soapy water for a period before scrubbing.
- Rinse thoroughly with clean water and dry completely to prevent water spots or rust.
- Avoid using harsh chemicals, abrasive cleaners, or metal scouring pads, as these can damage the chrome plating.

- **Storage:** Store the clean, dry oven rack in a safe place to prevent bending or damage.

- **Inspection:** Periodically inspect the rack for any signs of wear, corrosion, or damage.




Image 2: Top view of the GGM Gastro EHK500-R Oven Rack. This image provides a clear view of the rack's chrome-plated surface and grid design, emphasizing its clean and ready-to-use condition.

## 6. TROUBLESHOOTING

---

This section addresses common issues you might encounter with your oven rack.

Problem	Possible Cause	Solution
Rack does not slide smoothly.	Food debris or grease buildup on rack or oven guides.	Clean the oven rack and oven rack guides thoroughly. Ensure no obstructions are present.
Rack appears discolored or stained.	Baked-on food residue or exposure to high heat over time.	Soak the rack in warm, soapy water. Use a non-abrasive cleaner. Discoloration from prolonged high heat is normal and does not affect performance.
Rack is bent or warped.	Overloading or accidental impact.	If severely bent, the rack may need to be replaced. Avoid overloading and dropping the rack.

## 7. SPECIFICATIONS

---

- **Model:** EHK500-R
- **Compatibility:** GGM Gastro EHK500 Oven
- **Dimensions (L x W x H):** 35.2 cm x 32.2 cm x 3.1 cm (13.86 in x 12.68 in x 1.22 in)
- **Weight:** 414 grams (0.91 lbs)
- **Material:** Chrome-plated steel
- **Features:** Wear-resistant, heat-resistant, non-stick coating (inherent to chrome plating), easy to remove.
- **Compliance:** CE mark, European food standards.
- **ASIN:** B0BPR5M3P2

## 8. WARRANTY AND SUPPORT

---

Information regarding specific warranty terms for the GGM Gastro EHK500-R oven rack is not provided in the product details. For warranty claims, technical support, or to inquire about spare parts, please contact GGM Gastro customer service directly or refer to the documentation provided with your GGM Gastro EHK500 oven.

**Contact Information:** Please visit the official GGM Gastro website for the most up-to-date contact details and support resources.



© 2023 GGM Gastro. All rights reserved.

This manual is for informational purposes only. GGM Gastro reserves the right to make changes to products and specifications without prior notice.