

Azwok RM-QT1E-SQ003

Azwok Replacement QT1E Remote Control for Soniq TV User Manual

INTRODUCTION

This manual provides instructions for the Azwok Replacement QT1E Remote Control, designed for use with various Soniq TV models. This remote serves as a direct replacement for your original QT1E remote, offering all primary functions without the need for complex programming.

The remote is compatible with a wide range of Soniq TV models, including but not limited to: E24Z15B, E23Z13A-AU, E23Z15A-AU, E24Z15B-AU, E32V15B-AU, E32V15D-AU, E32V16B-AU, E32V17A-AU, E32V17B-AU, E32W13A-AU, E32W13B-AU, E32W13D-AU, E40V14A-AU, E40V14B-AU, E40V16A-AU, E40W13A-AU, E40W13C-AU, E42V14A-AU, E43V15B-AU, E43V15C-AU, E43V15D-AU, E48W13A-AU, L32V12B-AU, E24HZ17B-AU, E32HV18A-AU, E42FV16A-AU, E48FH16A-AU, E55FV16A-AU, S55UV16A-AU, S55UV16B-AU, S65UX16A-AU, E24Z15B-AU REV.A, E43V15C-AU REV.B, E32HV18A-AU REV.A, L42D11A, L47V12A, P51E12A, E55S14A, E55V12A, E55V13A, E55V14B, E32Z10A, E16Z11A-AU, E16Z11B-AU, E22Z11A-AU, E22Z11B-AU, E22Z11C-AU, E23Z11B-AU, E26Z11B-AU, E42Z10A-AU, E32Z10A-NZ, E40Z10A-NZ, E32Z10A-AU, E42Z10B-AU, L32V10A-AU, L32V11B-AU, L32V11C-AU, L32V10A-NZ, L42V11A-AU, L42V11C-AU, L47S10A, L47S10A-AU, L55S11A-AU, L60U11A-AU, QSL422XTV3-AU, QSP550TV2-AU, P50E11A-AU, E32S12A, E40S12A, E48S12A, E55S12A, E42S14A, E47S14A, E55S14A, U42V14B.

SETUP

The Azwok Replacement QT1E Remote Control is designed for immediate use with compatible Soniq TV models. No programming or pairing is required.

1. Install Batteries

To begin using your remote control, you must first install two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.







Image: Back of the remote control with the battery cover open, illustrating the correct placement of AAA batteries.

Once batteries are installed, the remote control is ready to operate your Soniq TV.

OPERATING INSTRUCTIONS

The Azwok Replacement QT1E Remote Control provides full functionality for your Soniq TV. The button layout is designed to mimic the original remote for intuitive use.



Image: Front view of the Azwok QT1E remote control, displaying its full button layout.

Basic Functions:

- **Power:** Press the **POWER** button to turn your TV on or off.
- **Volume Control:** Use the **VOL+** and **VOL-** buttons to adjust the sound level.
- **Channel Navigation:** Use the **CH+** and **CH-** buttons to change channels.

- **Mute:** Press the **MUTE** button to silence the TV audio.
- **Numeric Keypad:** Use the number buttons (0-9) to directly enter channel numbers.
- **Navigation and OK:** Use the directional arrows (**UP**, **DOWN**, **LEFT**, **RIGHT**) and the **OK** button to navigate menus and confirm selections.
- **Source/Input:** Press the **SOURCE** button to switch between different input sources (HDMI, AV, etc.).
- **Menu:** Press the **MENU** button to access the TV's main menu.

For advanced functions, refer to your Soniq TV's original user manual for specific button operations.

MAINTENANCE

Proper care and maintenance will ensure the longevity and optimal performance of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact. Dropping the remote can damage its internal circuitry.

TROUBLESHOOTING

If you encounter issues with your Azwok Replacement QT1E Remote Control, please refer to the following common solutions:

1. Remote is not responding:

- Ensure batteries are installed correctly with the correct polarity (+/-).
- Replace old batteries with new AAA batteries.
- Check for any obstructions between the remote control and the TV's infrared sensor.
- Confirm that the remote is pointed directly at the TV's sensor.

2. Remote functions are intermittent:

- This often indicates low battery power. Replace the batteries.
- Ensure there are no strong light sources (like direct sunlight or bright fluorescent lights) interfering with the infrared signal.

3. Remote does not work with your specific Soniq TV model:

- Verify that your TV model is listed in the "Introduction" section of this manual.
- If your model number is not listed, or if your original remote control looks significantly different from the QT1E, this replacement remote may not be compatible. Please contact customer support for assistance.

SPECIFICATIONS

Azwok Replacement QT1E Remote Control

Model Number	RM-QT1E-SQ003
Brand	Azwok
Compatible Devices	Soniq Televisions (QT1E series and listed models)
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Product Dimensions	8.27 x 1.97 x 0.79 inches (21 x 5 x 2 cm)
Item Weight	3.21 ounces (91 grams)
Special Feature	No Programming Required

WARRANTY AND SUPPORT

Your Azwok Replacement QT1E Remote Control comes with a commitment to quality and customer satisfaction.

Warranty Information

This remote control is covered by a **12-month replacement warranty** from the date of purchase. This warranty covers manufacturing defects and ensures that the remote functions as intended with compatible devices.

Returns are accepted for refund or exchange if the product does not work with your specified devices, provided it is within the return policy period (typically 30 days from purchase, but please verify with your retailer).

Customer Support

If you have questions regarding compatibility, require assistance with troubleshooting, or need to make a warranty claim, please contact Azwok customer support.

Note: If your TV model number is not explicitly listed in this manual, or if your original remote control differs significantly from the QT1E model, please contact us to confirm suitability before purchase or for troubleshooting assistance. We are available to help you find the correct remote control for your device.