HNARL 203990000010

Sinoboom Circuit Board 203990000010 Instruction Manual


Model: 203990000010 | Brand: HNARL

Product Overview


This manual provides essential information for the installation, operation, and maintenance of the Sinoboom Circuit Board, Part Number 203990000010. This circuit board is a critical component designed for use in various Sinoboom scissor lift models.

Applicable Models:


- 0407SE (1330SE)
- 0608E (2132E)
- 0608SE/ME (1930SE/1932ME)
- 0612E (2146E)
- 0808E (2732E)
- 1012E (3346E)
- 1212E (4047E)
- 1412E (4647E)
- 1414E (4655E)
- 0608 (2132)
- 0608S/M (1930S/1932M)
- 0612 (2146)
- 0808 (2732)
- 0812 (2746)
- 1012 (3346)
- 1212 (4047)
- 1412 (4647)
- 1414 (4655)



Front view of the circuit board, featuring a digital display and four green-lit control buttons. This side is typically exposed for user interaction and status monitoring.



Rear view of the circuit board, displaying the main processor chip, various resistors, capacitors, and multiple connectors for integration into the scissor lift's electrical system.



An angled perspective of the circuit board's front, providing a clearer view of the button layout and the digital display module.

Setup and Installation

Installation of the Sinoboom Circuit Board 203990000010 should only be performed by qualified personnel. Ensure the scissor lift's power is completely disconnected before beginning any installation procedures.

1. **Safety First:** Disconnect all power sources to the scissor lift and engage lockout/tagout procedures to prevent accidental startup.
2. **Access Panel:** Locate and open the control panel or housing where the existing circuit board is installed. Refer to your specific scissor lift model's service manual for exact location.
3. **Disconnect Wiring:** Carefully label and disconnect all wiring harnesses and connectors from the old circuit board. Take photographs for reference if necessary.
4. **Remove Old Board:** Unscrew or unclip the old circuit board from its mounting points.
5. **Install New Board:** Position the new Sinoboom Circuit Board 203990000010 in the designated slot. Secure it using

the original screws or clips.

6. **Reconnect Wiring:** Reconnect all wiring harnesses and connectors to the new board, ensuring each connection matches the labels or photographs taken in step 3. Verify all connections are secure and properly seated.
7. **Close Panel:** Close and secure the control panel or housing.
8. **Initial Power-Up:** Reconnect power to the scissor lift. Observe the circuit board's display and indicators for proper function.
9. **Functionality Test:** Perform a comprehensive test of all functions controlled by the circuit board according to the scissor lift's operational manual.

Important: *Improper installation can lead to equipment malfunction or personal injury. If unsure, consult a certified technician.*

Operating Instructions

The circuit board primarily acts as a control interface and processing unit within the scissor lift system. Its operation is integrated with the lift's main control system. Direct user interaction with the board itself is typically limited to observing status indicators and, in some cases, performing diagnostic checks via the integrated display.

- **Status Display:** The digital display on the board (if present and active) may show error codes, operational status, or diagnostic information. Refer to the scissor lift's main operational manual for interpretation of these codes.
- **Control Buttons:** The four green-lit buttons on the board are generally for diagnostic purposes or specific system resets, not for routine operation of the lift. Their specific functions are detailed in the lift's service manual.
- **System Integration:** The circuit board processes signals from joysticks, sensors, and other input devices, translating them into commands for the lift's motors and hydraulic systems.

For detailed operational procedures of the scissor lift, refer to the complete user manual provided with your Sinoboom equipment.

Maintenance

The Sinoboom Circuit Board 203990000010 is designed for durability and minimal maintenance. However, regular inspection of the surrounding environment and connections is recommended.

- **Visual Inspection:** Periodically inspect the board for any signs of physical damage, corrosion, loose connections, or excessive dust accumulation.
- **Cleaning:** If dust or debris is present, gently clean the board using compressed air or a soft, dry brush*Do not use liquids or abrasive cleaners.*
- **Connection Integrity:** Ensure all connectors and wiring harnesses remain firmly seated and free from strain.
- **Environmental Control:** Protect the circuit board from extreme temperatures, humidity, and direct exposure to water or corrosive substances.

Any repairs or component replacements on the circuit board itself should only be performed by authorized service technicians.

Troubleshooting

This section provides general troubleshooting steps for issues potentially related to the circuit board. For specific error codes or complex issues, consult the scissor lift's service manual or contact technical support.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No power to the board/display off	Loose connection, power supply issue, blown fuse	Check all power connections. Verify power supply to the lift. Inspect relevant fuses in the lift's electrical system.
Incorrect display readings/Error codes	Sensor malfunction, wiring issue, board fault	Refer to the scissor lift's service manual for specific error code interpretations. Check sensor connections. If issue persists, board may require professional diagnosis.
Intermittent operation of lift functions	Loose wiring, faulty input signal, environmental interference	Inspect all wiring harnesses connected to the board for looseness or damage. Ensure the operating environment is stable.

If troubleshooting steps do not resolve the issue, contact HNARL customer support or a certified Sinoboom service center.

Specifications

Attribute	Detail
Part Name	Sinoboom Circuit Board
Part Number	203990000010
Manufacturer	HNARL
Item Weight	1.06 ounces
Product Dimensions	3.15 x 1.57 x 0.39 inches
Included Components	Sinoboom Circuit Board
Condition	New

Warranty Information

The Sinoboom Circuit Board 203990000010 comes with a**12-month warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
The warranty does not cover damage resulting from:

- Improper installation or unauthorized repairs.
- Accident, misuse, abuse, or neglect.
- Exposure to extreme environmental conditions (e.g., water, excessive heat, corrosive chemicals).
- Normal wear and tear.

To claim warranty service, please retain your proof of purchase and contact HNARL customer support.

Support and Contact

For technical assistance, warranty claims, or inquiries regarding the Sinoboom Circuit Board 203990000010, please

contact HNARL customer support.

HNARL Customer Service:

Online Store: Visit the HNARL Store on Amazon

General Inquiries: Refer to the contact information provided on the official HNARL store page or product packaging.

When contacting support, please have your product model number (203990000010) and proof of purchase readily available.

© 2023 HNARL. All rights reserved. Sinoboom is a registered trademark.
This manual is subject to change without notice.