

[Manuals.plus](#) /

› [Walker's](#) /

› Walker's Disrupter Bluetooth Earbuds Instruction Manual

Walker's GWP-DSRPT

Walker's Disrupter Bluetooth Earbuds Instruction Manual

Model: GWP-DSRPT

1. INTRODUCTION

The Walker's Disrupter Bluetooth Earbuds are designed to provide both hearing protection and sound enhancement for various activities, including hunting, shooting, and active lifestyles. These electronic earbuds feature advanced noise-cancelling technology to protect against dangerous sound levels while simultaneously enhancing environmental sounds and offering high-quality Bluetooth audio streaming.

Key features include active noise cancellation, rapid impulse noise protection, 360-degree true surround sound mode, and customizable ambient sound settings controlled via a mobile application.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- Walker's Disrupter Bluetooth Earbuds (Left and Right)
- USB-C Charging Case with Integrated Lithium Battery
- 3 Sizes of Noise-Reducing Foam Ear Tips (Small, Medium, Large)
- 3 Sizes of Silicone In-Ear Tips (Small, Medium, Large)
- USB-C Charging Cable



Image: Walker's Disrupter Earbuds, charging case, various ear tips, and USB-C cable.

3. PRODUCT OVERVIEW

The Disrupter earbuds are designed for a secure and comfortable fit, featuring a compact in-ear design. The included charging case not only protects the earbuds but also provides additional battery life on the go.



Image: Front view of the Walker's Disrupter Bluetooth Earbuds.



Image: Walker's Disrupter Earbuds inside their charging case.

4. SETUP AND CHARGING

4.1 Initial Charging

Before first use, fully charge the earbuds and the charging case. Connect the provided USB-C cable to the charging case and a compatible USB power source. The indicator light on the case will show charging status. A full charge provides approximately 6 hours of Bluetooth streaming or 11 hours of ambient-only use for the earbuds, with the case providing an additional 24 hours of battery life.

4.2 Ear Tip Selection and Fit

Proper ear tip selection and fit are crucial for optimal noise reduction and sound quality. The package includes three sizes of noise-reducing foam ear tips for maximum protection and three sizes of silicone ear tips for everyday use. Experiment with different sizes to find the most comfortable and secure fit that creates a good seal in your ear canal.



Image: Proper fit of the earbuds for shooting activities.

4.3 Video: Product Overview and Usage

Your browser does not support the video tag.

Video: Official product video demonstrating the features, setup, and use of Walker's Disrupter Bluetooth Earbuds, including active noise cancellation, sound enhancement, app control, and charging.

5. OPERATION

5.1 Powering On/Off

To power on the earbuds, remove them from the charging case. They will automatically attempt to connect to the last paired device. To power off, place them back into the charging case.

5.2 Bluetooth Pairing

When removed from the case for the first time, the earbuds will enter pairing mode. Open the Bluetooth settings on your device (smartphone, tablet, etc.) and select "Walker's Disrupter" from the list of available devices. Once paired, the earbuds will automatically connect to your device when removed from the case.

5.3 Ambient Sound Settings

The Disrupter earbuds offer five ambient sound settings to optimize your listening experience:

- **Universal:** General setting for balanced sound.
- **Clear Voice:** Enhances speech clarity.
- **Hi-Frequency Boost:** Amplifies high-frequency sounds.
- **Power Boost:** Provides maximum sound amplification.
- **Custom:** Allows personalized adjustments via the Walker's Link app.

These settings, along with features like Forward Focus Mode and 360-degree Directional Sound, can be adjusted through the Walker's Link mobile application.



Image: User actively engaged while wearing the earbuds.

6. APP CONTROL (WALKER'S LINK APP)

The Walker's Link 4.0 app provides comprehensive control over your Disrupter earbuds. Download the app from your device's app store. Once installed and connected via Bluetooth, you can:

- Select and customize ambient sound settings.
- Adjust volume levels for both ambient sound and Bluetooth audio.
- Monitor earbud and case battery levels.
- Update firmware (FOTA - Firmware Over The Air) for improved performance and new features.
- Adjust auto shut-off time.



Image: Walker's Link app interface on a smartphone.

7. MAINTENANCE

To ensure longevity and optimal performance of your earbuds:

- **Cleaning Ear Tips:** Regularly remove and clean ear tips with a mild soap and water solution. Ensure they are completely dry before reattaching.
- **Cleaning Earbuds:** Wipe the earbuds with a soft, dry cloth. If residue accumulates on the pogo pins (charging contacts), gently clean them with a cotton swab lightly dampened with rubbing alcohol.
- **Storage:** Always store the earbuds in their charging case when not in use to protect them and keep them charged.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Earbuds not charging	Dirty charging contacts (pogo pins) or uncharged case.	Clean pogo pins on earbuds and in case with alcohol. Ensure charging case is charged.
No sound or poor sound quality	Improper ear tip fit, low battery, or incorrect app settings.	Adjust ear tips for a secure seal. Charge earbuds. Check ambient sound settings in the Walker's Link app.
Earbuds not pairing	Earbuds not in pairing mode or already connected to another device.	Ensure earbuds are out of the case. Turn off Bluetooth on other nearby devices. Re-initiate pairing from your device's Bluetooth settings.
App not connecting to earbuds	Bluetooth not enabled or app issue.	Ensure Bluetooth is on and earbuds are paired to your phone. Restart the app or your phone.

For further assistance, refer to the Walker's Link app for potential firmware updates or contact customer support.

9. SPECIFICATIONS

Feature	Detail
Model Number	GWP-DSRPT
Noise Reduction Rating (NRR)	25 dB
Microphones	4 Hi-Gain Omnidirectional
Noise Control	Active Noise Cancellation, Rapid Impulse Noise Protection
Ambient Sound Settings	Universal, Clear Voice, Hi-Frequency Boost, Power Boost, Custom
Connectivity Technology	Wireless (Bluetooth 5.0)
Bluetooth Range	10 Meters
Earbud Battery Life	6 hours (BT streaming), 11 hours (Ambient Only)
Charging Case Battery Life	Additional 24 hours
Charging Port	USB-C
Control Method	App (Walker's Link 4.0)
Firmware Updates	FOTA (Firmware Over The Air) Update Ability
Weight	227 Grams

10. WARRANTY AND SUPPORT

The Walker's Disrupter Bluetooth Earbuds come with a limited warranty. For detailed warranty information, please refer to the documentation included with your product or visit the official Walker's website.

For technical support, troubleshooting assistance, or any product-related inquiries, please contact Walker's customer service. Contact information can typically be found on the product packaging or the manufacturer's website.