

[Manuals.plus](#) /

> [Luminzone](#) /

> Luminzone 5-Light Flush Mount Ceiling Light Instruction Manual

## Luminzone 7J4F BK+BG

# Luminzone 5-Light Flush Mount Ceiling Light

Model: 7J4F BK+BG

Brand: Luminzone

## 1. PRODUCT OVERVIEW

---

The Luminzone 5-Light Flush Mount Ceiling Light is designed to provide elegant and functional illumination for various indoor spaces. Featuring a modern design with a black and brass finish, this fixture is suitable for bedrooms, dining rooms, living rooms, kitchens, and foyers. It accommodates five E26 base bulbs (not included) and supports dimmable or non-dimmable bulbs.



Figure 1.1: Luminzone 5-Light Flush Mount Ceiling Light

## 2. SAFETY INFORMATION

---

**WARNING: Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.**

- Read all instructions carefully before installation.
- Installation must be performed by a qualified electrician or a person familiar with the construction and operation of the product and the hazards involved.
- Ensure the supply voltage is correct (120V AC).
- Do not exceed the maximum wattage specified for the bulbs (40W per bulb).
- Use only E26 base bulbs.
- This fixture is intended for indoor use only.
- Keep flammable materials away from the light fixture.
- Always wear appropriate safety gear, including safety glasses and gloves, during installation.

## 3. PACKAGE CONTENTS

---

Carefully unpack the fixture and check that all parts are included. If any parts are missing or damaged, contact customer service before proceeding with installation.

- Ceiling Light Fixture (1)
- Mounting Hardware Kit (1)
- Instruction Manual (1)

## 4. SPECIFICATIONS

---

<b>Brand</b>	Luminzone
<b>Model Number</b>	7J4F BK+BG
<b>Dimensions (L x W x H)</b>	11.8" x 11.8" x 4.64" (approx.)
<b>Weight</b>	4.4 pounds
<b>Material</b>	Brass, Metal
<b>Color</b>	Black and Brass
<b>Number of Lights</b>	5
<b>Bulb Base</b>	E26 Medium Base
<b>Max Wattage per Bulb</b>	40W
<b>Voltage</b>	120V AC (Standard US)
<b>Installation Type</b>	Flush Mount
<b>Dimmable</b>	Yes (with dimmable bulbs and compatible dimmer switch)

# E26 BULB BASE

(BULBS ARE NOT INCLUDED) COMPATIBLE WITH LED, INCANDESCENT, CFL AND HALOGEN BULBS



INCANDESCEN



CFL



HALOGENBULBS



LED



E26 BULB BASE

Figure 4.1: Product Dimensions and Bulb Base Information

## 5. SETUP AND INSTALLATION

Follow these steps for safe and proper installation of your ceiling light fixture.

1. **Turn Off Power:** Before starting, ensure the power to the junction box is turned off at the circuit breaker or fuse box. This is a critical safety step.
2. **Prepare Mounting Plate:** Attach the mounting plate to the junction box using the screws provided. Ensure it is securely fastened.
3. **Wire Connections:** Carefully connect the electrical wires. Connect the black wire from the fixture to the black (live) wire from the junction box, the white wire from the fixture to the white (neutral) wire from the junction box, and the ground wire from the fixture to the ground wire from the junction box (or to the green ground screw on the mounting plate). Secure connections with wire nuts.
4. **Mount Fixture:** Carefully push the wired connections into the junction box. Align the fixture base with the mounting plate and secure it with the provided screws.
5. **Install Bulbs:** Screw five E26 base bulbs (not included) into the sockets. Do not exceed 40W per bulb.
6. **Restore Power:** Once the fixture is securely installed and bulbs are in place, restore power at the circuit

breaker or fuse box.



Figure 5.1: Detail of Metal Finish and E26 Bulb Sockets

## 6. OPERATING INSTRUCTIONS

---

Once installed, operate the light fixture using your standard wall switch. If you wish to utilize the dimming feature, ensure you have installed dimmable E26 bulbs and connected the fixture to a compatible dimmer switch (sold separately).



Figure 6.1: Light Fixture On/Off Display

## 7. MAINTENANCE

---

- **Cleaning:** To clean the fixture, ensure the power is off. Wipe with a soft, dry cloth. Do not use abrasive cleaners or solvents as they may damage the finish.
- **Bulb Replacement:** Always turn off the power before replacing bulbs. Allow bulbs to cool before handling. Replace with E26 base bulbs, not exceeding 40W per bulb.
- **Inspection:** Periodically inspect the wiring and connections for any signs of wear or damage. If any issues are found, consult a qualified electrician.

## 8. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
---------	----------------	----------

Light does not turn on	No power to fixture Loose wire connections Faulty bulb(s) Faulty fixture base	Check circuit breaker/fuse. Ensure all wire connections are secure. Test bulbs in another working fixture or replace with new ones. If all else fails, consult a qualified electrician or contact customer support.
Light flickers	Loose bulb Incompatible dimmer switch/bulb Loose wiring	Tighten bulbs. Ensure dimmable bulbs are used with a compatible dimmer switch. Check wire connections (with power off).
Buzzing sound	Incompatible dimmer switch/bulb Loose components	Ensure dimmable bulbs are used with a compatible dimmer switch. Check that all parts are securely fastened.

## 9. WARRANTY AND SUPPORT

---

Luminzone provides a 1-year warranty for this ceiling light fixture, covering defects in materials and workmanship from the date of purchase. This warranty does not cover damage caused by improper installation, misuse, abuse, or normal wear and tear.

For technical assistance, warranty claims, or any other inquiries, please contact Luminzone customer service through the retailer's platform where the product was purchased. Please have your model number (7J4F BK+BG) and purchase information ready when contacting support.