

[Manuals.plus](#) /

› [Silonn](#) /

› Silonn Air Fryer Oven User Manual

Silonn SLAF03TB

Silonn Air Fryer Oven User Manual

Model: SLAF03TB

INTRODUCTION

Welcome to the Silonn Air Fryer Oven user manual. This appliance is designed to combine the functionalities of an air fryer and a toaster oven, offering versatile cooking options. It features precise temperature control and efficient heat circulation for optimal cooking results.



Figure 1: Silonn Air Fryer Oven with included accessories.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the Silonn Air Fryer Oven. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the appliance on a stable, heat-resistant surface.
- Do not immerse the cord, plug, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use attachments not recommended by the appliance manufacturer.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Always ensure the door is fully closed before operating the appliance. The appliance is designed not to turn on if the door is open.

WHAT'S IN THE BOX

Your Silonn Air Fryer Oven package includes the following components:

- Silonn Air Fryer Oven Unit
- Crumb Tray x 1
- Oil Tray x 1
- Wire Rack x 1
- Air Fry Basket x 1
- Tray Handle x 1



Figure 2: Included accessories for the Silonn Air Fryer Oven.

SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the crumb tray, oil tray, wire rack, air fry basket, and tray handle with warm, soapy water. Wipe the interior and exterior of the oven with a damp cloth. Ensure all parts are completely dry before use.
3. **Placement:** Place the air fryer oven on a flat, stable, heat-resistant surface, ensuring adequate clearance (at least 4 inches) on all sides for proper ventilation.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.
5. **Initial Run (Optional but Recommended):** For the first use, it is recommended to run the oven empty for about 10-15 minutes at 400°F (200°C) to burn off any manufacturing residues. A slight odor or smoke may be present, which is normal. Ensure the area is well-ventilated.

OPERATING INSTRUCTIONS

The Silonn Air Fryer Oven features an intuitive LED touch panel with 8 preset cooking modes. Follow these steps to operate your appliance:

General Operation

1. **Power On:** Plug in the appliance. The display will light up. Press the **Power** button (*power icon*) to turn the unit on.
2. **Select Mode:** Choose your desired cooking mode by tapping the corresponding icon on the LED touch panel. The available modes are: Air Fry, Roast, Broil, Preheat, Bake, Pizza, Toast, and Dehydrate.
3. **Adjust Temperature/Time:** Use the **+/-** buttons to adjust the temperature and cooking time. Tap the **Temp** or **Time** button to switch between adjusting temperature and time.
4. **Start Cooking:** Once settings are configured, press the **Start/Pause** button (*play/pause icon*) to begin cooking.
5. **Pause/Resume:** During cooking, press the **Start/Pause** button to pause the operation. Press it again to resume.
6. **Light Feature:** To check on your food without opening the door, press the **Light** button (*light bulb icon*) to illuminate the interior.
7. **Power Off:** To turn off the appliance, press and hold the **Power** button.

Key Features and Modes



Figure 3: Digital control panel with 8 cooking presets.

- **2-in-1 Functionality:** This appliance combines the best of air fryers and toaster ovens, allowing for a wide range of cooking tasks.

Figure 4: The 2-in-1 operation of the Silonn Air Fryer Oven.

- **Dual Independent Heating:** Unlike ordinary air fryers that heat from one side, the Silonn Air Fryer Oven features dual independent heating elements (upper and lower) for balanced cooking. This eliminates the need to manually flip food and can halve cooking time.

Figure 5: Balanced cooking with dual heating elements.

Figure 6: Efficient 360° heat circulation for faster cooking.

- **Crispier and Healthier Food:** With 1200W of power and a temperature range of 140°F–450°F, coupled with a powerful fan and 360° heat circulation, this oven ensures crispier results with up to 90% less oil.

Figure 7: Achieving crispy and healthy food.

- **Large Capacity:** The 14-quart capacity provides ample space for various foods, such as 4 slices of toast, a 9-inch pizza, 10 chicken wings, or 300g of fries per layer.

Figure 8: Overview of the oven's capacity and food examples.

Figure 9: The Silonn Air Fryer Oven in use, preparing various dishes.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Silonn Air Fryer Oven.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Interior Cleaning:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn stains, use a non-abrasive sponge. Do not use harsh chemicals or abrasive cleaners.
3. **Exterior Cleaning:** Wipe the exterior surface with a soft, damp cloth. Do not use abrasive pads or steel wool.
4. **Accessory Cleaning:** The crumb tray, oil tray, wire rack, and air fry basket are dishwasher safe for easy cleaning. Alternatively, wash them with warm, soapy water and dry thoroughly.
5. **Crumb Tray:** Empty the crumb tray regularly to prevent grease buildup and potential fire hazards.
6. **Storage:** Store the appliance in a cool, dry place when not in use.

TROUBLESHOOTING

If you encounter any issues with your Silonn Air Fryer Oven, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; Door not fully closed; Power outage.	Ensure the power cord is securely plugged into a working outlet. Close the door completely. Check your household's power supply.
Food is not cooking evenly.	Overcrowding the basket; Incorrect temperature/time settings.	Avoid overcrowding; cook in smaller batches if necessary. Adjust temperature and time according to recipe recommendations. The dual heating system should minimize the need for flipping.
White smoke coming from the appliance.	Grease residue from previous use; High fat content food.	Clean the appliance thoroughly after each use, especially the crumb tray and heating elements. For high-fat foods, use the oil tray to catch drips.
Food is not crispy.	Too much oil; Overcrowding; Not enough cooking time/high enough temperature.	Use minimal oil or spray. Do not overcrowd the basket. Increase cooking time or temperature as needed.

SPECIFICATIONS

Feature	Detail
Brand	Silonn
Model Name	SLAF03TB
Color	Black
Product Dimensions	13.27"D x 9.92"W x 12.91"H
Capacity	14 Quarts
Special Feature	Manual (Digital Touch Control)
Control Type	Touch Control
Door Style	Dropdown Door
Power Source	Electric Outlet
Material	Stainless Steel
Item Weight	8.8 pounds
Temperature Range	140°F – 450°F
Power	1200W

WARRANTY AND SUPPORT

Silonn stands behind the quality of its products. For warranty information, technical support, or any inquiries regarding your Silonn Air Fryer Oven, please refer to the following:

- **User Guide (PDF):** [Download User Guide](#)

- **User Manual (PDF):** [Download User Manual](#)
- **Silonn Store:** Visit the official Silonn store on Amazon for more products and information: [Silonn Amazon Store](#)
- For direct customer support, please refer to the contact information provided in the physical user manual included with your product.