Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Cecotec /
- Cecotec Bolero Hexa C134500 Built-in Oven User Manual

Cecotec 02824

Cecotec Bolero Hexa C134500 Built-in Oven User Manual

Model: 02824

1. Introduction

Thank you for choosing the Cecotec Bolero Hexa C134500 Built-in Oven. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read it thoroughly before use and keep it for future reference.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the oven is properly installed by a qualified technician.
- Do not touch hot surfaces. Use oven mitts or pot holders.
- Supervise children when the oven is in use.
- Never use water to extinguish grease fires. Smother the fire or use a dry chemical or foam-type extinguisher.
- Disconnect the appliance from the power supply before cleaning or maintenance.
- Do not store flammable materials in or near the oven.
- The oven door features Triple Glass to minimize heat loss and prevent burns, but caution is still advised.

3. PRODUCT FEATURES

- 56-Liter Capacity: Large interior suitable for family cooking with 4 tray positions.
- 2600W Power: High power for perfect results in less time.
- 4 Functions: Internal light, Grill mode, Convection mode, and Steam Assist/Steam EasyClean.
- Steam Base X2: Double steam zone with XXL capacity (500ml + 500ml) for Steam EasyClean and Steam Assist functions.
- Steam EasyClean: Steam cleaning function to loosen dirt for efficient cleaning.
- Steam Assist: Combines steam cooking for crispy exteriors and juicy interiors.

- Cooling Fan: Rapid cooling system to minimize condensation and excess temperature.
- **Triple Glass Door:** Cold door with 3 panes of glass to prevent burns and heat loss.
- Timer: Control cooking time precisely.
- Energy Class A: Efficient energy consumption.



Figure 1: Front view of the Cecotec Bolero Hexa C134500 Built-in Oven.

4. COMPONENTS AND ACCESSORIES

The following items are included with your oven:

- 1 x Conventional Oven Unit
- 1 x User Manual
- 1 x Tray
- 1 x Grill Rack

5. Installation and Setup

5.1 Unpacking

Carefully remove the oven from its packaging. Inspect for any damage during transit. Keep packaging materials for future transport or disposal.

5.2 Placement and Ventilation

The oven is designed for built-in installation. Ensure adequate ventilation around the appliance as per local regulations. The cooling fan system helps manage internal temperatures and condensation.



Figure 2: Illustration of the Cooling Fan system.

5.3 Electrical Connection

Connect the oven to a suitable electrical outlet according to the specifications provided. Ensure the power supply matches the appliance's requirements (2600W). It is recommended that electrical installation be performed by a qualified electrician.

5.4 Dimensions

Product dimensions: 59.4 x 63 x 45.5 cm (Width x Depth x Height). Weight: 23.05 kg. Ensure the cabinet opening is appropriate for these dimensions.

6. OPERATING INSTRUCTIONS

6.1 Control Panel Overview

The oven features intuitive rotary controls for function selection, temperature, and timer settings.



Figure 3: Control panel showing the four main functions.

6.2 Cooking Functions

- Internal Light: Illuminates the oven interior.
- Grill Mode: Ideal for grilling and browning dishes.

- Convection Mode: Circulates hot air for even cooking and baking.
- Steam Assist: For combined steam cooking. Fill the Steam Base X2 with water (up to 1 liter total capacity, 500ml per zone). This function helps achieve crispy exteriors and juicy interiors.



Figure 4: Steam Base X2 for steam functions.



Figure 5: Example of steam-assisted cooking.

6.3 Using the Timer

Set the desired cooking duration using the timer knob. The oven will automatically turn off once the set time has elapsed.



Figure 6: Setting the oven timer.

7. MAINTENANCE AND CLEANING

7.1 General Cleaning

Before cleaning, ensure the oven is cool and disconnected from the power supply. Use a damp cloth and mild detergent for external surfaces. For the interior, remove racks and trays and clean with appropriate oven cleaner.

7.2 Steam EasyClean Function

The Steam EasyClean function simplifies oven cleaning. Fill the Steam Base X2 with water. Activate the Steam EasyClean function. The steam will loosen baked-on food residues, making them easier to wipe away once the oven has cooled.



Figure 7: Steam EasyClean in action, showing its effectiveness.

7.3 Triple Glass Door Cleaning

The Triple Glass door can be cleaned with a soft cloth and glass cleaner. Avoid abrasive materials that could scratch the glass.



Figure 8: Illustration of the Triple Glass Door construction.

8. TROUBLESHOOTING

If you encounter issues with your oven, refer to the table below for common problems and solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution
Oven does not heat up.	No power supply; incorrect function selected; faulty heating element.	Check power connection and circuit breaker. Ensure correct function and temperature are set. Contact service if element is faulty.
Light not working.	Bulb needs replacement.	Replace the oven light bulb.
Uneven cooking.	Improper rack position; overloaded oven; faulty fan.	Adjust rack position. Avoid overcrowding the oven. Contact service if fan is faulty.

Problem	Possible Cause	Solution
Excessive smoke during cooking.	Food spills; excessive grease.	Clean oven interior thoroughly. Reduce amount of grease in cooking.

9. SPECIFICATIONS

• Model Number: 02824

• Brand: Cecotec

• Capacity: 56 Liters

• Power: 2600 W

• Energy Class: A

• Dimensions (W x D x H): 59.4 x 63 x 45.5 cm

• Weight: 23.05 kg

• Heating Method: Radiant

• Fuel Type: Electric

Installation Type: Built-inColor: Black | 45cm Height

• Country of Origin: Spain

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the terms provided at the time of purchase or visit the official Cecotec website. If you wish to return a product within 30 days of receipt because you have changed your mind, please consult the Amazon help page. If you have received a defective or damaged product, please consult the Amazon help page on returns. For specific information on purchases made on the Marketplace, please consult the Amazon help page.

Contact Information: Please refer to your purchase documentation or the official Cecotec website for the most up-to-date contact details for customer service and technical support.

© 2025 Cecotec. All rights reserved.



Cecotec Bolero Hexa M224500 Manual de Instrucciones

Manual de instrucciones para el horno integrable Cecotec Bolero Hexa M224500 (modelos Glass Black A y Edge A), con información sobre seguridad, instalación, funcionamiento y mantenimiento.



Cecotec Horno Bolero Hexa: Manual de Instrucciones Completo

Manual de instrucciones para hornos integrables Cecotec Bolero Hexa (C126000, C136000). Incluye seguridad, funcionamiento, instalación, mantenimiento, consejos y especificaciones técnicas.



Cecotec Bolero Hexa AF314500: Manual de Instrucciones y Guía de Uso

Descubra el horno integrable Cecotec Bolero Hexa AF314500. Este manual proporciona instrucciones detalladas de instalación, funcionamiento, seguridad y mantenimiento para los modelos Glass Black A y Matt A.



Cecotec Bolero Hexa MW0706000 Line Oven: User Manual and Safety Instructions

Comprehensive user manual for the Cecotec Bolero Hexa MW0706000 Line oven, covering safety instructions, installation, operation, cleaning, maintenance, and troubleshooting.



Manual de Instrucciones Cecotec Bolero CoolMarket 4D 474 Frigorífico

Guía completa para los frigoríficos Cecotec Bolero CoolMarket 4D 474 Inox E y Dark E. Incluye instrucciones de seguridad, instalación, uso, mantenimiento y solución de problemas.



Cecotec Bolero Hexa SM406000: Manual de Instrucciones y Seguridad

Manual completo de instrucciones y seguridad para los hornos multifunción Cecotec Bolero Hexa SM406000 (Edge+, Glass Black, Glass White, Glass Grey). Incluye guía de uso, limpieza, resolución de problemas y especificaciones técnicas.