

## Cecotec 08572

# Cecotec Conga Rockstar Wet & Dry Steel Pro Tool Vacuum Cleaner 30L 1600W User Manual

Model: 08572

## 1. SAFETY INFORMATION

Please read all safety instructions carefully before using the appliance. Retain this manual for future reference.

- Ensure the power supply voltage matches the rating label on the appliance.
- Do not use the vacuum cleaner to pick up flammable or combustible liquids, hot ashes, or sharp objects.
- Always unplug the appliance from the power outlet before cleaning, maintenance, or when not in use.
- Do not immerse the motor unit in water or other liquids.
- Keep the appliance away from children and pets.
- Do not operate the vacuum cleaner with a damaged cord or plug. Contact authorized service personnel for repairs.
- When vacuuming liquids, ensure the tank does not overfill. The float mechanism will stop suction when full.
- Use only original accessories and spare parts.

## 2. PRODUCT OVERVIEW

The Cecotec Conga Rockstar Wet & Dry Steel Pro Tool Vacuum Cleaner is a powerful and versatile appliance designed for both solid and liquid waste. It features a durable metal tank, a 1600W motor, and a 30L capacity, making it suitable for various cleaning tasks.

### Key Features:

- **1600W Power:** Provides strong suction for efficient cleaning.
- **30L Capacity:** Large tank for extended cleaning sessions without frequent emptying.
- **Wet & Dry Functionality:** Capable of vacuuming both solid debris and liquids.

- **Blowing System:** Integrated function for clearing debris from hard-to-reach areas.
- **Dual Filtration:** Features a water filter and a high-efficiency filter to purify air and retain allergens.
- **Tool Socket:** Integrated power outlet for connecting power tools, allowing simultaneous vacuuming of dust.
- **Accessory Kit:** Includes various nozzles and brushes for different surfaces and tasks.

### Components:

- Vacuum Cleaner Unit (Motor Head, Metal Tank, Base with Wheels)
- Flexible Hose
- Extension Tubes (usually 2-3 pieces)
- Floor Brush (for wet and dry use)
- Crevice Tool
- Upholstery Brush
- Drill Dust Collector Accessory
- Water Filter
- High-Efficiency Filter
- Instruction Manual



Image 2.1: Overview of the Cecotec Conga Rockstar Wet & Dry Steel Pro Tool Vacuum Cleaner and its included accessories.

### 3. SETUP

Follow these steps to assemble your vacuum cleaner before first use.

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Attach Wheels:** Insert the wheels into the designated slots on the base of the tank until they click into place.
3. **Install Filters:**
  - For dry vacuuming, ensure the high-efficiency filter is securely installed on the motor unit.
  - For wet vacuuming, remove the high-efficiency filter and ensure the water filter is correctly positioned.

4. **Secure Motor Unit:** Place the motor unit onto the metal tank and secure it with the side clips.
5. **Connect Hose:** Attach the flexible hose to the suction inlet on the tank. Ensure it is firmly twisted or pushed into place.
6. **Assemble Extension Tubes and Nozzle:** Connect the extension tubes to the flexible hose, then attach the desired cleaning nozzle (e.g., floor brush) to the end of the tubes.



Image 3.1: Front view of the assembled vacuum cleaner, ready for use.

---

## 4. OPERATING INSTRUCTIONS

This section details how to use your vacuum cleaner for various cleaning tasks.

## 4.1 Dry Vacuuming

1. Ensure the high-efficiency filter is installed and the water filter is removed (if applicable).
2. Connect the desired dry cleaning accessory (e.g., floor brush for carpets/hard floors, crevice tool for tight spaces).
3. Plug the power cord into a suitable electrical outlet.
4. Turn on the vacuum cleaner using the power switch.
5. Move the nozzle over the surface to be cleaned.
6. After use, turn off the appliance and unplug it.



Image 4.1: Demonstrating dry vacuuming on a hard floor surface.

## 4.2 Wet Vacuuming

**Important:** Before wet vacuuming, remove the high-efficiency filter. Only use the water filter for wet applications.

1. Ensure the water filter is correctly installed.

2. Connect the appropriate wet cleaning accessory (e.g., the floor brush with its squeegee attachment).
3. Plug the power cord into a suitable electrical outlet.
4. Turn on the vacuum cleaner.
5. Move the nozzle over the liquid spill. The vacuum will collect the liquid into the tank.
6. The float mechanism will automatically stop suction when the tank is full to prevent overflow. Turn off the appliance immediately and empty the tank.
7. After use, turn off the appliance and unplug it. Clean and dry the tank and filters thoroughly.

### 4.3 Blowing Function

The vacuum cleaner can also be used as a blower to clear debris.

1. Disconnect the flexible hose from the suction inlet.
2. Connect the flexible hose to the blowing outlet, usually located on the motor unit.
3. Plug the power cord into a suitable electrical outlet.
4. Turn on the vacuum cleaner. Air will now be expelled through the hose.
5. Direct the airflow to clear leaves, dust, or other light debris.
6. After use, turn off the appliance and unplug it.



#### 4.4 Using the Tool Socket

The integrated tool socket allows you to connect power tools and simultaneously vacuum the dust they generate.

1. Plug your power tool into the tool socket on the vacuum cleaner's motor unit.
2. Connect the flexible hose to the suction inlet of the vacuum cleaner.
3. Attach the drill dust collector accessory or another suitable nozzle to the hose and position it near the work area of your power tool.
4. Plug the vacuum cleaner's power cord into a suitable electrical outlet.
5. Turn on the vacuum cleaner. When the power tool is activated, the vacuum cleaner will also start, providing synchronized dust extraction.
6. After completing your work, turn off the power tool, then turn off the vacuum cleaner and unplug it.



Image 4.3: Detail of the integrated tool socket on the vacuum cleaner.




Image 4.4: Using the vacuum cleaner with a power tool for dust extraction.

## 5. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

### 5.1 Emptying the Tank

#### For Dry Waste:

1. Unplug the vacuum cleaner.
2. Unclip the motor unit and lift it off the tank.
3. Carefully remove the high-efficiency filter and tap it to dislodge dust, or brush it clean.
4. Empty the solid waste from the tank into a trash receptacle.
5. Clean the inside of the tank with a damp cloth if necessary.

#### For Liquid Waste:

1. Unplug the vacuum cleaner.

2. Unclip the motor unit and lift it off the tank.
3. Locate the drain plug at the bottom of the tank.
4. Place a bucket or suitable container under the drain plug.
5. Open the drain plug to empty the liquid.
6. Alternatively, the entire tank can be carefully tilted to pour out liquids.
7. Rinse the tank with clean water and allow it to air dry completely before reassembly.



Image 5.1: Draining liquid from the vacuum cleaner's tank using the integrated drain plug.

## 5.2 Filter Cleaning

- **High-Efficiency Filter:** For dry use, regularly tap the filter to remove accumulated dust. It can be gently washed with cold water if heavily soiled, but must be completely dry before reinstallation.
- **Water Filter:** After wet vacuuming, rinse the water filter thoroughly with clean water. Ensure it is clean and free of debris.
- Inspect filters for damage. Replace damaged filters immediately to maintain suction performance and air quality.



Image 5.2: Illustration of filter removal and cleaning process.

### 5.3 Storage

Store the vacuum cleaner in a dry, cool place, away from direct sunlight and extreme temperatures. Ensure the tank is empty and clean, and all filters are dry before storage.

## 6. TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Vacuum cleaner does not start.	No power supply; Power switch off; Tool socket mode active without tool.	Check power cord and outlet; Ensure power switch is ON; If using tool socket, ensure tool is plugged in and switched on.
Low or no suction power.	Hose/nozzle blocked; Tank full; Filters clogged; Motor unit not properly sealed.	Check and clear blockages; Empty the tank; Clean or replace filters; Ensure motor unit clips are securely fastened.
Water leaks from the tank.	Drain plug not closed properly; Tank damaged; Motor unit not sealed.	Ensure drain plug is tightly closed; Inspect tank for cracks (contact support if damaged); Re-secure motor unit.
Vacuum cleaner stops during wet vacuuming.	Tank is full (float mechanism activated).	Turn off the vacuum cleaner, unplug it, and empty the liquid from the tank.
Unusual noise during operation.	Foreign object in hose/tank; Motor issue.	Turn off and unplug. Inspect hose and tank for foreign objects. If noise persists, contact support.

## 7. SPECIFICATIONS

Specification	Value
---------------	-------

Specification	Value
Brand	Cecotec
Model Number	08572
Color	Black
Capacity	30 Liters
Power	1600 Watts
Voltage	230 Volts
Power Source	Corded Electric
Filter Type	HEPA Filter, Water Filter
Item Weight	6.5 Kilograms
Product Dimensions (L x W x H)	1 x 1 x 1 cm (approximate, as per source)
Cordless	No
Spare Parts Availability	10 Years


## 8. WARRANTY AND SUPPORT






This Cecotec product is manufactured to high-quality standards. For information regarding the warranty period and conditions, please refer to the warranty card included with your purchase or visit the official Cecotec website.

For technical support, spare parts, or service inquiries, please contact Cecotec customer service through their official channels. When contacting support, please have your product model number (08572) and purchase details readily available.

**Spare Parts Availability:** Spare parts for this model are available for a period of 10 years from the date of purchase.

### Related Documents - 08572

	<p><a href="#">Conga Rockstar Wet &amp; Dry Compact Garden Plus Vacuum Cleaner - User Manual   Cecotec</a></p> <p>Official user manual for the Cecotec Conga Rockstar Wet &amp; Dry Compact Garden Plus vacuum cleaner (Model: EU01_100012). Provides detailed instructions on safety, assembly, operation, cleaning, maintenance, troubleshooting, technical specifications, and disposal.</p>
---	---

	<p><a href="#">Cecotec Conga Rockstar 6500 Century ErgoWet Animal Instruction Manual</a></p> <p>Comprehensive instruction manual for the Cecotec Conga Rockstar 6500 Century ErgoWet Animal upright vacuum cleaner, covering safety, assembly, operation, cleaning, maintenance, and troubleshooting.</p>
	<p><a href="#">Conga RockStar Micro 6000 &amp; 8000: Manual de Instrucciones y Guía de Usuario</a></p> <p>Manual completo de instrucciones para los aspiradores de mano Cecotec Conga RockStar Micro 6000 y Conga RockStar Micro 8000. Incluye guías de seguridad, funcionamiento, limpieza, mantenimiento y especificaciones técnicas.</p>
	<p><a href="#">Cecotec Conga Robot Vacuum Cleaners: Ultra-Powerful &amp; Smart Cleaning Solutions</a></p> <p>Explore the advanced range of Cecotec Conga robot vacuum cleaners, featuring ultra-powerful suction, intelligent navigation, and versatile 4-in-1 cleaning capabilities for a spotless home.</p>
	<p><a href="#">Manual de Instrucciones Conga Rockstar 2500 Thunder Jalisco</a></p> <p>Guía completa de instrucciones para el aspirador vertical Conga Rockstar 2500 Thunder Jalisco de Cecotec. Aprenda a usar, limpiar y mantener su aspirador para un rendimiento óptimo.</p>
	<p><a href="#">Cecotec Conga Rockstar 3000 Advance ErgoWet: Посібник користувача</a></p> <p>Повний посібник користувача для пилососа Cecotec Conga Rockstar 3000 Advance ErgoWet. Дізнайтеся про функції, експлуатацію, обслуговування та усунення несправностей.</p>



#### [\[pdf\]](#) User Manual Instructions

WET DRY STEEL PRO TOOL ConforamaCONGA ROCKSTAR 49 NEDERLANDS Inhoud van de doos  
Conga Rockstar Wet Dry Steel Pro Tool stofzuiger voor vaste en vloeibare  
stoffen5eeadccf3149624ace6bb15df5ededad774582d6 7269be3b9b8d44ab9bee6c8b688a5d58media fd  
conforama es media 5eeadccf3149624ace6bb15df5ededad774582d6  
7269be3b9b8d44ab9bee6c8b688a5d58 stoffenmedia ConforamaManual usuarioCONGA stoffenCecotec  
Aspirador Sólidos y Líquidos Metal con Cable 30L 1600W Mayor Durabilidad Resistencia Incluye  
Enchufe para Herramientas Kit Accesorios Amazon Hogar cocinaA1RKkSeWDILmedia  
7269be3b9b8d44ab9bee6c8b688a5d58m amazon images I A1RKkSeWDIL ref dp product quick  
viewmedia ||| ||| WET DRY STEEL PRO TOOL Aspirador de slidos y liquidos / Wet dry vacuum cleaner  
Manual de instrucciones Instruction manual Manuel d instructions Bedienungsanleitung Manuale di  
istruzioni Manual de instrues Handleiding Instrukcja obsługi Nvod  
WET DRY STEEL PRO TOOL Aspirador de slidos y liquidos / Wet dry vacuum cleaner  
Manual de instruccio ... su posicin 7. ESPECIFICACIONES TCNICAS Modelo: Conga  
Rockstar Wet Dry Steel Pro Tool Referencia: **08572** Voltaje: 220- 240V-, 50/60Hz  
Potencia: 1600 W IP24 Las especificaciones tcnicas pueden cambia...  
lang:it **score:35** filesize: 1.33 M page\_count: 64 document date: 2024-01-18



#### [\[pdf\]](#) User Manual Instructions

Descargar manual de usuario Conga Rockstar Wet Dry Steel Pro Tool Aspirador jardín solidos líquidos y  
soplador Cecotec conga rockstar wet dry steel pro tool user cdn cecotec cloud media files |||  
WET DRY STEEL PRO TOOL Aspirador de slidos y liquidos / Wet dry vacuum cleaner  
Manual de instruccio ... su posicin 7. ESPECIFICACIONES TCNICAS Modelo: Conga  
Rockstar Wet Dry Steel Pro Tool Referencia: **08572** Voltaje: 220- 240V-, 50/60Hz  
Potencia: 1600 W IP24 Las especificaciones tcnicas pueden cambia...  
lang:it **score:29** filesize: 1.33 M page\_count: 64 document date: 2024-01-18