

Manuals.plus /

› Cecotec /

› Cecotec IronHero 2600 Force Steam Iron User Manual

## Cecotec IronHero 2600 Force

# Cecotec IronHero 2600 Force Steam Iron User Manual

Model: IronHero 2600 Force | Brand: Cecotec

## 1. IMPORTANT SAFETY INSTRUCTIONS

---

Please read these instructions carefully before using the appliance and keep them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the voltage indicated on the rating label corresponds to your mains voltage.
- Do not immerse the iron, power cord, or plug in water or any other liquid.
- Keep the iron out of reach of children and individuals with reduced physical, sensory, or mental capabilities.
- Never leave the iron unattended while it is connected to the power supply or cooling down.
- The soleplate of the iron can reach very high temperatures. Avoid direct contact with hot surfaces.
- Unplug the iron from the power outlet before filling or emptying the water tank, and when not in use.
- Do not operate the iron with a damaged cord or plug, or if the iron malfunctions or has been dropped or damaged in any way.
- Use the iron only for its intended household purpose.

## 2. PRODUCT OVERVIEW

---

Familiarize yourself with the components of your Cecotec IronHero 2600 Force steam iron.

- **Water Tank:** Transparent reservoir for water.
- **Water Inlet:** Opening for filling the water tank.
- **Spray Nozzle:** For misting garments.
- **Steam Button:** Activates steam shot.
- **Spray Button:** Activates the spray function.
- **Steam Selector:** Adjusts continuous steam output.
- **Temperature Control Dial:** Selects ironing temperature based on fabric type.
- **Turbo Slide Soleplate:** High-resilience, non-stick soleplate for smooth gliding.
- **Precision Tip:** Designed for reaching difficult areas.
- **Power Cord:** Connects the iron to the electrical outlet.



Front view of the Cecotec IronHero 2600 Force steam iron, showcasing its design and controls.



Underside view of the Turbo Slide soleplate of the Cecotec IronHero 2600 Force steam iron, highlighting the steam vents for efficient distribution.

## 3. SETUP

---

### 3.1 Before First Use

- Remove any labels or protective foil from the soleplate.
- It is recommended to iron an old piece of fabric first to ensure no residue is left on the soleplate.

### 3.2 Filling the Water Tank

1. Ensure the iron is unplugged from the power outlet.
2. Set the steam selector to the 'Dry Ironing' position (no steam).
3. Open the water inlet cover.
4. Using a measuring cup, carefully pour tap water into the water tank up to the 'MAX' level indicator. Do not overfill.
5. Close the water inlet cover securely.



A person carefully pouring water into the water tank of the Cecotec IronHero 2600 Force steam iron using a measuring cup.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Temperature Selection

1. Plug the iron into a suitable power outlet.
2. Turn the temperature control dial to the desired setting according to the fabric type. Refer to the garment's care label.
3. The indicator light will illuminate, indicating the iron is heating up. It will turn off when the set temperature is reached.



A close-up of the temperature control dial on the Cecotec IronHero 2600 Force steam iron, showing various fabric settings for precise temperature control.

## 4.2 Dry Ironing

For dry ironing, ensure the water tank is empty or the steam selector is set to the 'Dry Ironing' position. Select the appropriate temperature and iron as usual.

## 4.3 Steam Ironing

Steam ironing is effective for most fabrics, especially cotton and linen. Ensure the water tank is filled.

1. Set the temperature control dial to a steam-suitable setting (usually indicated by steam symbols on the dial).
2. Once the indicator light turns off, indicating the iron is hot enough, adjust the steam selector to the desired steam level.
3. Move the iron over the garment. The iron will produce continuous steam up to 55 g/min.



The Cecotec IronHero 2600 Force steam iron emitting steam while held above a garment, demonstrating its powerful steam function.

#### **4.4 Steam Shot Function**

For stubborn creases, press the Steam Button. This releases a powerful burst of steam (up to 210 g/min). Wait a few seconds between shots to allow the iron to reheat.

#### **4.5 Spray Function**

Press the Spray Button to mist the fabric with water. This helps to dampen dry areas and ease crease removal.

#### **4.6 Precision Tip**

The specially designed Precision Tip allows you to easily iron around buttons, collars, and pleats, ensuring thorough crease removal in hard-to-reach areas.



A close-up of the precision tip of the Cecotec IronHero 2600 Force steam iron, positioned near a garment's pocket for detailed ironing.



A person's hand guiding the Cecotec IronHero 2600 Force steam iron over a dark garment on an ironing board, demonstrating precise control.

## 5. MAINTENANCE AND CLEANING

---

### 5.1 After Each Use

- Unplug the iron and allow it to cool down completely.
- Empty any remaining water from the tank.
- Wipe the soleplate with a damp cloth to remove any residue.
- Store the iron upright to prevent water leakage from the soleplate.

### 5.2 Cyclo Clean Anti-Calc System

The integrated Cyclo Clean anti-calc filter helps prevent limescale buildup, ensuring consistent steam performance and extending the iron's lifespan. Regular use of this system is recommended, especially in hard water areas. Refer to the full manual for detailed descaling instructions.

### 5.3 Drip Block Anti-Drip System

The Drip Block system prevents water from dripping onto your garments when ironing at low temperatures, protecting your clothes

from water stains.

## 6. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outage; faulty outlet.	Check power connection; test outlet with another appliance.
No steam produced.	Water tank empty; temperature too low; steam selector off.	Fill water tank; set higher temperature; adjust steam selector.
Water leaks from soleplate.	Temperature too low for steam; water tank overfilled.	Increase temperature; do not overfill water tank.
White flakes on garments.	Limescale buildup.	Perform descaling procedure (refer to full manual).

## 7. SPECIFICATIONS

---

**Model Name:** IronHero 2600 Force

**Model Number:** 01867

**Power:** 2600 Watts

**Continuous Steam:** Up to 55 g/min

**Steam Shot:** 210 g/min

**Soleplate:** Turbo Slide (High resilience, non-stick)

**Dimensions (L x W x H):** 31 x 12.5 x 16 cm

**Weight:** 1.45 Kilograms

**Voltage:** 230 Volts

**Base Material:** Stainless Steel

**Special Features:** Power Steam Technology, Drip Block Anti-Drip System, Cyclo Clean Anti-Calc Filter, Precision Tip

**Recommended Use:** Various textiles and fabric types, including garments and household items.

## 8. WARRANTY AND SUPPORT

---

This product comes with a manufacturer's warranty. For detailed information regarding warranty terms, technical support, or spare parts availability, please refer to the official Cecotec website or contact their customer service department. Keep your proof of purchase for warranty claims.