

Cecotec VQU11070Z+S

Cecotec QLED 70" Smart TV V1Z+ Series User Manual

Model: VQU11070Z+S

Brand: Cecotec

1. INTRODUCTION

This user manual provides comprehensive instructions for the installation, operation, and maintenance of your Cecotec QLED 70" Smart TV V1Z+ Series. Please read this manual thoroughly before using the television and retain it for future reference. This television combines advanced display technology with smart features to deliver an immersive viewing experience.

2. SAFETY INFORMATION

Always adhere to the following safety precautions to prevent electric shock, fire, or damage to the television.

- **Power Supply:** Ensure the power supply voltage matches the rating label on the TV. Do not overload power outlets.
- **Ventilation:** Do not block ventilation openings. Allow adequate space around the TV for proper airflow.
- **Liquid and Moisture:** Keep the TV away from water, rain, or excessive moisture. Do not place objects filled with liquids on the TV.
- **Cleaning:** Unplug the TV before cleaning. Use a soft, dry cloth. Avoid liquid or aerosol cleaners.
- **Placement:** Place the TV on a stable, level surface. If wall-mounting, ensure the wall mount is suitable for the TV's weight and installed by qualified personnel.
- **Children:** Do not allow children to climb on the TV or stand.
- **Lightning:** Unplug the TV during lightning storms or when unused for long periods.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Cecotec QLED 70" Smart TV

- 1 x Remote Control
- 1 x AAA Batteries (for remote control)
- 1 x User Manual (this document)
- 1 x Power Cable
- 1 x Central Stand (if "Con Peana" model)

4. PRODUCT OVERVIEW

Familiarize yourself with the main components and features of your television.



Figure 4.1: Front view of the Cecotec QLED 70" Smart TV with included remote controls.



Figure 4.2: Detailed front view of the Cecotec QLED 70" Smart TV, highlighting its slim bezels.




Figure 4.3: Illustration of the TV's frameless design, enhancing the viewing experience by minimizing borders.



Chromecast integrado para enviar contenido de forma sencilla.

Figure 4.4: Depiction of Chromecast built-in functionality, allowing easy content streaming from mobile devices to the TV.

5. SETUP

5.1 Unpacking

Carefully remove the television from its packaging. It is recommended to keep the original packaging for future transportation or servicing.

5.2 Stand Installation

If you intend to use the included central stand, follow these steps:

1. Place the TV screen-down on a soft, flat surface to prevent scratches.
2. Align the stand with the mounting holes on the bottom of the TV.
3. Secure the stand using the provided screws.



Figure 5.1: The rotative central stand allows for flexible viewing angles.

5.3 Wall Mounting (Optional)

For wall mounting, use a VESA-compatible wall mount kit (not included). Consult a professional for installation to ensure safety and proper mounting.

5.4 Connections

Connect your devices to the TV using the appropriate ports:

- **HDMI:** For high-definition devices like Blu-ray players, game consoles, and set-top boxes. This TV supports HDMI 2.1 for high frequencies and resolutions.
- **USB:** For connecting USB storage devices to play media files.
- **Ethernet:** For a wired internet connection.
- **Power:** Connect the power cable to the TV and then to a wall outlet.

6. OPERATING

6.1 Initial Setup

Upon first power-on, the TV will guide you through the initial setup process, including language selection, network connection, and Google account sign-in for Android TV 11 features.



Figure 6.1: The Android TV 11 interface provides access to a wide collection of applications for an optimal user experience.

6.2 Basic Functions

- **Power On/Off:** Press the power button on the remote control or TV.
- **Input Selection:** Use the "Input" button on the remote to switch between HDMI, TV, and other sources.
- **Volume Control:** Use the Volume Up/Down buttons.
- **Navigation:** Use the directional pad and OK button to navigate menus.

6.3 Smart TV Features

Your Cecotec Smart TV runs on Android TV 11, offering a rich smart experience:

- **Google Assistant:** Use voice commands via the remote control to search for content, control smart home devices, and get information.

- **Chromecast Built-in:** Easily cast content from your smartphone, tablet, or computer directly to the TV.
- **Google Play Store:** Download and install a wide variety of apps, games, and streaming services.


6.4 Picture Settings

Optimize your viewing experience with these advanced picture technologies:

- **4K UHD Resolution:** Enjoy ultra-sharp images with high definition, revealing even the smallest details.
- **QLED Technology:** Delivers vibrant and realistic colors with exceptional contrast.
- **HDR10+:** Processes images for greater color depth and dynamic range.
- **Dolby Vision:** Optimizes each frame for purer and more realistic images.
- **MEMC (Motion Estimation, Motion Compensation):** Adds compensation frames to generate smoother and sharper images, especially beneficial for fast-moving scenes.
- **10-Bit Display:** Reproduces over 1 billion colors for a richer and more nuanced picture.



Figure 6.2: Experience ultra-high definition images with 4K UHD and QLED technology.



Tecnología MEMC.

Movimientos fluidos y detalles más definidos.

Figure 6.3: MEMC technology ensures fluid movements and more defined details in fast-paced scenes.



HDR 10

Mayor profundidad de
color en cada imagen.

Figure 6.4: HDR 10 provides greater color depth in every image, enhancing realism.

Pantalla 10 Bits.

Reproduce más de 1000 millones de colores.




Figure 6.5: The 10-bit display reproduces over 1 billion colors for superior image quality.

6.5 Audio Settings

Enhance your audio experience:

- **Dolby Atmos:** Provides immersive 360° multi-dimensional surround sound.
- **Subwoofer:** Integrated subwoofer system improves bass and creates a superior audio experience.

 **Dolby**
VISION·ATMOS



Get purer and more realistic images and
multi-dimensional surround sound.

Figure 6.6: Dolby Vision and Dolby Atmos combine for purer images and multi-dimensional surround sound.



Subwoofer

Mejora los bajos y crea una experiencia de audio superior.

Figure 6.7: The integrated subwoofer enhances bass for a superior audio experience.

6.6 Gaming Features

- **Low Latency for Gaming (ALLM):** Automatically configures latency to improve your console gaming experience.

HDMITM
HIGH-DEFINITION MULTIMEDIA INTERFACE
VERSION 2.1

ALLM
Auto Low Latency Mode



Mejora la experiencia de juego de tu consola.

Figure 6.8: HDMI 2.1 with Auto Low Latency Mode (ALLM) improves your console gaming experience.

7. MAINTENANCE

- **Screen Cleaning:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a screen-specific cleaner. Do not spray liquid directly onto the screen.
- **Cabinet Cleaning:** Use a soft, dry cloth to clean the TV cabinet.
- **Dusting:** Regularly dust the ventilation openings to prevent overheating.

8. TROUBLESHOOTING

If you encounter issues with your television, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No Power	Power cable disconnected; Power outlet issue.	Check power cable connection. Try a different outlet.
No Picture, but Sound is Present	Incorrect input source; Loose HDMI/AV cable.	Select correct input source. Reconnect cables securely.
No Sound, but Picture is Present	Volume muted or too low; Audio settings incorrect.	Unmute volume or increase level. Check audio output settings.
Remote Control Not Working	Dead batteries; Obstruction between remote and TV.	Replace batteries. Remove any obstructions.
Wi-Fi Connection Issues	Incorrect password; Router issues; TV too far from router.	Verify password. Restart router. Move TV closer or use Ethernet.

If the problem persists after trying these solutions, please contact Cecotec customer support.

9. SPECIFICATIONS

Feature	Detail
Model Number	VQU11070Z+S (03632)
Screen Size	70 inches / 178 cm
Display Technology	QLED
Resolution	4K UHD (3840 x 2160 pixels)
Operating System	Android TV 11
Refresh Rate	50 Hz
Special Features	Chromecast Built-in, HDR10+, Dolby Vision, Dolby Atmos, Subwoofers, Google Voice Assistant, MEMC, 10-Bit Display, Low Latency for Gaming (HDMI 2.1 ALLM), Rotative Central Stand, Eye Safe (minimizes blue light emission)
Connectivity	Ethernet, Wi-Fi (implied by Android TV), HDMI 2.1
Aspect Ratio	16:9
Product Dimensions (with stand)	27.9 cm (depth) x 157.5 cm (width) x 92.4 cm (height)
Product Weight	27.58 kg

Feature	Detail
Energy Efficiency Class	F (based on 114 kWh/1000h)
Origin	Spain



ENERG



CECOTEC

VQU11070Z+S




114 kWh/1000h

ABCDEF **G**



194 kWh/1000h



50689813

2019/2013

Figure 9.1: Energy efficiency label for the Cecotec QLED 70" Smart TV. For more details, scan the QR code or visit eprel.ec.europa.eu/qr/1677956.

10. WARRANTY AND SUPPORT





Your Cecotec QLED 70" Smart TV is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, service, or inquiries, please visit the official Cecotec website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty claims.

For more information, visit the official Cecotec store: [Cecotec Store](#)

© 2024 Cecotec. All rights reserved.

[gen_bottom_of_page]

Related Documents - VQU11070Z+S

	<p>Manuale Cecotec TV LED A3 e QLED V2/V3: Istruzioni e Sicurezza</p> <p>Guida completa per i televisori Cecotec delle serie TV LED A3 e TV QLED V2/V3. Include istruzioni di sicurezza, installazione, uso, manutenzione e risoluzione problemi.</p>
	<p>Manual de Usuario Motocicleta Eléctrica Cecotec Halo</p> <p>Guía completa para la motocicleta eléctrica Cecotec Halo. Aprenda sobre su funcionamiento, seguridad, mantenimiento y especificaciones técnicas para un uso óptimo y seguro.</p>
	<p>Cecotec TV O SERIES 0024 / TV O SERIES 0032: Manual de Instrucciones y Guía de Usuario</p> <p>Explore el manual de instrucciones completo para los televisores LED Cecotec TV O SERIES 0024 y 0032. Encuentre información detallada sobre instalación, configuración, menús, solución de problemas y especificaciones técnicas para optimizar su experiencia visual.</p>
	<p>Cecotec BIGDRY 2500 PURE LIGHT Deshumidificador - Manual de Instrucciones</p> <p>Manual de instrucciones para el Cecotec BIGDRY 2500 PURE LIGHT, un deshumidificador diseñado para uso doméstico. Incluye información sobre seguridad, funcionamiento, limpieza y mantenimiento.</p>



[Manual de Usuario Cecotec ReadyWarm 2070 Max Force Black Termoventilador | Instrucciones y Especificaciones](#)

Manual completo del termoventilador Cecotec ReadyWarm 2070 Max Force Black (modelo 08254). Incluye instrucciones de seguridad, funcionamiento, limpieza, mantenimiento y especificaciones técnicas para un uso óptimo y seguro.



[Cecotec Cecofry&Grill Smokin' 6500: Руководство пользователя для Цифровой мультипечи с двумя нагревательными элементами и коптильней](#)

Полное руководство пользователя для Cecotec Cecofry&Grill Smokin' 6500. Инструкции по эксплуатации, безопасности, чистке, уходу и технические характеристики мультипечи с функцией гриля и коптильни.