

Cecotec ReadyWarm 2000 Power Tower (Model 08264)

Cecotec ReadyWarm 2000 Power Tower Outdoor Electric Heater User Manual

Model: ReadyWarm 2000 Power Tower (08264)

Brand: Cecotec

1. INTRODUCTION

Thank you for choosing the Cecotec ReadyWarm 2000 Power Tower Outdoor Electric Heater. This manual provides essential information for the safe and effective use, installation, and maintenance of your new heater. Please read these instructions thoroughly before operating the appliance and retain them for future reference.

The ReadyWarm 2000 Power Tower is designed to provide instant, pleasant heat for outdoor spaces, featuring 2000W of power, halogen technology, three adjustable power levels, remote control operation, and an LCD display. Its IP34 protection ensures safe outdoor placement.

2. SAFETY INSTRUCTIONS

Always observe basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the voltage indicated on the rating label matches your mains voltage before connecting the appliance.
- Do not operate the heater with a damaged cord or plug, or if the heater malfunctions or has been dropped or damaged in any manner.
- This heater is designed for outdoor use and features IP34 protection against splashing water. However, do not immerse the heater in water or other liquids.
- Keep flammable materials (e.g., furniture, curtains, paper) at least 1 meter (3 feet) away from the heater.
- Do not cover the heater or obstruct its air inlets/outlets.
- Always unplug the heater when not in use, before cleaning, or before moving it.
- Do not allow children or persons with reduced physical, sensory, or mental capabilities to operate the heater without supervision.
- Avoid touching the heating elements when the heater is operating or immediately after it has been turned off, as they will be extremely hot.
- Ensure the heater is placed on a stable, level surface to prevent tipping.
- The heater is equipped with a triple safety system for enhanced protection.

3. PRODUCT COMPONENTS





Figure 1: Overview of the Cecotec ReadyWarm 2000 Power Tower heater and its remote control.

1. Main Heater Unit (Column)
2. Base
3. Halogen Heating Elements
4. Control Panel with LCD Display
5. Remote Control
6. Power Cord

4. SETUP

Follow these steps to set up your ReadyWarm 2000 Power Tower heater:

1. **Unpacking:** Carefully remove all packaging materials. Inspect the heater for any signs of damage. If damaged, do not use it and contact customer support.
2. **Assembly:** Attach the base to the main heater unit according to the instructions provided in the separate assembly guide (if applicable). Ensure all screws are tightened securely.
3. **Placement:** Place the heater on a firm, level, and stable outdoor surface. Ensure there is at least 1 meter (3 feet) of clear space around the heater from any walls, furniture, or other objects. Do not place it directly under a power outlet.
4. **Power Connection:** Plug the power cord into a suitable outdoor electrical outlet. Ensure the outlet is protected and rated for outdoor use.



Figure 2: Proper placement of the heater in an outdoor setting.

5. OPERATING INSTRUCTIONS

The ReadyWarm 2000 Power Tower can be operated via its integrated control panel or the included remote control.

5.1. Control Panel



Figure 3: Detailed view of the heater's control panel and LCD display.

The control panel is located at the top of the heater and features an LCD display and several buttons:

- **Power Button ():** Turns the heater on or off.
- **Mode/Level Button:** Cycles through the 3 power levels (P1, P2, P3).
- **Timer Button ():** Activates and adjusts the programmable timer.

5.2. Remote Control



Figure 4: Using the remote control to operate the heater.

The remote control provides convenient access to all heater functions:

- **Power Button:** Turns the heater on or off.
- **Power Level Buttons (e.g., 650W, 1350W, 2000W):** Directly select one of the three power levels.
- **Timer Button:** Activates and adjusts the programmable timer.

5.3. Power Levels

The heater offers 3 power levels to suit different heating needs:

- **Level 1 (P1):** Lower heat output for mild conditions or smaller areas.
- **Level 2 (P2):** Medium heat output.
- **Level 3 (P3):** Maximum heat output (2000W) for colder conditions or larger areas.



Figure 5: The heater features 3 distinct power levels.

5.4. Programmable Timer

The heater includes a programmable timer that allows you to set the desired operating time for up to 24 hours. Press the Timer button on the control panel or remote control to activate and adjust the timer. The selected time will be displayed on the LCD screen.



Figure 6: The timer function allows for scheduled operation.

6. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your heater.

- Cleaning:** Before cleaning, always unplug the heater and allow it to cool completely. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Storage:** When not in use for extended periods, store the heater in a cool, dry place, protected from dust and moisture. It is recommended to cover the heater to prevent dust accumulation.
- Inspection:** Periodically check the power cord and plug for any signs of damage. If any damage is found, discontinue use and contact qualified service personnel.

7. TROUBLESHOOTING

If you encounter issues with your heater, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply; Power cord not properly plugged in; Unit is off.	Check power outlet; Ensure plug is fully inserted; Press the power button.
No heat output.	Power level set too low; Heating elements damaged.	Increase power level; Contact customer support if elements appear damaged.
Remote control not working.	Batteries depleted; Obstruction between remote and heater.	Replace batteries; Ensure clear line of sight to the heater's receiver.

Problem	Possible Cause	Solution
Heater turns off unexpectedly.	Overheating protection activated; Timer function engaged.	Unplug, let cool, then restart; Check timer settings.

If the problem persists after attempting these solutions, please contact Cecotec customer support.

8. SPECIFICATIONS

Brand	Cecotec
Model Number	08264
Color	Black
Product Dimensions (L x W x H)	10.5 x 29.5 x 29.5 cm
Power	2000 Watts
Voltage	230 Volts
Number of Power Levels	3
Features	Programmable Timer, Remote Control, LCD Display
Item Weight	5.55 Kilograms
IP Rating	IP34 (Outdoor Use)
Heating Method	Radiant (Halogen Technology)
Country of Origin	Spain

9. WARRANTY AND SUPPORT

Cecotec products are manufactured to high-quality standards. In the unlikely event of a defect, please refer to your purchase documentation for warranty terms and conditions.

- Spare Parts Availability:** Spare parts for this model are available for up to 10 years from the date of purchase.
- Customer Support:** For technical assistance, warranty claims, or general inquiries, please visit the official Cecotec website or contact your local retailer.

© 2024 Cecotec. All rights reserved.

Related Documents - ReadyWarm 2000 Power Tower (Model 08264)

	<p><u>Cecotec ReadyWarm 4000/6000/8000 Thermal Ceramic Connected: Manual de Instrucciones y Características</u></p> <p>Descubra el Cecotec ReadyWarm 4000/6000/8000 Thermal Ceramic Connected, un termoventilador vertical inteligente. Este manual de instrucciones cubre su funcionamiento, seguridad y especificaciones.</p>
	<p><u>Cecotec ReadyWarm 6500 Turbo Convection Heater - User Manual and Safety Guide</u></p> <p>This comprehensive user manual provides detailed instructions for the Cecotec ReadyWarm 6500 Turbo Convection heater, covering safety guidelines, operation, cleaning, maintenance, technical specifications, and disposal information.</p>
	<p><u>Cecotec ReadyWarm 2000 Power Tower: Manual de Instrucciones y Seguridad</u></p> <p>Guía completa para el Cecotec ReadyWarm 2000 Power Tower, un calefactor de torre diseñado para uso en exteriores. Incluye instrucciones de uso, seguridad, mantenimiento y especificaciones técnicas.</p>
	<p><u>Manual de Usuario Cecotec ReadyWarm 2070 Max Force Black Termoventilador Instrucciones y Especificaciones</u></p> <p>Manual completo del termoventilador Cecotec ReadyWarm 2070 Max Force Black (modelo 08254). Incluye instrucciones de seguridad, funcionamiento, limpieza, mantenimiento y especificaciones técnicas para un uso óptimo y seguro.</p>
	<p><u>Cecotec ReadyWarm 9750 Rotate Force Upright Fan Heater - User Manual</u></p> <p>Explore the Cecotec ReadyWarm 9750 Rotate Force upright fan heater. This manual provides essential operating instructions, safety guidelines, and technical details for efficient heating in well-insulated spaces.</p>
	<p><u>Cecotec ReadyWarm 9750 Rotate Force Upright Fan Heater - User Manual</u></p> <p>Comprehensive user manual for the Cecotec ReadyWarm 9750 Rotate Force upright fan heater, including safety instructions, operation guide, technical specifications, and warranty information.</p>

