ChooChoo EUR-ET2203-1T15L

ChooChoo Farmhouse End Table (Model EUR-ET2203-1T15L) Instruction Manual

Brand: ChooChoo

1. Introduction

Thank you for choosing the ChooChoo Farmhouse End Table. This manual provides essential information for the safe assembly, proper use, and maintenance of your new furniture. This narrow side table, featuring a rustic A-design and a convenient storage shelf, is designed to complement various living spaces, including living rooms and bedrooms.



Image 1.1: ChooChoo Farmhouse End Table in a living room setting, showcasing its design and functionality.

2. Safety Information

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always follow the assembly instructions carefully.
- Do not exceed the maximum weight recommendation of 45 pounds to maintain stability.
- Keep the table away from heat sources and sharp objects to prevent damage.
- Always use the table on a flat, stable surface.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.

3. Package Contents

Before beginning assembly, please verify that all components are present and undamaged. Refer to the diagram below for a visual representation of the parts.



Image 3.1: Exploded view of the end table components and hardware, labeled for easy identification.

The package includes all necessary parts and accessories, clearly marked for a straightforward assembly process.

4. Assembly Instructions

Assembly of the ChooChoo Farmhouse End Table is designed to be quick and easy. Follow the step-by-step instructions provided in the included manual and refer to the diagrams for guidance.

1. **Step 1: Attach Table Legs to Bottom Panel.** Use the provided bolts and wooden dowels to secure the table legs (2 and 3) to the bottom panel (4).
2. **Step 2: Attach Table Legs to Top Panel.** Secure the remaining table legs (2 and 3) to the top panel (1) using the designated hardware.
3. **Step 3: Install A-Frame Supports.** Attach the metal A-frame supports to the side panels using the

provided screws. Ensure they are oriented correctly for stability.

4. **Step 4: Final Tightening.** Once all parts are in place, carefully tighten all screws and fasteners. Do not overtighten.



Image 4.1: Detailed assembly steps, illustrating how to connect the table components.

Tools recommended for assembly include an Allen Key and a screwdriver, which are typically included with the hardware.

5. Usage Guidelines

The ChooChoo Farmhouse End Table is a versatile piece of furniture designed for various applications in your home. Its compact dimensions (23.6"D x 11.8"W x 22.4"H) make it ideal for small spaces.

- **As a Sofa Side Table:** Place it next to your sofa to keep snacks, beverages, and remote controls within easy reach.
- **As a Nightstand:** Utilize it in the bedroom to hold your mobile phone, alarm clock, or reading materials.
- **As a Computer Host Table:** Its narrow design can accommodate a computer tower or other small electronic devices.



Image 5.1: The end table serving as a nightstand, demonstrating its suitability for bedroom use.



Image 5.2: The end table positioned beside a sofa, highlighting its function as a convenient side table.

6. Maintenance and Care

To ensure the longevity and appearance of your ChooChoo Farmhouse End Table, follow these simple care instructions:

- **Cleaning:** The surface is scratch-resistant and waterproof. Wipe clean with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Protection:** Use coasters under drinks to prevent water rings and heat damage.
- **Stability:** Periodically check all fasteners and re-tighten if necessary to maintain structural integrity.
- **Placement:** Avoid prolonged exposure to direct sunlight or extreme temperature changes, which can affect the wood finish.




Image 6.1: Key features of the table, including its MDF material, metal corners for protection, A-shaped metal frame for strength, and non-slip stickers for floor protection.

7. Troubleshooting

If you encounter any issues with your end table, please refer to the following common solutions:

- **Wobbly Table:** Ensure all screws and bolts are fully tightened. Check that the table is on a level surface. Adjust non-slip stickers if needed.
- **Missing Parts:** If any parts were missing upon delivery, please contact customer support immediately with your purchase details.

- **Surface Damage:** For minor scratches, wood repair kits can be used. For significant damage, contact customer support for advice.

8. Specifications

Feature	Detail
Brand	ChooChoo
Model Number	EUR-ET2203-1T15L
Product Dimensions (D x W x H)	11.81" x 23.62" x 22.44"
Maximum Weight Recommendation	45 Pounds
Color	White & Brown
Material Type	Engineered Wood (MDF), Metal
Item Weight	19.18 Pounds
Tools Recommended For Assembly	Allen Key, Screw Driver

9. Warranty and Support

For any questions, concerns, or support needs regarding your ChooChoo Farmhouse End Table, please contact our customer service department. While specific warranty details are not provided in this manual, ChooChoo is committed to providing high-quality products and customer satisfaction.
Please retain your purchase receipt for any potential claims or inquiries.