



[Manuals.plus](#) /

> [OKD](#) /

> OKD Farmhouse TV Stand User Manual

OKD BDC66TC-ROWAW

OKD Farmhouse TV Stand User Manual

MODEL: BDC66TC-ROWAW

Product Overview

The OKD Farmhouse TV Stand is a rustic wood entertainment center designed to accommodate televisions up to 75 inches. It features sliding barn doors, adjustable interior shelves, and a sturdy construction, blending modern and farmhouse aesthetics to enhance your living space.



Image: The OKD Farmhouse TV Stand in Antique White, featuring a large television on its top surface and decorative items on its shelves. The sliding barn doors are partially open, revealing interior storage.

Safety Information

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Keep away from sharp objects during use to prevent scratches or damage to the wood finish.
- Ensure proper assembly by following all steps in the instruction manual to guarantee stability and longevity of the TV stand.
- Avoid prolonged exposure to extreme temperatures or humidity, as this may affect the wood material.
- Do not overload the shelves or the top surface beyond the specified weight capacities to prevent collapse or damage.
- Always place the TV stand on a flat, level surface to ensure stability and prevent wobbling.

Setup and Assembly

The OKD Farmhouse TV Stand is designed for straightforward assembly. All necessary parts, hardware kits, and clear instructions are included in the package. It is recommended that 1-2 people complete the assembly, which typically takes about 1.5-2 hours.

Pre-Assembly Checklist:

1. Verify all parts are present according to the parts list in the included assembly guide.
2. Ensure you have the required tools (e.g., screwdriver, hammer) as specified in the assembly guide.
3. Clear a spacious area for assembly to prevent damage to components or flooring.

Assembly Tips:

- Follow the step-by-step instructions provided in the separate assembly manual.
- Do not overtighten screws to avoid stripping or damaging the wood.
- The packaging includes protection boards to prevent damage during shipping; retain these until assembly is complete.




Image: An illustration detailing the dimensions of the TV stand (66" W x 15.7" D x 24.7" H) and the weight capacities for the top surface (150 lbs) and interior shelves (30 lbs and 50 lbs).




Image: A visual representation of the TV stand's compatibility with different television sizes, indicating it fits TVs up to 75 inches, with examples for 32", 50", 55", 65", 70", and 75" TVs.

Operating Instructions

Sliding Barn Doors:

The TV stand features smooth-gliding barn doors on a metal track. To access the cabinets, gently slide the doors along the track to the desired position. The doors can be positioned to cover either the side compartments or the central open shelves, allowing for flexible display and storage options.

Adjustable Shelves:

The interior shelves are adjustable, providing customizable storage space for media devices, books, or decorative items. To adjust a shelf, remove any items, lift the shelf, and reposition it into the desired set of shelf pin holes. Ensure the shelf is level and securely seated before placing items on it.

Cable Management:

Two cable management holes are located on the back panel behind the central shelves. These holes allow for easy routing and organization of power cords and audio/video cables, helping to keep wires tidy and out of sight.



Adjustable Shelves

- Adjustable shelves for flexible and customizable storage.



Sliding Barn Door

- Smooth track, easily access to your cabinet.



Spacious Rustic Tabletop

- Support flat screen TVs up to 75".
- Adding a farmhouse charming to your home.



Image: A detailed view highlighting the adjustable shelves within the cabinet and the smooth sliding mechanism of the barn doors on their metal track.



Stable Base

- The 3.34-inch high wooden base ensures stability and no wobbling.

Large Cable Hole

- Large holes allow cables to through easily and keep them tidy.



Metal Corner Decor

- Premium matte metal decor complements the farmhouse style.

Image: Close-up images showing the 3.34-inch high wooden support base for stability, the large cable hole for wire organization, and the premium matte metal corner decor accents.

Maintenance

To maintain the appearance and longevity of your OKD Farmhouse TV Stand, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a dry cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the woodgrain paper finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent water damage or staining.
- **Sunlight:** Avoid placing the TV stand in direct sunlight for prolonged periods, as this can cause fading or discoloration of the finish.
- **Heat:** Do not place hot items directly on the surface. Use coasters or protective pads if necessary.

Troubleshooting

This section addresses common issues you might encounter with your TV stand.

Wobbling or Instability:

- **Check Assembly:** Ensure all screws and fasteners are securely tightened. Refer to the assembly manual to confirm all steps were followed correctly.
- **Level Surface:** Verify that the TV stand is placed on a flat and level floor. Use furniture pads or shims if necessary to stabilize it on uneven surfaces.
- **Overload:** Ensure the stand is not overloaded beyond its weight capacity. Distribute weight evenly.

Sliding Doors Sticking:

- **Track Cleanliness:** Inspect the metal track for any debris or obstructions. Clean the track with a dry cloth.
- **Alignment:** Check if the doors are properly aligned on the track. Gently lift and reseal them if they appear off-track.

Damaged or Missing Parts:

- If you receive damaged parts or find components missing, please contact customer support immediately with your purchase details. Do not attempt to assemble with damaged or missing parts.

Specifications

Feature	Detail
Brand	OKD
Model Number	BDC66TC-ROWAW
Color	Antique White
Material	Engineered Wood
Product Dimensions (L x W x H)	66 x 15.75 x 24.75 inches
Item Weight	90 pounds
Number of Shelves	6 (including adjustable interior shelves)
Max TV Size Compatibility	Up to 75 inches
Top Surface Weight Capacity	150 lbs
Interior Shelf Weight Capacity	30 lbs (upper), 50 lbs (lower)
Product Care Instructions	Wipe with Dry Cloth
GTIN (Global Trade Identification Number)	00850072932422

Warranty Information

This product is typically covered by a standard return policy. For specific warranty details, please refer to your purchase documentation or contact the seller directly.

Return Policy:

- A 30-day easy return policy is generally offered for this product. Please check your specific retailer's return policy for full details and conditions.

Protection Plans:

Extended protection plans may be available for purchase separately to cover your product beyond the standard return period. These plans typically offer:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly subscription covering multiple eligible purchases)

For details on coverage, pricing, and terms, please consult the provider of these protection plans.

Customer Support

For any questions, concerns, or assistance with your OKD Farmhouse TV Stand, please contact our customer support team.

- **Manufacturer:** OKD
- **Seller:** OKD-us
- **Contact:** Refer to your purchase platform or the included documentation for direct contact methods (e.g., phone number, email, website).
- When contacting support, please have your model number (BDC66TC-ROWAW) and purchase date readily available.

© 2023 OKD. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.