

## Cecotec 01851

# Cecotec 4-in-1 Espresso Coffee Machine User Manual

Model: 01851

## 1. INTRODUCTION

Thank you for choosing the Cecotec 4-in-1 Espresso Coffee Machine. This versatile appliance is designed to provide you with a rich coffee experience, supporting ground coffee, Nespresso, Dolce Gusto, and K-Fee capsules. Please read this manual thoroughly before first use to ensure safe operation and optimal performance. Keep this manual for future reference.

## 2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Read all instructions carefully before operating the appliance.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Unplug the machine from the power outlet when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep hands and cords away from hot parts of the appliance during operation.
- Use only cold, fresh water in the water tank. Do not use milk or other liquids.
- This appliance is for household use only. Do not use outdoors.
- Children should be supervised to ensure they do not play with the appliance.

## 3. PACKAGE CONTENTS

Please check the contents of the box. If any items are missing or damaged, contact your retailer.

- Cecotec 4-in-1 Espresso Coffee Machine
- Ground Coffee Adapter
- Nespresso Capsule Adapter
- Dolce Gusto Capsule Adapter
- K-Fee Capsule Adapter
- Removable Water Tank (800 ml capacity)
- Drip Tray
- User Manual

## **4. PRODUCT OVERVIEW**

---

Familiarize yourself with the components of your Cecotec coffee machine.



Figure 1: Cecotec 4-in-1 Espresso Coffee Machine brewing coffee, with various capsule adapters shown on the side.



Figure 2: Front view of the Cecotec 4-in-1 Espresso Coffee Machine.



Figure 3: Angled view of the Cecotec 4-in-1 Espresso Coffee Machine, highlighting its compact design.



Figure 4: Cecotec 4-in-1 Espresso Coffee Machine on a wooden counter with various coffee capsules and a ground coffee filter basket.



Figure 5: Side view of the Cecotec 4-in-1 Espresso Coffee Machine, showing the removable water tank.



Figure 6: Close-up of the Cecotec 4-in-1 Espresso Coffee Machine brewing espresso into a glass cup.





Figure 7: Cecotec 4-in-1 Espresso Coffee Machine on a counter with an icon indicating its 15-minute automatic shut-off feature.

## 5. SETUP

1. **Unpacking:** Carefully remove all packaging materials and check for any damage. Keep packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash the water tank and drip tray with warm, soapy water. Wipe the exterior of the machine with a damp cloth.
3. **Fill Water Tank:** Remove the water tank from the back of the machine. Fill it with fresh, cold water up to the MAX line (800 ml capacity). Place the tank back securely.
4. **First Use / Priming:**
  - Place a large cup or container under the coffee outlet.
  - Plug the machine into a grounded power outlet. The power button will illuminate.
  - Press the power button to turn on the machine. It will begin heating (pre-heating time is approximately 30 seconds).
  - Once heated, select the Lungo (100 ml) option without any coffee or capsule inserted. Let the water run through to clean the internal system. Repeat this process 2-3 times.

5. **Positioning:** Place the machine on a stable, flat, heat-resistant surface, away from heat sources and direct sunlight.

## 6. OPERATING INSTRUCTIONS

---

The Cecotec 4-in-1 machine offers flexibility for various coffee types.

### General Operation:

1. Ensure the water tank is filled with fresh water.
2. Turn on the machine by pressing the power button. Wait for the machine to pre-heat (approx. 30 seconds).
3. Insert the appropriate adapter for your chosen coffee type.
4. Place your cup on the drip tray. The machine is suitable for cups of different sizes.
5. Select your desired coffee volume: Espresso (50 ml), Lungo (100 ml), or Large coffee (150 ml). The machine will automatically dispense the selected volume.
6. After brewing, remove the cup and dispose of the used coffee/capsule.
7. The machine features an energy-saving system with automatic shutdown after 9 minutes of inactivity and a standby mode.

### Using Ground Coffee:

1. Insert the Ground Coffee Adapter into the machine.
2. Add your desired amount of ground coffee into the filter basket of the adapter. Do not overfill.
3. Close the adapter securely.
4. Proceed with general operation steps 4-6.

### Using Nespresso, Dolce Gusto, or K-Fee Capsules:

1. Select the corresponding capsule adapter (Nespresso, Dolce Gusto, or K-Fee).
2. Insert the chosen adapter into the machine.
3. Place your capsule into the adapter.
4. Close the adapter securely.
5. Proceed with general operation steps 4-6.

*Note: No official product videos were available for inclusion in this manual.*

## 7. MAINTENANCE AND CLEANING

---

Regular cleaning ensures the longevity and optimal performance of your coffee machine.

### Daily Cleaning:

- **Drip Tray:** Empty and rinse the drip tray after each use or when the indicator shows it's full.
- **Water Tank:** Rinse the water tank daily and refill with fresh water.
- **Adapters:** Remove and rinse the used coffee adapter after each use.

- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents.

**Descaling:**

Descaling is essential to remove mineral deposits that can affect machine performance and coffee taste. The frequency depends on water hardness and usage, but generally every 2-3 months.

1. Empty the water tank and fill it with a descaling solution (follow descaler manufacturer's instructions) or a mixture of white vinegar and water (1:1 ratio).
2. Place a large container under the coffee outlet.
3. Run several cycles of Lungo (100 ml) until the water tank is empty.
4. Rinse the water tank thoroughly and fill it with fresh water.
5. Run several cycles of Lungo with fresh water to rinse out any descaling solution residue.

**8. TROUBLESHOOTING**

If you encounter issues with your coffee machine, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Machine does not turn on	Not plugged in; Power outlet malfunction; Machine fault.	Check power plug and outlet; Try a different outlet; Contact customer support.
No coffee dispenses	Water tank empty; Air in the system; Clogged nozzle.	Fill water tank; Run a priming cycle (Lungo without coffee); Descale the machine.
Coffee is too weak	Insufficient coffee grounds/capsule; Incorrect grind size (for ground coffee); Machine needs descaling.	Use more coffee/fresh capsule; Use finer grind; Descale the machine.
Leaking from machine	Water tank not seated correctly; Drip tray full; Internal seal issue.	Ensure water tank is properly inserted; Empty drip tray; Contact customer support.
Coffee is not hot enough	Machine not fully pre-heated; Cold cup.	Wait for pre-heating indicator; Pre-heat cup with hot water.

**9. SPECIFICATIONS**

Feature	Specification
Brand	Cecotec
Model Number	01851

Feature	Specification
Color	Black
Product Dimensions (D x W x H)	26.2 cm x 11.7 cm x 26.2 cm
Capacity	800 milliliters
Power	1350 watts
Voltage	230 volts
Material	Metal
Automatic Shut-off	Yes (after 9 minutes)
Special Features	Cup warmer, Automatic shut-off
Item Weight	3 Kilograms
Coffee Maker Type	Espresso Machine
Filter Type	Weiderfer Windbar
Style	Modern
Specific Uses	Espresso


## 10. WARRANTY AND SUPPORT






Your Cecotec 4-in-1 Espresso Coffee Machine is covered by a manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details.


For technical support, troubleshooting assistance, or to inquire about spare parts, please contact Cecotec customer service through their official website or the contact information provided with your purchase documentation.

Keep your proof of purchase (receipt or invoice) as it will be required for any warranty claims.

### Related Documents - 01851

	<p><a href="#">Cecotec FreeStyle Compact Black Coffee Machine User Manual</a></p> <p>Comprehensive user manual for the Cecotec FreeStyle Compact Black coffee machine, covering safety instructions, parts and components, operation, cleaning and maintenance, troubleshooting, technical specifications, and warranty information.</p>
---	--

	<p><a href="#">Cecotec Power Espresso 20 Matic: User Manual &amp; Instructions</a></p> <p>Comprehensive user manual for the Cecotec Power Espresso 20 Matic espresso machine, covering safety instructions, operation, cleaning, troubleshooting, and technical specifications.</p>
	<p><a href="#">Manual de Instrucciones Cecotec Power Espresso 20 Barista Mini   Cafetera Espresso</a></p> <p>Descubra cómo usar su Cecotec Power Espresso 20 Barista Mini con este completo manual de instrucciones. Incluye seguridad, operación, limpieza y solución de problemas para su cafetera espresso.</p>
	<p><a href="#">Cecotec Cumbia Power Espresso 20 Matic: Manual de Instrucciones y Guía de Usuario</a></p> <p>Manual de instrucciones completo para la cafetera espresso Cecotec Cumbia Power Espresso 20 Matic, que cubre seguridad, funcionamiento, limpieza, solución de problemas e información de garantía.</p>
	<p><a href="#">Cecotec Power Espresso 20 Steel Pro User Manual</a></p> <p>Comprehensive user manual for the Cecotec Power Espresso 20 Steel Pro coffee maker, covering safety instructions, operation, cleaning, maintenance, and troubleshooting.</p>
	<p><a href="#">Cecotec Cumbia Power Espresso 20: User Manual and Operating Guide</a></p> <p>Comprehensive user manual for the Cecotec Cumbia Power Espresso 20 espresso machine, covering safety, operation, cleaning, maintenance, troubleshooting, and technical specifications.</p>



[\[pdf\]](#) User Manual Instructions Troubleshooting Guide Specifications Warranty  
FREESTYLE COMPACT BLACK 9 nov 2024 — FreeStyle Compact Black coffee machine Instruction manual 3 OPERATION Control panel Button functions Fig 2 instrukcja obsługi CECOTEC Freestyle Compac mediaexpert.pl products/files/69/6968410 |||  
FREESTYLE COMPACT BLACK Cafetera de cpsulas compacta / Compact pod coffee machine Manual de instrucc ... e nuevo. FREESTYLE COMPACT BLACK 41 ESPAOL 6. ESPECIFICACIONES TCNICAS Referencia del producto: **01851**  
Producto: Cafetera FreeStyle Compact Black Voltaje: 220 - 240 V - Frecuencia: 50 - 60 Hz Poten...  
lang:it **score:35** filesize: 3.19 M page\_count: 118 document date: 2024-04-10




[\[pdf\]](#) User Manual Instructions Troubleshooting Guide Specifications Warranty  
FREESTYLE COMPACT BLACK Appliance Hub The surface of Page 4 9 8 FreeStyle Compact Black coffee machine Instruction manual 3 User appliancehub.mt/content/docs/products/26599/web |||  
FREESTYLE COMPACT BLACK Cafetera de cpsulas compacta / Compact pod coffee machine Manual de instrucc ... ng that the machine is ready to brew coffee again. 6. TECHNICAL SPECIFICATIONS Product reference: **01851** Product: FreeStyle Compact Black coffee machine Voltage: 220 - 240 V- Frequency: 50 - 60 Hz Ra...  
lang:it **score:32** filesize: 355.66 K page\_count: 9 document date: 2024-12-04



[\[pdf\]](#) User Manual Instructions Troubleshooting Guide Specifications Warranty  
FREESTYLE COMPACT BLACK freestyle compact black user manual cdn cecotec.cloud/media/files |||  
FREESTYLE COMPACT BLACK Cafetera de cpsulas compacta / Compact pod coffee machine Manual de instrucc ... e nuevo. FREESTYLE COMPACT BLACK 41 ESPAOL 6. ESPECIFICACIONES TCNICAS Referencia del producto: **01851**  
Producto: Cafetera FreeStyle Compact Black Voltaje: 220 - 240 V - Frecuencia: 50 - 60 Hz Poten...  
lang:it **score:29** filesize: 740.81 K page\_count: 60 document date: 2024-04-10





[\[pdf\]](#) User Manual Instructions Troubleshooting Guide Specifications Warranty  
FREESTYLE COMPACT BLACK instrukcja obsługi CECOTEC Freestyle Compac electro pl products files  
69 6968410 Nov 9 2024 — INSTRUCCIONES DE SEGURIDAD Lea las siguientes instrucciones  
atentamente antes de usar el producto Guarde este manual para referencias futuras o |||  
FREESTYLE COMPACT BLACK Cafetera de cpsulas compacta / Compact pod  
coffee machine Manual de instrucc ... e nuevo. FREESTYLE COMPACT BLACK 41  
ESPAOL 6. ESPECIFICACIONES TCNICAS Referencia del producto: **01851**  
Producto: Cafetera FreeStyle Compact Black Voltaje: 220 - 240 V - Frecuencia: 50 -  
60 Hz Poten...  
lang:it **score:24** filesize: 1.39 M page\_count: 118 document date: 2024-04-10



[\[pdf\]](#) User Manual Instructions Troubleshooting Guide Specifications Warranty  
FREESTYLE COMPACT BLACK Triple ANo coloque el producto bajo armarios o muebles de cocina  
emite vapor y podría dañarlos No llene filtro másUser manualtriplea mt content docs products 7797 web  
User manual |||  
FREESTYLE COMPACT BLACK Cafetera de cpsulas compacta / Compact pod  
coffee machine Manual de instrucc ... ng that the machine is ready to brew coffee  
again. 6. TECHNICAL SPECIFICATIONS Product reference: **01851** Product:  
FreeStyle Compact Black coffee machine Voltage: 220 - 240 V- Frequency: 50 - 60  
Hz Ra...  
lang:it **score:20** filesize: 355.66 K page\_count: 9 document date: 2024-12-04



[\[pdf\]](#) User Manual Instructions Troubleshooting Guide Specifications Warranty  
Manual de usuarioCecotec Cafetera Cápsulas Express Compacta FreeStyle Compact Black 1350W 20  
Bares Apta para Café Molido Dolce Gusto Nespresso y K fee Depósito Extraíble 800ml Apagado  
Automático Amazon es Hogar cocina91bAnYKFxTlM media amazon images I 91bAnYKFxTL ref dp  
product quick view |||  
FREESTYLE COMPACT BLACK Cafetera de cpsulas compacta / Compact pod  
coffee machine Manual de instrucc ... e nuevo. FREESTYLE COMPACT BLACK 41  
ESPAOL 6. ESPECIFICACIONES TCNICAS Referencia del producto: **01851**  
Producto: Cafetera FreeStyle Compact Black Voltaje: 220 - 240 V - Frecuencia: 50 -  
60 Hz Poten...  
lang:it **score:20** filesize: 740.81 K page\_count: 60 document date: 2024-04-10



[Cecotec FreeStyle Compact Black Coffee Machine User Manual](#)  
Comprehensive user manual for the Cecotec FreeStyle Compact Black coffee  
machine, covering safety instructions, parts and components, operation, cleaning and  
maintenance, troubleshooting, technical specifications, and warranty information.  
lang:it **score:18** filesize: 1.74 M page\_count: 18 document date: 2024-10-14

