

Cecotec 01718

Cecotec Super Automatic Coffee Machine User Manual

Model: 01718 - Cremmaet Macchia White Rose

1. INTRODUCTION

Welcome to the user manual for your new Cecotec Cremmaet Macchia Super Automatic Coffee Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read all instructions carefully before using the machine for the first time and keep this manual for future reference.

2. SAFETY INSTRUCTIONS

To ensure safe operation, always adhere to the following safety guidelines:

- **Electrical Safety:** Ensure the voltage indicated on the appliance matches your local mains voltage before connecting. Do not immerse the appliance, power cord, or plug in water or any other liquid. Do not operate the machine with a damaged cord or plug.
- **Heat and Hot Surfaces:** The coffee machine generates hot water and steam. Avoid contact with hot surfaces and steam to prevent burns. Always use handles and knobs.
- **Children and Vulnerable Persons:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Placement:** Place the machine on a stable, level, heat-resistant surface, away from water sources and direct sunlight. Ensure adequate ventilation around the appliance.
- **Cleaning:** Always unplug the machine before cleaning. Do not use abrasive cleaning agents or scourers.

3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your Cecotec Cremmaet Macchia coffee machine.



Figure 3.1: Front view of the Cecotec Cremmaet Macchia coffee machine, showcasing its compact design and elegant white and rose gold finish.



Figure 3.2: Close-up of the intuitive touch control panel located on the top of the machine, featuring various function icons.



Figure 3.3: The integrated coffee bean hopper with a conical grinder, allowing for fresh grinding of beans for each cup.



Figure 3.4: The removable 1.5-liter water tank, easily accessible for refilling and cleaning.

4. SETUP

Follow these steps to set up your coffee machine for the first time:

1. **Unpacking:** Carefully remove the machine from its packaging. Remove all protective films and packaging materials.
2. **Initial Cleaning:** Before first use, wash the water tank, drip tray, and coffee grounds container with warm water and a mild detergent. Rinse thoroughly and dry.
3. **Fill Water Tank:** Fill the removable water tank with fresh, cold drinking water up to the MAX level. Ensure the tank is properly seated in the machine.



Figure 4.1: Pouring fresh water into the machine's water tank.

4. **Add Coffee Beans:** Open the lid of the bean hopper and fill it with fresh whole coffee beans. The hopper has a capacity of 200g.



Figure 4.2: Adding whole coffee beans to the integrated grinder compartment.

5. **Plug In:** Connect the power cord to a suitable electrical outlet.
6. **First Use/Priming:** The machine may perform an initial rinse cycle when first turned on or after a period of inactivity. Follow any on-screen prompts or indicator lights.

5. OPERATING INSTRUCTIONS

Your Cecotec coffee machine is designed for ease of use with its Plug & Play system.

5.1. Turning On/Off

- Press the power button on the control panel to turn the machine on. The machine will heat up and perform a brief rinse cycle.



Figure 5.1: Activating the machine by pressing the power button on the touch control panel.

- Press the power button again to turn the machine off. It will perform a final rinse cycle before shutting down.

5.2. Adjusting Grind Settings

The integrated conical grinder offers 5 levels of grinding. Adjust the grind setting by rotating the dial inside the bean hopper. It is recommended to adjust the grinder only while it is operating to prevent damage.

5.3. Making Coffee

The machine can prepare espresso and American coffee.

1. Place a cup under the coffee spout.
2. Select your desired coffee type (e.g., Espresso, Americano) from the control panel.
3. The machine will automatically grind the beans, brew, and dispense your coffee.



Figure 5.2: Selecting a coffee option on the control panel as the machine prepares the beverage.



Figure 5.3: The machine actively dispensing freshly brewed coffee into a cup, highlighting the rich crema.



Figure 5.4: The machine's capability to brew and dispense two cups of coffee at once, ideal for sharing.

5.4. Customizing Coffee

You can easily customize and memorize the amount and intensity of your coffee to suit your taste preferences. Refer to the specific icons on the control panel for these adjustments.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your coffee machine.

- **Automatic Cleaning:** The machine features an automatic cleaning function to keep it clear at all times. This typically occurs upon startup and shutdown.
- **Emptying Grounds Container:** The machine will indicate when the coffee grounds container needs to be emptied. Remove and clean it regularly.
- **Cleaning Drip Tray:** The drip tray collects excess water and coffee spills. Empty and clean it frequently to prevent overflow and maintain hygiene.
- **Removable Parts:** Periodically remove and clean the water tank and other removable components as per the initial cleaning instructions.

- **Descaling:** Over time, mineral deposits can build up inside the machine. The machine will indicate when descaling is required. Use a suitable descaling solution designed for coffee machines and follow the instructions provided with the descaler.

7. TROUBLESHOOTING

If you encounter issues with your coffee machine, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Machine does not turn on	Not plugged in; power outage	Check power connection; check circuit breaker.
No coffee dispensed	Water tank empty; bean hopper empty; machine needs descaling.	Fill water tank; fill bean hopper; perform descaling cycle.
Coffee is too weak	Grind setting too coarse; insufficient coffee dose.	Adjust grind to a finer setting; increase coffee intensity setting.
Water leaks from machine	Water tank not properly seated; drip tray full.	Ensure water tank is correctly inserted; empty and clean drip tray.
Error indicator light on	Specific issue indicated by light (e.g., grounds full, water empty).	Refer to the machine's indicator light guide for specific meaning and action.

If the problem persists after attempting these solutions, please contact Cecotec customer support.

8. SPECIFICATIONS

Technical details for the Cecotec Cremmaet Macchia Super Automatic Coffee Machine:

Brand: Cecotec
Model Number: 01718
Colour: White Rose
Product Dimensions: 19 x 40 x 32 cm
Item Weight: 7.9 kg
Special Features: Removable Tank
Coffee Maker Type: Espresso Machine
Filter Type: Reusable
Pressure Pump: 19 bar
Heating System: Thermoblock
Coffee Tank Capacity: 200 g (integrated grinder)
Water Tank Capacity: 1.5 litres






9. WARRANTY AND SUPPORT

Your Cecotec Cremmaet Macchia Super Automatic Coffee Machine comes with a manufacturer's warranty. For detailed information regarding warranty terms and conditions, please refer to the warranty card included with your product or visit the official Cecotec website. For technical support, spare parts, or service, please contact Cecotec

customer service through their official channels.

© 2024 Cecotec. All rights reserved.

Related Documents - 01718

	<p>Cecotec Cremmaet Macchia Super-Automatic Coffee Machine User Manual</p> <p>Comprehensive user manual for the Cecotec Cremmaet Macchia super-automatic coffee machine, covering safety instructions, operation, cleaning, maintenance, and troubleshooting.</p>
	<p>Cecotec Cremmaet Compactccino Super-automatic Coffee Machine User Manual</p> <p>Comprehensive user manual for the Cecotec Cremmaet Compactccino Super-automatic Coffee Machine, covering safety instructions, operation, cleaning, maintenance, troubleshooting, and technical specifications.</p>
	<p>Cecotec Cremmaet Compactccino Super-automatic Coffee Machine User Manual</p> <p>Comprehensive user manual for the Cecotec Cremmaet Compactccino Super-automatic Coffee Machine. This guide provides detailed instructions on operation, cleaning, maintenance, and troubleshooting for models including Black, Black Rose, White Rose, and Black Silver. Learn to brew perfect coffee with your Cecotec machine.</p>
	<p>Cecotec Cremmaet Compact Automatic Coffee Machine User Manual</p> <p>Comprehensive user manual for the Cecotec Cremmaet Compact automatic coffee machine, covering safety instructions, operation, maintenance, troubleshooting, and technical specifications.</p>
	<p>Руководство пользователя Cecotec Cremmaet Compactccino Connected</p> <p>Полное руководство пользователя для автоматической кофемашины Cecotec Cremmaet Compactccino Connected. Содержит инструкции по безопасности, эксплуатации, уходу и устранению неполадок.</p>



[Cecotec Cremmaet Compactccino Coffee Machine User Manual](#)

Comprehensive user manual for the Cecotec Cremmaet Compactccino coffee machine, covering safety instructions, operation, cleaning, maintenance, and troubleshooting for models in black, black rose, white rose, and black silver.