Vactidy T8

Vactidy Nimble T8 Robot Vacuum and Mop Combo User Manual

Model: T8

1. INTRODUCTION

The Vactidy Nimble T8 is an advanced robot vacuum and mop combo designed to provide efficient and convenient floor cleaning. Equipped with GyroNav Navigation, it intelligently plans cleaning paths for thorough coverage. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Nimble T8 robot vacuum.

Image: The Vactidy Nimble T8 Robot Vacuum and Mop Combo, showcasing its sleek design, remote control, and smartphone app interface.

2. PACKAGE CONTENTS

Please check the package contents to ensure all items are present and in good condition.

Image: An illustration showing all components included in the Vactidy Nimble T8 package.

- Robot Vacuum and Mop *1
- 2-in-1 Dustbin & Water Tank *1
- Mopping Cloth *2
- Hepa Filters *2
- Cleaning Tool *1
- Side Brushes *4
- Remote Control *1
- Adapter *1
- Charging Base *1
- User Manual *1

3. PRODUCT FEATURES

- **2-in-1 Vacuum and Mop:** Seamlessly switches between vacuuming and mopping for comprehensive floor cleaning.
- **GyroNav Navigation:** Utilizes advanced gyroscope technology for systematic cleaning paths, ensuring efficient coverage and avoiding random patterns.
- **Smart App & Voice Control:** Control your robot vacuum via the Vactidy APP, Siri, or voice commands through Alexa and Google Assistant.
- **Super Slim Design:** With a height of 2.89 inches, the T8 can easily clean under furniture and hard-to-reach areas.
- **Self-Charging:** Automatically returns to its charging base when the battery is low or cleaning is complete.
- **Anti-Fall & Anti-Collision Sensors:** Equipped with sensors to prevent falls from stairs and collisions with obstacles.
- **Roller Brush System:** Features a roller brush for deeper cleaning, effectively removing dust and debris from various floor types.

Image: Comparison of GyroNav's effective zig-zag route versus a random cleaning path.

Remote Control

Image: Illustration of the T8's roller brush for deeper cleaning compared to a suction-only port.

2.89in
Slim Design

2.89In

Image: Underside view of the robot, highlighting anti-fall, anti-collision, roller brush, and side brushes.

Image: The slim profile of the T8 robot vacuum, demonstrating its ability to clean under low furniture.

4. SETUP GUIDE

4.1 Initial Charging

Before first use, fully charge the robot vacuum. Place the charging base against a wall in an open, uncluttered area. Ensure there is at least 0.5 meters (1.6 feet) of clear space on either side of the charging base and 1.5 meters (4.9 feet) in front.

Connect the adapter to the charging base and plug it into a power outlet. Place the robot vacuum onto the charging base, ensuring the charging contacts align. The indicator light on the robot will show charging status.

4.2 App Connection (Vactidy APP)

To unlock full features and control your robot remotely, connect it to the Vactidy APP.

Image: Step-by-step guide on connecting the Vactidy robot vacuum to the Vactidy mobile application.

1. Download the **Vactidy APP** from your app market (App Store or Google Play).
2. Add your T8 robot vacuum to the APP.
3. Make sure the T8 is **on** and charging in the charging dock.
4. Press and hold the start button on the robot for **5 seconds** until it enters pairing mode.
5. Connect your smartphone to a **2.4GHz WiFi** network.
6. Select and connect to the WiFi network named "SL-Vactidy-XXXX" (where XXXX is a unique identifier).
7. Wait for the robot to pair successfully with the app.

5. OPERATING INSTRUCTIONS

5.1 Cleaning Modes

The Vactidy Nimble T8 offers various cleaning modes to suit your needs:

- **Auto Cleaning:** The robot intelligently navigates and cleans the entire floor area.
- **Spot Cleaning:** Focuses on a specific dirty area, cleaning in a spiral pattern.
- **Edge Cleaning:** Cleans along walls and furniture edges.
- **Room Cleaning:** Cleans a specific room (requires app setup).

Image: The robot vacuum performing auto cleaning, following a systematic path across a room.

Upgraded GyroNav Tech

Effective Zig-Zag Route

Disorder Random Route

Image: The robot vacuum performing spot cleaning, concentrating on a localized area of debris.

Deeper Clean with Roller Brush

Roller Brush

Roller brush removes dust and up to 90% cleaning efficiency

Vactidy Nimble T8

Suction Port

Brushless suction port is more like sweeping not vacuuming

other products

Image: The robot vacuum cleaning along the edges of a room, ensuring thorough coverage near walls.

Anti-fall
Prevents damage from falling down stairs or off ledges

Anticollision
Prevents collision with furniture or walls

Roller brush
Sweeps and vacuums at the same time for better cleaning

Side brushes
Cleans corners and hard-to-reach edges

Image: The robot vacuum entering a new room to perform targeted cleaning.

5.2 Control Methods

You can control your Nimble T8 using multiple methods:

- **Vactidy APP:** Use the app for full control, including scheduling, mode selection, and monitoring cleaning progress.

- **Remote Control:** The included remote allows for basic controls like starting/stopping, changing modes, and directing the robot.
- **Voice Control:** Integrate with Amazon Alexa or Google Assistant for convenient voice commands.


Image: A user interacting with the robot vacuum using voice commands through a smart speaker.


Image: A user operating the robot vacuum using the included remote control.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Vactidy Nimble T8.

6.1 Emptying the Dustbin

Empty the dustbin after each cleaning cycle or when the 'full' indicator appears. Open the top cover, remove the dustbin, and dispose of collected debris.

6.2 Cleaning Filters

Tap the HEPA filter to remove dust. Rinse the pre-filter and sponge filter with water. Allow all filters to air dry completely before reinserting them. Replace HEPA filters every 3-6 months, depending on usage.

6.3 Cleaning Brushes

Main Roller Brush: Remove the brush guard and lift out the roller brush. Use the cleaning tool to cut and remove any tangled hair or debris. Reinstall the brush securely.

Side Brushes: Periodically check side brushes for tangles or damage. Remove any hair or debris. If brushes are worn, replace them with new ones.

6.4 Cleaning Sensors and Charging Contacts

Wipe the anti-fall sensors, anti-collision sensors, and charging contacts on both the robot and the charging base with a clean, dry cloth. This ensures proper navigation and charging.

6.5 Water Tank and Mopping Cloth

After mopping, empty any remaining water from the tank. Remove and rinse the mopping cloth thoroughly. Allow the cloth to air dry before reattaching or storing.

7. TROUBLESHOOTING

If your Vactidy Nimble T8 encounters an issue, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Robot does not turn on	Low battery; Power switch off	Charge the robot; Ensure power switch is ON
Robot cannot charge	Charging contacts dirty; Charging base not powered	Clean charging contacts; Check power connection to base
Cleaning efficiency decreases	Dustbin full; Brushes tangled; Filters clogged	Empty dustbin; Clean main/side brushes; Clean/replace filters
Robot gets stuck frequently	Obstacles; Uneven surfaces	Clear obstacles; Use virtual walls if available; Ensure flat cleaning surface
App connection fails	Incorrect WiFi (not 2.4GHz); Robot not in pairing mode	Connect to 2.4GHz WiFi; Re-enter pairing mode (hold start button 5s)

For more detailed troubleshooting or persistent issues, please contact Vactidy customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Vactidy
Model Number	T8
Special Feature	Bagless

Feature	Detail
Color	Black
Product Dimensions	13"L x 16"W x 5"H
Filter Type	Cartridge
Battery Life	100 minutes
Capacity (Dustbin/Water Tank)	250 Milliliters
Power Source	Battery Powered
Form Factor	Compact, low-profile design
Item Weight	5.4 pounds
Batteries	2 Lithium Ion batteries required (included)

9. Warranty and Support

Vactidy products come with a standard manufacturer's warranty. Please refer to the warranty card included in your package or visit the official Vactidy website for detailed warranty terms and conditions.

For technical support, product inquiries, or assistance with warranty claims, please contact Vactidy customer service through their official channels. Contact information can typically be found on the Vactidy website or in the product packaging.