

[Manuals.plus](#) /

› [BEAMNOVA](#) /

› BEAMNOVA Tabletop Elephant Sculpture Water Fountain User Manual

BEAMNOVA B0BQ3724KN

BEAMNOVA Tabletop Elephant Sculpture Water Fountain User Manual

Model: B0BQ3724KN

INTRODUCTION

This user manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your BEAMNOVA Tabletop Elephant Sculpture Water Fountain. Please read this manual carefully before using the product to ensure proper function and longevity.



Image: The BEAMNOVA Tabletop Elephant Sculpture Water Fountain, featuring two elephants, a waterfall, and a glowing blue crystal ball.

IMPORTANT SAFETY INSTRUCTIONS

-
- Always unplug the fountain from the power outlet before cleaning, performing maintenance, or when not in use.
 - Do not operate the fountain if the power cord or pump is damaged.
 - Ensure the fountain is placed on a stable, level, and waterproof surface to prevent spills and damage.
 - Keep the power cord away from heat sources, sharp edges, and wet areas.
 - Do not allow children or pets to play with the fountain unsupervised.
 - Use only clean water. Distilled water is recommended to prevent mineral buildup.
 - Never let the pump run dry; ensure the water level always covers the pump.
 - This product is for indoor use only.

PACKAGE CONTENTS

Before beginning assembly, please check that all parts are included in your package:

- 1 x Water Fountain Resin Base (Elephant Sculpture)
- 1 x Water Pump with LED Light
- 1 x Roll Ball (Crystal Ball)
- 1 x Power Adapter

SETUP INSTRUCTIONS


Follow these steps to set up your BEAMNOVA Tabletop Water Fountain:

1. **Step 1: Check Parts.** Unpack all components and verify that all items listed in the "Package Contents" section are present.
2. **Step 2: Clean the Fountain.** Gently clean the fountain base to remove any dust or debris from manufacturing or packaging. This helps prevent blockages in the water pump.
3. **Step 3: Insert Water Pipe.** Locate the water pipe connection point, typically in the center of the ring light area, and firmly insert the water pipe from the pump into it.
4. **Step 4: Connect Water Pump.** Connect the water pump to the water pipe. Adjust the pump's speed setting if it has one, usually a small switch or dial on the pump itself, to your preferred flow rate.
5. **Step 5: Add Water.** Place the fountain on its intended stable surface. Carefully add clean water to the fountain's reservoir. Ensure the water level fully covers the water pump. Do not overfill.
6. **Step 6: Place Crystal Ball.** Position the crystal ball in its designated spot at the top of the fountain, where the water flow will cause it to rotate.
7. **Step 7: Power On.** Plug the power adapter into a standard electrical outlet. The pump will begin to circulate water, and the LED light will illuminate the crystal ball.

Easy to Install



Check the parts from your package, including 1 * water fountain, 1 * water pump with LED light, 1 * roll ball.




Clean the fountain to wash away the foam fragments inside to avoid blocking the water pump.



Insert the water pipe into the center of the ring light.



Connect the water pump to the water pipe, change its speed settings as you prefer.



Add water to the bowl. Make sure the pump be fully covered by enough water.



Put into the resin base, get your pump plugged in an electrical outlet to set it to work.

Image: Visual guide illustrating the seven steps for easy installation of the BEAMNOVA fountain, from checking parts to plugging it in.

OPERATING INSTRUCTIONS

Once set up, your BEAMNOVA fountain is ready to operate. It is designed for continuous use, providing a calming ambiance.

- **Power On/Off:** The fountain operates by plugging it into a power outlet. To turn it off, simply unplug the power adapter.
- **Crystal Ball Feature:** The integrated LED light within the crystal ball creates a dynamic and colorful visual effect as the water flow causes the ball to rotate.
- **Gurgling Water Sound:** The multi-layer design of the fountain is engineered to produce the soothing sound of natural water flow, contributing to a relaxing environment.

Crystal Ball

The crystal ball with LED light creates a dynamic color and movement to this tabletop fountain.



Image: The crystal ball with LED light, creating dynamic color and movement.

Gurgling Water Sound

Multi-layer design to create the sound of natural water flow



Image: The multi-layer design of the fountain, producing natural gurgling water sounds.




Image: The BEAMNOVA fountain displayed in a living room, bedroom, bathroom, and office, demonstrating versatile placement options.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your fountain.

- **Water Level:** Check the water level daily. Due to evaporation, water levels will decrease. Always ensure the pump is fully submerged to prevent it from running dry, which can cause damage. Refill with clean, distilled water as needed.
- **Cleaning:** Clean the fountain and pump regularly (e.g., weekly or bi-weekly) to prevent mineral buildup, algae growth, and debris accumulation.
 - Unplug the fountain and drain all water.
 - Remove the pump and clean it according to its specific instructions (usually involves disassembling the impeller cover and cleaning the impeller).
 - Wipe down the fountain's interior and exterior surfaces with a soft cloth and mild soap solution. Rinse thoroughly to remove all soap residue.

- For stubborn mineral deposits, use a vinegar and water solution.
- **Pump Care:** Periodically inspect the pump for any blockages or wear. A clean pump ensures quiet and efficient operation.

TROUBLESHOOTING

If you encounter issues with your fountain, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fountain not running / No water flow	Not plugged in or power outage. Insufficient water level. Pump clogged or dirty. Kink in tubing. Pump failure.	Check power connection and outlet. Add water until pump is fully submerged. Clean the pump and tubing thoroughly. Straighten any kinks in the water pipe. Contact customer support if pump is confirmed faulty.
Water flow is weak or inconsistent	Low water level. Pump partially clogged. Pump flow rate set too low.	Add water. Clean the pump and filter. Adjust the pump's flow rate setting.
Excessive noise from pump	Pump not fully submerged. Debris in pump impeller. Pump vibrating against fountain base.	Add water. Clean the pump impeller. Adjust pump position to prevent contact with sides.
Water leaking from base	Crack or damage to resin base. Improper sealing of components. Overfilling.	Inspect the base for visible cracks. If damaged, repair with waterproof sealant or replace. Ensure all connections are secure and properly seated. Do not fill water above the recommended maximum level.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	BEAMNOVA
Model Number	B0BQ3724KN
Product Dimensions	24.99 x 20.07 x 32 cm (9.84 x 7.9 x 12.6 inches)
Item Weight	1.78 kg (3.92 lbs)
Power Source	Corded Electric
Material	Resin

Feature	Detail
Special Features	LED Lighted Crystal Ball, Gurgling Water Sound



Image: Diagram showing the dimensions of the BEAMNOVA fountain: 9.84 inches wide, 7.9 inches deep, and 12.6 inches high.

WARRANTY AND SUPPORT

BEAMNOVA is committed to providing high-quality products. While specific warranty details are not provided in this manual, please retain your proof of purchase for any warranty claims.

For technical support, troubleshooting assistance beyond this manual, or warranty inquiries, please contact BEAMNOVA customer service through the retailer where you purchased the product or visit the official BEAMNOVA website for contact information.

Contact Information: Please refer to the packaging or the retailer's website for the most up-to-date customer support contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question