

[Manuals.plus](#) /

› [Portronics](#) /

› Portronics Harmonics Z3 Wireless Bluetooth 5.3 Neckband Earphones User Manual

Portronics Harmonics Z3

Portronics Harmonics Z3 Wireless Bluetooth 5.3 Neckband Earphones User Manual

Model: Harmonics Z3 (POR-1752)

INTRODUCTION

Thank you for choosing the Portronics Harmonics Z3 Wireless Bluetooth 5.3 Neckband Earphones. This manual provides essential information for setting up, operating, and maintaining your device to ensure optimal performance and longevity. Please read these instructions carefully before use.

PACKAGE CONTENTS

Ensure all items are present in the package:

- 1 x Harmonics Z3 Neckband Headset
- 1 x USB Type-C Charging Cable
- 1 x User Documentation

PRODUCT OVERVIEW

The Portronics Harmonics Z3 features a comfortable neckband design with in-ear earbuds, equipped with 10mm audio drivers for clear sound. It includes a magnetic latch for secure wear and an IPX5 water-resistant rating for durability.

Click Action Buttons

Control music, calls & voice assistant using buttons




Image: Overview of the Harmanics Z3 controls and features. This image highlights the location of the Volume Up, Power, and Volume Down buttons, the magnetic latch for securing the earbuds, and the Type-C charging port.

IPX5

Water Resistant



Image: Key features of the Harmanics Z3. This visual summary shows the 10mm drivers, Bluetooth 5.3 connectivity, 280mAh battery capacity, magnetic latch, ergonomic earbud design, and support for voice assistants like Siri, Google, and Alexa.

SETUP

1. Charging the Device

Before first use, fully charge your Harmanics Z3 earphones.

1. Connect the provided USB Type-C charging cable to the charging port on the neckband.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status. A full charge typically takes approximately 2 hours.
4. Once fully charged, the earphones provide up to 30 hours of playtime.

2. Bluetooth Pairing

Follow these steps to pair your Harmanics Z3 with your device:

1. Ensure the earphones are charged and turned off.
2. Press and hold the Power button on the neckband until the LED indicator flashes red and blue alternately, indicating pairing mode.

3. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
4. Search for available devices and select "Portronics Harmonics Z3" from the list.
5. Once connected, the LED indicator will turn solid blue or flash blue slowly.
6. The earphones will automatically reconnect to the last paired device when powered on, if Bluetooth is enabled on the device.



Image: Super Quick Connect feature. This image demonstrates the seamless Bluetooth 5.3 connectivity of the Harmonics Z3 neckband earphones with mobile devices.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator flashes blue.
- **Power Off:** Press and hold the Power button for approximately 5 seconds until the LED indicator flashes red and then turns off.

Music Playback Controls

- **Play/Pause:** Press the Power button once.

- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.

Call Management

- **Answer/End Call:** Press the Power button once.
- **Reject Call:** Press and hold the Power button for 2 seconds.
- **Redial Last Number:** Double-press the Power button.

Voice Assistant Activation

Activate your device's voice assistant (Siri, Google Assistant, Alexa) by triple-pressing the Power button.

MAINTENANCE

Cleaning

- Wipe the neckband and earbuds with a soft, dry cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Regularly clean the ear tips to prevent wax buildup, which can affect sound quality.

Water Resistance (IPX5)

The Harmonics Z3 is rated IPX5 water-resistant, meaning it can withstand splashes and sweat. It is suitable for workouts and light rain.

- **Do NOT** immerse the earphones in water.
- **Do NOT** expose to running water or high-pressure water jets.
- Ensure the charging port cover is securely closed when not charging to maintain water resistance.
- If exposed to sweat or water, wipe dry before charging.

Swag and Comfort



Image: IPX5 Water Resistant feature. This image visually represents the earphones' ability to withstand water splashes, making them suitable for active use.

Storage

- Store the earphones in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid storing with sharp objects that could damage the cables or earbuds.
- The magnetic latch helps keep the earbuds together when not in use, preventing tangles.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cannot power on	Low battery	Charge the earphones fully.
Cannot pair with device	Earphones not in pairing mode; Bluetooth off on device; device too far	Ensure earphones are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Keep devices within 10 meters.

Problem	Possible Cause	Solution
No sound or low volume	Volume too low; earphones not connected; incorrect audio output selected	Increase volume on earphones and device. Reconnect earphones. Check audio output settings on your device.
Charging issues	Faulty cable/adaptor; charging port obstruction	Try a different Type-C cable and USB adapter. Ensure the charging port is clean and free of debris.
Buttons unresponsive	Software glitch; physical damage	Restart the earphones. If the issue persists, contact customer support.

SPECIFICATIONS

Brand	Portronics
Model Name	Harmonics Z3
Model Number	POR-1752
Bluetooth Version	5.3
Ear Placement	In Ear
Audio Driver Type	Dynamic Driver
Driver Size	10 mm
Playtime	Up to 30 hours
Battery Charge Time	Approx. 2 hours
Charging Port	Type-C
Water Resistance Level	IPX5
Control Type	Voice Control, Touch (via buttons)
Weight	100 Grams
Material	Aluminium, Plastic
Compatible Devices	Smartphones, Tablets, Laptops, Desktops

WARRANTY AND SUPPORT

Warranty Information

The Portronics Harmonics Z3 comes with a **1 Year Manufacturing Warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your purchase receipt for warranty claims.

Customer Support

For any product-related queries, technical assistance, or warranty claims, please contact Portronics customer support.

Manufacturer: Portronics Digital Pvt Ltd

Address: FLOOR-1st and 2nd, B-76, Wazirpur Industrial area, Wazirpur, New Delhi, Delhi, 110052

Please refer to the official Portronics website or the documentation included in your package for the most current contact information and support channels.