

Lenco Xemio 659MIX

Lenco Xemio 659MIX MP3/MP4 Player User Manual

1. INTRODUCTION

The Lenco Xemio 659MIX is a versatile portable media player designed for enjoying music, videos, e-books, and recording voice memos. Featuring a 1.8-inch TFT LCD screen and expandable storage, this device offers a compact solution for your digital media needs. This manual provides essential instructions for setup, operation, and maintenance of your Xemio 659MIX.

2. SAFETY INFORMATION

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Use only the provided or approved accessories.
- Prolonged listening at high volume levels can cause hearing damage. Adjust volume to a moderate level.

3. PACKAGE CONTENTS

Please check that all items are present in the package:

- Lenco Xemio 659MIX MP3/MP4 Player
- Earbud Headphones
- 4GB Micro SD Card
- Micro USB Cable
- Auxiliary Cable
- User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the device's components and controls.







Figure 4.1: Front View. This image shows the front of the Lenco Xemio 659MIX MP3/MP4 player. It features a 1.8-inch TFT LCD screen at the top, displaying a 'Music' icon and text. Below the screen, the 'Lenco' brand name is visible. At the bottom, there is a circular control pad with a central play/pause button, left and right skip buttons, a back/return button (U-turn arrow), and an 'M' button for menu access.





Figure 4.2: Back View. This image displays the back of the Lenco Xemio 659MIX MP3/MP4 player. It includes the Lenco logo, model number 'Xemio-659MIX', regulatory marks (CE, WEEE), manufacturer details, battery specifications (Lithium 3.7V 300mAh), and country of origin. At the bottom edge, labels indicate the Microphone (MIC), Headphone Jack, ON/OFF switch, and USB port.





Figure 4.3: Side View. This image provides an angled front view of the Lenco Xemio 659MIX MP3/MP4 player, showing a slight side profile. This perspective highlights the compact form factor and the placement of the screen and control buttons, giving a better sense of the device's overall design.



Figure 4.4: Menu Options. This composite image illustrates various menu options on the Lenco Xemio player, showing different icons for Music, Picture, and Video functions. Each player variant shown has a distinct control pad color,

demonstrating the user interface for different media types.

5. SETUP

5.1. Charging the Device

1. Connect the Micro USB cable to the USB port on the player.
2. Connect the other end of the USB cable to a powered USB port on a computer or a compatible USB wall adapter (not included).
3. The battery indicator on the screen will show charging status. A full charge typically takes a few hours.

5.2. Inserting the Micro SD Card

The device comes with a 4GB Micro SD card, which can be expanded up to 32GB.

1. Locate the Micro SD card slot on the side of the player.
2. Gently insert the Micro SD card into the slot until it clicks into place. Ensure the card is oriented correctly.
3. To remove, gently push the card in until it clicks, then release, and it will eject.

5.3. Connecting Headphones

1. Plug the 3.5mm jack of the earbud headphones into the headphone port on the player.
2. Ensure the connection is secure for optimal audio quality.

6. BASIC OPERATION

6.1. Power On/Off

- **To Power On:** Slide the ON/OFF switch (located on the back/side) to the 'ON' position. The screen will light up.
- **To Power Off:** Slide the ON/OFF switch to the 'OFF' position. The device will shut down.

6.2. Navigation

Use the circular control pad for menu navigation:

- **Left/Right Buttons (< / >):** Navigate through menu options or skip tracks/chapters.
- **Central Button (▶||):** Select an option, play/pause media.
- **Back Button (←):** Return to the previous menu or screen.
- **'M' Button:** Access the main menu or context-sensitive options within an application.

6.3. Volume Control

Volume is typically controlled using the Left/Right buttons during media playback. Press the 'M' button during playback to access volume control if not directly available.

7. FUNCTIONS

7.1. Music Playback

1. From the main menu, select 'Music'.
2. Browse your music files by artist, album, or folder.

3. Select a song and press the central button to play.
4. Use the Left/Right buttons to skip tracks. Press the central button to pause/resume.

7.2. Video Playback

1. From the main menu, select 'Video'.
2. Browse your video files.
3. Select a video and press the central button to play.
4. The 1.8-inch screen supports video playback for compatible formats.

7.3. E-book Reader

The Xemio 659MIX supports e-book files in XXT format, as well as image files like JPG and BMP.

1. From the main menu, select 'E-book' or 'Picture' for image viewing.
2. Navigate to your desired file.
3. Press the central button to open and view the content.

7.4. Voice Recorder

The integrated voice recorder allows you to create and save voice memos.

1. From the main menu, select 'Voice Recorder'.
2. Press the central button to start recording.
3. Press the central button again to stop and save the recording.
4. Recordings are saved to the device's memory or SD card.

8. CONNECTING TO A COMPUTER

To transfer files to and from your Xemio 659MIX:

1. Ensure the player is powered on.
2. Connect the player to your computer using the Micro USB cable.
3. The player will appear as a removable disk drive on your computer.
4. Drag and drop your music, video, e-book, or image files into the appropriate folders on the player's storage or SD card.
5. Always safely eject the device from your computer before disconnecting the USB cable.

9. MAINTENANCE

9.1. Cleaning

- Wipe the device with a soft, dry, lint-free cloth.
- Do not use liquid cleaners or abrasive materials.

9.2. Battery Care

- Charge the battery regularly, even if the device is not used for extended periods, to maintain battery health.
- Avoid fully discharging the battery frequently.
- Do not expose the device to extreme heat or cold, as this can degrade battery performance.

10. TROUBLESHOOTING

- **Device does not power on:** Ensure the battery is charged. Check the ON/OFF switch is in the 'ON' position.
- **No sound:** Check headphone connection. Adjust volume. Ensure media files are not corrupted.
- **Cannot transfer files:** Ensure the USB cable is securely connected. Try a different USB port or cable. Ensure the device is recognized by the computer.
- **Screen is frozen:** Try sliding the ON/OFF switch to 'OFF' and then 'ON' again to restart the device.
- **SD card not recognized:** Ensure the SD card is inserted correctly. Try reinserting it. Ensure the card is not damaged.

11. SPECIFICATIONS

Model Name	Xemio 659MIX
Screen	1.8-inch TFT LCD
Storage Capacity	4GB Micro SD card included (expandable up to 32GB)
Connectivity	USB, Auxiliary (3.5mm headphone jack)
Special Features	Voice Recorder, E-book Function (TXT, JPG, BMP), Video Playback
Battery	300 mAh Lithium-ion rechargeable battery
Compatible Devices	Headphones, Personal Computer, Laptop

12. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Lenco website. Keep your proof of purchase for warranty claims.

Related Documents - Xemio 659MIX

	Lenco XEMIO-950 MP5 Player User Manual User manual for the Lenco XEMIO-950 portable MP5 player, detailing its features, operations, settings, and technical specifications. Covers music playback, video viewing, photo browsing, voice recording, apps, e-book reading, and radio functions.
--	---

 Lenco Model: XEMIO-860 User manual - MP3/MP4 Player with Bluetooth and 8GB memory Bedienungsanleitung - MP3/MP4 Player mit Bluetooth und 8 GB Speicher Manuel de l'utilisateur - Lecteur MP3/MP4 avec Bluetooth et 8 GB de mémoire Manual do usuário - Reprodutor MP3/MP4 com Bluetooth e 8 GB de memória Ingebruiksaanwijzing - MP3/MP4-speler met Bluetooth en 8 GB-geheugen Bedieningshandleiding - MP3/MP4-speler met Bluetooth en 8 GB-geheugen	Lenco XEMIO-860 MP3/MP4 Player User Manual Explore the Lenco XEMIO-860 MP3/MP4 Player. This user manual details its features, including Bluetooth connectivity, 8GB storage, and support for multiple audio/video formats. Learn about safe operation, technical specifications, and warranty information from Lenco.
 Lenco Model: XEMIO-560 Quick Guide 8GB MP3/MP4 Player 8GB MP3/MP4-speler 8GB Player mit 8 GB Speicherkapazität Lecteur MP3/MP4 8 Go Reprodutor de 8 GB MP3/MP4	Lenco XEMIO-560 Quick Guide: Features, Operation, and Specifications A comprehensive quick guide for the Lenco XEMIO-560 8GB MP3/MP4 player, covering its features, technical specifications, operation for music, video, recording, and settings, along with safety and warranty information.
 Lenco USER'S MANUAL XEMIO-768 / MP-208 MP3 / MP4 player with Bluetooth For more information: www.lenco.com	Lenco XEMIO-768/MP-208 MP3/MP4 Player User Manual Official user manual for the Lenco XEMIO-768 and MP-208 MP3/MP4 players with Bluetooth. Contains detailed instructions, safety precautions, operational guides, and troubleshooting tips for the portable media device.
 Lenco XEMIO-668 / MP-108 User manual - MP3/MP4 Player with 8GB Memory and 6.5" LCD Bedienungsanleitung - MP3/MP4-Spieler mit 8 GB Speicher und 6,5" LCD Manuel de l'utilisateur - Lecteur MP3/MP4 avec 8 Go de mémoire et écran 6,5"	Lenco XEMIO-668 / MP-108 User Manual Comprehensive user manual for the Lenco XEMIO-668 and MP-108 portable media players, detailing setup, operation, features, safety, and troubleshooting.
 Lenco Model: XEMIO-860 User manual - MP3/MP4 Player with Bluetooth and 8GB memory Bedienungsanleitung - MP3/MP4-Spieler mit Bluetooth und 8 GB Speicher Manuel de l'utilisateur - Lecteur MP3/MP4 avec Bluetooth et 8 GB de mémoire Manual do usuário - Reprodutor MP3/MP4 com Bluetooth e 8 GB de memória Ingebruiksaanwijzing - MP3/MP4-speler met Bluetooth en 8 GB-geheugen Bedieningshandleiding - MP3/MP4-speler met Bluetooth en 8 GB-geheugen	Lenco XEMIO-860 MP3/MP4 Player User Manual User manual for the Lenco XEMIO-860 MP3/MP4 Player with Bluetooth and 8GB memory. Includes setup, operation, features, and technical specifications.



[\[pdf\]](#) User Manual

Shower Bluetooth Speaker Alex Xemio 659MIX manual v1 0 NL EN DE FR ES Lenco 659GY MP3 MP4 player with 4GB micro SD card grey a9c94ed497e72910a3c7f778411c5d4a61bc6cf8 cdn maxx nl |||

Model No: Xemio-659MIX User Manual MP3/4 player with 4GB micro SD card
Gebruikshandleiding MP3/4-speler met 4GB microSD-kaart Bedienungsanleitung
MP3/4-Player mit 4-GB-microSD-Karte Mode d emploi Lecteur MP3/4 avec carte SD
de 4 Go Manual de usuario Reproductor MP3/4 con tarjeta micro SD de 4 GB...
lang:en score:48 filesize: 1.22 M page_count: 58 document date: 2019-04-09



[\[pdf\]](#) User Manual

Shower Bluetooth Speaker Alex 1f386809c8129c45fca8902e0b121e3212f1279f Xemio 659MIX manual v4 0 EN NL DE FR ES cdn maxx nl |||

Model No: Xemio-659MIX User Manual MP3/4 player with 4GB micro SD card
Gebruikershandleiding- MP3/MP4-speler met 4 GB microSD-kaart
Bedienungsanleitung MP3/4-Player mit 4-GB-microSD-Karte Manuel d utilisation -
lecteur MP3/4 avec carte micro SD de 4 Go Manual de usuario: Reproductor MP3/4
con tarj...
lang:en score:48 filesize: 761.53 K page_count: 56 document date: 2024-06-24



[\[pdf\]](#) User Manual

Shower Bluetooth Speaker Alex d4c69d4d9ea0aeba08aab2c037812f155a41f74d Xemio 659MIX manual v2 0 EN NL DE FR ES cdn maxx nl |||

Model No: Xemio-659MIX User Manual MP3/4 player with 4GB micro SD card
Gebruikershandleiding- MP3/MP4-speler met 4 GB microSD-kaart
Bedienungsanleitung MP3/4-Player mit 4-GB-microSD-Karte Manuel d utilisation -
lecteur MP3/4 avec carte micro SD de 4 Go Manual de usuario: Reproductor MP3/4
con tarj...
lang:en score:47 filesize: 1.23 M page_count: 56 document date: 2023-01-16



[\[pdf\]](#) User Manual

Shower Bluetooth Speaker Alex 470e9743a78e8e0b5b3e8059d81e5c0b388b3863 Xemio 659MIX manual v2 0 NL EN DE FR ES cdn maxx nl |||

Model No: Xemio-659MIX User Manual MP3/4 player with 4GB micro SD card
Gebruikshandleiding MP3/4-speler met 4GB microSD-kaart Bedienungsanleitung
MP3/4-Player mit 4-GB-microSD-Karte Mode d emploi Lecteur MP3/4 avec carte SD
de 4 Go Manual de usuario Reproductor MP3/4 con tarjeta micro SD de 4 GB...
lang:en **score:47** filesize: 984.55 K page_count: 58 document date: 2023-01-04



[\[pdf\]](#) User Manual

Shower Bluetooth Speaker Alex bec7c53caa5b2af737d5200f5383384e4d4fea75 Xemio 659MIX manual v3 0 EN NL DE FR ES cdn maxx nl |||

Model No: Xemio-659MIX User Manual MP3/4 player with 4GB micro SD card
Gebruikershandleiding- MP3/MP4-speler met 4 GB microSD-kaart
Bedienungsanleitung MP3/4-Player mit 4-GB-microSD-Karte Manuel d utilisation -
lecteur MP3/4 avec carte micro SD de 4 Go Manual de usuario: Reproductor MP3/4
con tarj...
lang:en **score:45** filesize: 938.47 K page_count: 56 document date: 2024-05-03



[\[pdf\]](#) Accessories

Xemio 659MIX leaflet NL EN DE FR ES Lenco 659GY MP3 MP4 player with 4GB micro SD card grey 4adcb12b85559fe85ce8f86dcfc47ffc97fff0f cdn maxx nl |||

Xemio-659MIX MP3/4 player with 4GB micro SD card 40 MM 90MM EN 1,8 4,5 cm
TFT LCD display 4GB micro SD card Audio formats: MP3, WMA, WAV, APE, FLAC
Photo formats: JPG, BMP and GIF Video formats : AMV E-book function supports
TXT files Voice recording function Playback time in music mode...

lang:nl **score:39** filesize: 369.31 K page_count: 1 document date: 2018-10-09

Lenco

Model No: Xemio-659MIX



User Manual – MP3/4 player with 4GB micro SD card
Gebruikshandleiding – MP3/4-speler met 4GB microSD-kaart
Bedienungsanleitung – MP3/4-Player mit 4-GB-microSD-Karte
Mode d'emploi – Lecteur MP3/4 avec carte SD de 4 Go
Manual de usuario –Reproductor MP3/4 con tarjeta micro SD de 4 GB

[\[pdf\]](#) User Manual

Shower Bluetooth Speaker Alex Bekijk de handleiding Lenco Xemio 659GY MP3 MP4 speler met 4GB micro SD kaart grijs bol original media s xLwz4YWDqjVn |||

Model No: Xemio-659MIX User Manual MP3/4 player with 4GB micro SD card
Gebruikshandleiding MP3/4-speler met 4GB microSD-kaart Bedienungsanleitung
MP3/4-Player mit 4-GB-microSD-Karte Mode d'emploi Lecteur MP3/4 avec carte SD
de 4 Go Manual de usuario Reproductor MP3/4 con tarjeta micro SD de 4 GB...
lang:en score:28 filesize: 754.33 K page_count: 58 document date: 2022-06-14

Lenco

Model No: Xemio-659MIX



User Manual – MP3/4 player with 4GB micro SD card
Gebruikshandleiding – MP3/4-speler met 4GB microSD-kaart
Bedienungsanleitung – MP3/4-Player mit 4-GB-microSD-Karte
Mode d'emploi – Lecteur MP3/4 avec carte SD de 4 Go
Manual de usuario –Reproductor MP3/4 con tarjeta micro SD de 4 GB

[\[pdf\]](#) User Manual

Shower Bluetooth Speaker Alex Bekijk de handleiding Lenco Xemio 659BU MP3 MP4 speler met 4GB micro SD kaart blauw bol original media s Xp2XOgvr9RKk |||

Model No: Xemio-659MIX User Manual MP3/4 player with 4GB micro SD card
Gebruikshandleiding MP3/4-speler met 4GB microSD-kaart Bedienungsanleitung
MP3/4-Player mit 4-GB-microSD-Karte Mode d'emploi Lecteur MP3/4 avec carte SD
de 4 Go Manual de usuario Reproductor MP3/4 con tarjeta micro SD de 4 GB...
lang:en score:28 filesize: 754.33 K page_count: 58 document date: 2022-06-14

Lenco

Model No: Xemio-659MIX



User Manual – MP3/4 player with 4GB micro SD card
Gebruikshandleiding – MP3/4-speler met 4GB microSD-kaart
Bedienungsanleitung – MP3/4-Player mit 4-GB-microSD-Karte
Mode d'emploi – Lecteur MP3/4 avec carte SD de 4 Go
Manual de usuario –Reproductor MP3/4 con tarjeta micro SD de 4 GB

[\[pdf\]](#) User Manual

Shower Bluetooth Speaker Alex Bekijk de handleiding Lenco Xemio 659PK MP3 MP4 speler met 4GB micro SD kaart roze bol original media s qLmp4O8KB3Ky |||

Model No: Xemio-659MIX User Manual MP3/4 player with 4GB micro SD card
Gebruikshandleiding MP3/4-speler met 4GB microSD-kaart Bedienungsanleitung
MP3/4-Player mit 4-GB-microSD-Karte Mode d'emploi Lecteur MP3/4 avec carte SD
de 4 Go Manual de usuario Reproductor MP3/4 con tarjeta micro SD de 4 GB...
lang:en score:28 filesize: 754.33 K page_count: 58 document date: 2022-06-14



[pdf] Accessories

Untitled Produktdatenblatt Lenco Xemio 659 MP3 Player MP4 4 GB mit 5 cm 1 8 Zoll LCD TFT

Farbdisplay b2a56d28 940c 54b4 ad94 05fc3df1b731 d otto de files |||

Xemio-659MIX MP3/4 player with 4GB micro SD card 40 MM 90MM EN 1,8 4,5 cm

TFT LCD display 4GB micro SD card Audio formats: MP3, WMA, WAV, APE, FLAC

Photo formats: JPG, BMP and GIF Video formats : AMV E-book function supports

TXT files Voice recording function Playback time in music mode...

lang:nl score:24 filesize: 108.44 K page_count: 1 document date: 2022-07-25



[pdf]

Bekijk de CE marking Lenco Xemio 659MIX MP3 Speler 4GB Micro SD bol original media s

q5ZxKLqqvv80 |||

...

lang:nl score:20 filesize: 210.9 K page_count: 1 document date: 2023-03-31