

Manuals.plus /

> Accutime /

> Pokémon Interactive Kids Smartwatch with Touchscreen, Interchangeable Pikachu & Friends Straps, Built-in Camera, Games, Alarm, Stopwatch, Calculator, and 10 Watch Faces - Fits Wrists 5.5"-8"

Accutime POK40031AZ

Pokémon Interactive Kids Smartwatch User Manual

Model: POK40031AZ | Brand: Accutime

1. INTRODUCTION

Welcome to the user manual for your new Pokémon Interactive Kids Smartwatch. This smartwatch is designed for young Pokémon fans, offering a fun and interactive way to learn time management and engage with various digital features. Please read this manual carefully to ensure proper use and maintenance of your device.



Image: The Pokémon Interactive Kids Smartwatch, showcasing its main display with a Pokéball-themed watch face. Included are two interchangeable silicone straps: one vibrant yellow strap featuring Pikachu, and another black strap adorned with various Pokémon characters like Charmander, Squirtle, and Bulbasaur. This image highlights the watch's customizable appearance and core design.

2. PRODUCT OVERVIEW

The Pokémon Interactive Kids Smartwatch is packed with features to entertain and educate. Key features include:

- **Interactive Touchscreen:** Easy navigation through menus and applications.
- **Interchangeable Straps:** Two silicone straps featuring Pikachu and other Pokémon characters for personalized style.

- **Built-in Camera:** Capture photos and videos directly from the watch.
- **Voice Recorder:** Record and play back voice messages.
- **Games:** Pre-loaded games for entertainment without internet connectivity.
- **Time Management Tools:** Alarm, timer, and stopwatch functions.
- **Calculator:** A basic calculator for quick computations.
- **Customizable Watch Faces:** 10 digital and analog watch faces and 3 wallpapers to choose from.

3. SETUP

3.1. Charging the Smartwatch

Your smartwatch comes with a built-in rechargeable Lithium Polymer battery. Before first use, fully charge the device. Connect the included USB charging cable to the watch's charging port and plug the other end into a standard USB power adapter (not included) or a computer's USB port. The charging indicator will show the battery status.

3.2. Attaching/Changing Straps

The smartwatch includes two interchangeable silicone straps. To attach or change a strap:

1. Locate the spring bars on the back of the watch and the strap.
2. Align the spring bar with the holes on the watch casing.
3. Push the spring bar inward and slide the strap into place until the spring bar clicks securely into the holes.
4. Gently pull on the strap to ensure it is firmly attached before wearing.





Image: The Pokémon Interactive Kids Smartwatch displayed alongside its two interchangeable silicone straps. One strap features a yellow Pikachu design, and the other is black with various Pokémon characters. This image illustrates how the watch and its straps appear when detached, demonstrating the modular design for customization.

4. OPERATING INSTRUCTIONS

4.1. Power On/Off

- **To Power On:** Press and hold the power button (usually on the side of the watch) for a few seconds until the screen lights up.
- **To Power Off:** Press and hold the power button until a power-off option appears on the screen. Tap to confirm.

4.2. Navigating the Touchscreen

The smartwatch features a responsive touchscreen. Swipe left or right to browse through different applications and features. Tap an icon to select an application.





Image: A close-up view of the Pokémon Interactive Kids Smartwatch, showing its digital display. The screen features a vibrant image of Pikachu with the current time (12:43 PM) and date (02-26-2021 FRI) displayed below. This image highlights the clarity of the touchscreen and the customizable watch face options.

4.3. Camera and Media Functions

- **Camera:** Tap the camera icon to open the camera. Tap the screen to take a photo.
- **Video Recorder:** Select the video icon to start recording. Tap again to stop.
- **Voice Recorder:** Access the voice recorder app to record audio.
- **Gallery:** View your captured photos and videos in the gallery application.

4.4. Games

The smartwatch comes with pre-loaded games. Tap the 'Games' icon to access the game selection menu. Select a game to start playing. No internet connection is required for games.

4.5. Time Tools and Calculator

- **Alarm:** Set multiple alarms with custom times and sounds.
- **Timer:** Set a countdown timer for various activities.
- **Stopwatch:** Use the stopwatch for timing events.
- **Calculator:** Perform basic arithmetic operations.

4.6. Customizing Watch Faces and Wallpapers

Personalize your smartwatch by changing the watch face and wallpaper:

- From the home screen, tap and hold the watch face, or navigate to the 'Settings' menu.
- Select 'Watch Face' or 'Wallpaper' options.
- Browse through the available 10 digital and analog watch faces and 3 wallpapers.
- Tap to select your preferred design.

CHANGEABLE WATCH FACES





Image: A collage showcasing nine different changeable watch faces available for the Pokémon Interactive Kids Smartwatch. The designs include various Pokémon characters like Pikachu, Charmander, Bulbasaur, Squirtle, and Mewtwo, as well as analog and digital watch faces with Pokeball themes. This image demonstrates the extensive customization options for the watch's display.

5. MAINTENANCE

5.1. Cleaning Your Smartwatch

To keep your smartwatch clean, gently wipe the screen and straps with a soft, dry, lint-free cloth. For stubborn smudges, a slightly damp cloth can be used, but ensure no moisture enters the device openings. Do not use harsh chemicals or abrasive cleaners.

5.2. Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the watch regularly. If storing the watch for an extended period, ensure it has at least a 50% charge.

5.3. Water Resistance

This smartwatch is not waterproof. Avoid immersing it in water. Discontinue use if the watch is immersed in water or if the case back is missing or disassembled.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch does not turn on.	Battery is drained.	Charge the smartwatch for at least 30 minutes.
Screen is unresponsive.	Temporary software glitch.	Restart the watch by holding the power button. If unresponsive, allow battery to drain completely and then recharge.
Cannot take photos/videos.	Insufficient storage space.	Delete some existing photos or videos from the gallery to free up space.
Watch is not holding a charge.	Faulty charging cable or battery issue.	Try a different USB charging port or cable. If the issue persists, contact customer support.

7. SPECIFICATIONS

- **Model Number:** POK40031AZ
- **Brand:** Accutime
- **Display:** Interactive Touchscreen
- **Battery:** 1 Lithium Polymer battery (included)
- **Wrist Fit:** 5.5" - 8"
- **Dimensions (Package):** 7.83 x 4.13 x 2.64 inches
- **Weight (Item):** 1.4 ounces
- **Manufacturer:** Accutime Watch Corp.
- **First Available Date:** December 14, 2022

8. SAFETY INFORMATION

WARNING: THIS IS NOT A TOY.

- Do not dispose of batteries in fire; batteries may explode or leak.
- Do not replace the battery. Send to a service center for replacement if needed.
- Discontinue use if immersed in water.
- Do not wear if the case back is missing or disassembled.
- Suitable for ages 6 and up.
- **CHOKING HAZARD:** Small Parts - Not For Children Under 3 Years.




Image: The back of the Pokémon Interactive Kids Smartwatch product packaging. The box features a red background with Pokéball patterns and prominently displays safety warnings, including "THIS IS NOT A TOY" and "WARNING CHOKING HAZARD: Small Parts - Not For Children Under 3 Years." Manufacturer and distribution information are also visible.

For detailed safety information, please refer to the official Safety Information PDF [Safety Information \(PDF\)](#)

9. WARRANTY AND SUPPORT

For product support, inquiries, or service, please contact Accutime Watch Corp. customer service. Refer to the product packaging or the official Accutime website for contact details.

Manufacturer: Accutime Watch Corp.

Address: 1001 Ave of the Americas, New York, NY 10018

Please retain your proof of purchase for warranty claims.

© 2023 Accutime Watch Corp. All rights reserved. Pokémon © 2023 The Pokémon Company International.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BQ4P67MH>

More documents and user manuals: <https://manuals.plus/>