

[Manuals.plus](#) /

› [LEDLUX](#) /

› LEDLUX 60 Inch Ceiling Fan with Light User Manual

LEDLUX SYCF6001

LEDLUX 60 Inch Ceiling Fan with Light User Manual

Model: SYCF6001

IMPORTANT SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, operate, or install the product. Failure to follow these instructions could result in electric shock, fire, or serious personal injury.

- Always disconnect power at the main circuit breaker before installation or maintenance.
- Ensure all electrical connections comply with local codes and ordinances.
- Mount the fan only to an outlet box marked "Acceptable for Fan Support of 35 lbs (15.9 kg) or less" and use the mounting screws provided with the outlet box.
- Do not bend the blade holders during installation, balancing, or cleaning.
- Keep hands, feet, and other objects clear of the rotating fan blades.
- This fan is designed for indoor use only.

PRODUCT OVERVIEW

The LEDLUX 60 Inch Ceiling Fan with Light is designed to provide efficient air circulation and illumination for living rooms, bedrooms, and kitchens. It features a sleek modern design with three solid wood blades and a reversible DC motor for year-round comfort. The integrated LED light offers energy-efficient illumination with adjustable color temperatures.



Image: The LEDLUX 60-inch ceiling fan featuring a white body, brushed nickel accents, and three light-colored wooden blades, with an integrated LED light kit.



Image: Examples of the ceiling fan installed in a living room, bedroom, and kitchen, demonstrating its versatility for different indoor spaces.

PACKAGE CONTENTS

Before beginning installation, ensure all parts listed below are present and undamaged. If any parts are missing or damaged, do not attempt to install the product.

- Fan Motor Assembly with Integrated LED Light
- 3 Solid Wood Fan Blades
- Remote Control
- 2 Downrods (4.5 inches and 12 inches)
- Mounting Bracket
- Hardware Pack (screws, wire nuts, washers)
- Instruction Manual

Ceiling Fan Details



Image: Detailed view of the ceiling fan components, highlighting the two included downrods (4.5" and 12"), the quiet reversible DC motor, and the solid wood fan blades.

SPECIFICATIONS

Brand	LEDLUX
Model Name	60 Inch Ceiling Fan with Light
Item Model Number	SYCF6001
Dimensions	60 x 60 x 15 inches
Item Weight	15.27 pounds
Number of Blades	3
Blade Material	Wood

Brand	LEDLUX
Motor Type	Reversible DC Motor
Number of Speeds	6
Control Method	Remote Control
Light Type	Integrated LED
Voltage	120 Volts (AC)
Indoor/Outdoor Usage	Indoor

Dimensions






Image: Diagram illustrating the dimensions of the 60-inch ceiling fan, including the fan diameter, downrod lengths (4.5" and 12"), and compatibility with flat or sloped ceilings.

Professional installation is recommended for electrical components. Ensure power is off before beginning.

1. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling outlet box. Ensure the outlet box is rated for fan support.
2. **Downrod Assembly:** Choose the appropriate downrod (4.5" or 12") for your ceiling height. Insert the downrod through the canopy and motor assembly.
3. **Wiring Connections:** Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the full manual. Ensure all connections are secure with wire nuts.
4. **Blade Attachment:** Attach the three solid wood fan blades to the motor assembly using the provided screws. Ensure they are securely fastened.
5. **Canopy Installation:** Slide the canopy up and secure it to the mounting bracket, covering the wiring connections.

How to Remove the Shadow of Wires?



When installing, cut the wires short and then connect.



Image: Illustration demonstrating how to properly trim and connect wires to avoid shadows from internal wiring within the light kit.




Image: Visual guide showing how the fan can be installed on high ceilings, low ceilings, and slanted ceilings, adapting to various room architectures.

OPERATING INSTRUCTIONS

The LEDLUX ceiling fan is operated using the included remote control.

Your browser does not support the video tag.

Video: Demonstration of the LEDLUX 60-inch ceiling fan's features, including light color temperature changes, 6-speed settings, reversible motor function, and timer options, all controlled via the remote.

- **Power On/Off:** Press the power button on the remote to turn the fan and light on or off.
- **Fan Speed Control:** Use the speed buttons (1-6) to adjust the fan's rotation speed.
 - Speeds 1-2: Comfortable breezes.
 - Speeds 3-4: Natural winds.
 - Speeds 5-6: Strong winds.
- **Light Control:**
 - Press the light button to turn the LED light on or off.
 - Press the color temperature button to cycle through 3 color temperatures: Warm Light (3000K), Neutral White (4500K), and Cold Light (6500K).
- **Reversible Motor:** Press the reverse button on the remote to change the direction of the fan blades.
 - **Summer Mode (Counter-clockwise):** Creates a downward airflow, producing a cooling effect.
 - **Winter Mode (Clockwise):** Creates an upward airflow, circulating warm air trapped near the ceiling.
- **Timer Function:** Set the fan to turn off automatically after 1H, 2H, 4H, or 8H using the timer buttons on the remote.

LEDLUX

60

INCHES

3 COLOR TEMPERATURE LIGHTS

6 Speeds For Your Choice



3000K



4000K



6500K



1

2

3

SPEED

4

5

6

Image: Visual representation of the three adjustable light color temperatures: 3000K (warm), 4000K (neutral), and 6500K (cool), demonstrating the versatility of the integrated LED light.



Image: Diagram illustrating the fan's reversible function: counter-clockwise rotation for summer cooling and clockwise rotation for winter heat circulation.

Hand Remote Control



Image: Close-up of the remote control, detailing buttons for speed adjustment, fan on/off, light on/off, forward/reverse fan direction, and timer settings (1H/2H/4H/8H).

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or blades.
- **Blade Care:** The solid wood blades can be gently wiped clean. Avoid excessive moisture.
- **Tightening Screws:** Periodically check all screws and connections for tightness. Due to natural movement, some connections may become loose over time.
- **Light Source:** The integrated LED light is designed for long life and typically does not require replacement. If issues arise, contact customer support.

TROUBLESHOOTING

If you experience issues with your ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start.	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker and wall switch. Ensure all wiring connections are secure. Replace remote battery or re-pair remote according to instructions.
Fan makes noise.	Loose screws on motor housing or blade holders; Blades unbalanced.	Tighten all screws. Ensure blades are securely attached. Use a balancing kit if necessary (not included).
Light does not work.	Loose wire connection to light kit; LED driver failure.	Check light kit wiring connections. If problem persists, contact customer support for LED driver replacement.
Fan wobbles excessively.	Loose blade screws; Unbalanced blades; Improper mounting.	Ensure all blade screws are tight. Check for bent blade holders. Use a balancing kit to correct blade imbalance. Verify mounting bracket is securely installed.
Fan does not blow sufficient air.	Fan speed too low; Incorrect direction for season.	Increase fan speed using the remote. Ensure fan is set to counter-clockwise rotation for cooling (summer mode).

WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or contact LEDLUX customer service directly. Keep your purchase receipt as proof of purchase.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact LEDLUX customer support through their official website or the contact information provided in your product packaging.

LEDLUX Official Store: [Visit LEDLUX Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question