

Manuals.plus /

› 7MAGIC /

› 7MAGIC Fast-Drying Foldable Ionic Hair Dryer (Model 7M3600) User Manual

7MAGIC 7M3600

7MAGIC Fast-Drying Foldable Ionic Hair Dryer

Model: 7M3600 | Brand: 7MAGIC

INTRODUCTION

Thank you for choosing the 7MAGIC Fast-Drying Foldable Ionic Hair Dryer. This manual provides essential information for the safe and efficient use of your new hair dryer. Please read it thoroughly before first use and keep it for future reference.

IMPORTANT SAFETY INFORMATION

To reduce the risk of electric shock, fire, or injury, always follow basic safety precautions when using electrical appliances. Please read and understand all instructions before use.

- Keep out of reach of children.
- Do not use while bathing or in a shower.
- Keep the power plug and cord away from heated surfaces.
- Do not rinse or submerge the appliance in water.
- Allow the hair dryer to cool down after use before storing.
- Ensure the ALCI safety plug is functioning correctly before each use. Press the "TEST" button, then the "RESET" button. If the indicator light does not illuminate after pressing "RESET", do not use the appliance.
- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner.
- Do not block the air openings or place the appliance on a soft surface, such as a bed or couch, where the air openings may be blocked.
- Use this appliance only for its intended household use as described in this manual.

PRODUCT FEATURES

- **Fast-Drying Technology:** Equipped with a powerful motor (32000 RPM) and 1600W wattage for

quick drying, up to 30% faster than traditional hair dryers.

- **Ionic Function:** Releases millions of negative ions to protect hair from heat damage, reduce frizz, and maintain natural moisture for smoother, shinier results.
- **Foldable & Lightweight Design:** Compact (7.67*5.11*2.08 inches) and lightweight (0.88 lbs) with a foldable handle, making it ideal for travel and easy storage.
- **Multiple Settings:** Features 3 temperature settings (COOL/WARM/HOT) and 2 speed settings (LOW/HIGH) for versatile styling.
- **Enhanced Safety:** Includes an upgraded air inlet design to prevent hair inhalation (99% effective) and a removable double safety dust cover. Overheating safety protection and an ALCI safety plug are integrated for user safety.



Image: Internal mechanism highlighting the 1600W power and 32000 RPM motor for rapid hair drying.

SETUP

1. **Unpacking:** Carefully remove the hair dryer and all accessories from the packaging. Ensure all components are present: hair dryer unit, concentrator nozzle, storage bag, and small soft brush.
2. **Unfolding the Handle:** If the handle is folded for storage, gently unfold it until it clicks securely into place.



Image: The hair dryer with its handle folded, illustrating its compact design for travel.

3. **Attaching the Concentrator Nozzle:** Align the concentrator nozzle with the air outlet of the hair dryer and gently push it on until it is firmly attached. It can be easily removed by pulling it off.
4. **Power Connection:** Plug the ALCI safety plug into a standard 110V-125V electrical outlet. Before each use, press the "TEST" button on the plug, then the "RESET" button. The indicator light should

illuminate, confirming the safety feature is active.

OPERATING INSTRUCTIONS

The 7MAGIC hair dryer features intuitive controls for customized drying and styling.



Image: Overview of the hair dryer's controls, including speed and temperature settings.

1. Power On/Off and Speed Settings:

- Locate the power/speed switch on the handle.
- Slide the switch to "LOW" for gentle airflow or "HIGH" for powerful airflow.
- Slide to "OFF" to turn off the appliance.

2. Temperature Settings:

- Use the temperature switch to select your desired heat level:
 - **COOL:** For setting your style and reducing frizz.
 - **WARM:** For regular drying.
 - **HOT:** For quick drying and initial styling.

3. Drying Your Hair:

- Towel-dry your hair to remove excess water.
- Select your preferred speed and temperature settings.
- Direct the airflow towards your hair, moving the dryer continuously to prevent concentrating heat in one area.
- For best results, use the concentrator nozzle for precise styling.
- Approximate drying times:
 - Short hair: 1-2 minutes
 - Medium-length hair: 3-5 minutes
 - Thick and long hair: 5-8 minutes

Your browser does not support the video tag.

Video: Official demonstration of the 7MAGIC Foldable Fast-Drying Hair Dryer for Travel, showcasing its features and ease of use.

Your browser does not support the video tag.

Video: Official video highlighting the hair dryer's ability to dry hair 30% faster than ordinary models.

MAINTENANCE

Regular cleaning of your hair dryer will ensure optimal performance and extend its lifespan.

1. Cleaning the Air Inlet Filter:

- Ensure the hair dryer is unplugged and completely cool.
- The air inlet features a removable double safety dust cover. Gently twist or pull to remove the outer cover.
- Use the provided small soft brush accessories to clean any accumulated dust or hair from the metal filter screen and the dust cover.
- Once clean, reattach the dust cover by aligning and twisting or pushing until secure.

Detachable Air Filter

99% of your hair does not get sucked into the dryer



Image: The detachable air filter, illustrating how to remove the dust cover for cleaning.

2. General Cleaning:

- Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure the hair dryer is completely dry before storing or using again.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Hair dryer stops working or powers off unexpectedly.	Overheating safety protection activated.	Unplug the hair dryer and allow it to cool down for several minutes. Check the air inlet for blockages and clean if necessary. Once cool, plug it back in and press the "RESET" button on the ALCI plug before resuming use.
Hair dryer does not turn on.	No power or ALCI plug tripped.	Ensure the hair dryer is properly plugged into a working outlet. Press the "RESET" button on the ALCI plug. If the issue persists, check your household circuit breaker.
Reduced airflow or unusual noise.	Blocked air inlet filter.	Unplug the hair dryer and allow it to cool. Remove and clean the air inlet filter as described in the Maintenance section.

SPECIFICATIONS

Feature	Detail
Brand	7MAGIC
Model Number	7M3600
Product Dimensions	5.24 x 11.81 x 2.91 inches
Item Weight	0.9 Pounds (14.4 ounces)
Wattage	1600 watts
Voltage	110V-125V
Power Source	Corded Electric
Number of Speeds	2 (Low, High)
Number of Settings	5 (combining speed and temperature)
Temperature Settings	3 (Cool, Warm, Hot)
Maximum Temperature	450 Degrees Fahrenheit
Special Features	Foldable, Ionic Technology, Overheating Protection, ALCI Safety Plug, Removable Double Safety Dust Cover
Included Components	Travel size hair dryer, Concentrator nozzle, Storage bag, Small soft brush, Removable double safety dust cover
Material Type	Ceramic
Color	Green

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your product packaging or visit the official 7MAGIC website. Keep your purchase receipt as proof of purchase.